

Quick Start Guide

for Class 5 SmartMotor™





For complete installation and programming details, see the *Class 5 SmartMotor™ Installation and Startup Guide* and the *SmartMotor™ Developer's Guide*.



SMI* Introduction

Install the SMI Software


Download SMI from animatics.com/smi, then follow the on-screen instructions to complete the installation.




*SMI: SmartMotor™ Interface

Establish Communication

To establish communication between the PC and SmartMotor, use the Find Motors button.




If communication is successful, the motor icon appears, indicating the hardware connections and software installation are correct.




Double-click the motor icon. The Motor View shows key information, including position, firmware version and model.

SMI Tools

SMI Tools offer an array of advanced functionality for the application developer. For instructions, refer to SMI's online help or see the *SmartMotor Developer's Guide*.



SMI Standard Control Interface



Menu bar: All of the windows and functions of the SMI software can be accessed through the menu bar. Many of these are also accessible through the icons on the toolbar.

Toolbar: Used for accessing the primary features of the SMI software. Depending on the current state of the SMI software and the currently active window, some toolbar buttons may be disabled.

Configuration window: Displays all connections to PC, all motors connected to PC, and status on all motors.


Terminal window: Used to directly access real-time command and control of the motor.

Program editor: Used to manage, edit and print the user program that will be sent to the motor.

Information window: Display the results of user operations.

Basic Wiring

Single RS-232 Communication



- 7 Pin Combo D-Sub Connection**
- 1 I/O – 6 GP, Index Input or "G" Command; For -CDS7, CAN-L only
 - 2 +5 VDC Out; For -CDS7, CAN-H only
 - 3 RS-232 Transmit (Tx)
 - 4 RS-232 Receive (Rx)
 - 5 Common Ground (typ. SIG Ground)
 - A1 Main Power: +20-48 VDC
 - A2 Common Ground (req'd. POWER Ground)


- 9 PIN RS-232 Connection**
- 2 RS-232 Receive (Rx)
 - 3 RS-232 Transmit (Tx)
 - 5 RS-232 Ground (Gnd)

NOTE: Do not reverse the positive and negative leads from the power supply.
High-speed operation of the application requires 48 VDC input.

Basic Operating Instructions

Send Commands to the Motor

Use the Terminal window to enter single commands.



The following commands can be entered in the Terminal window.
NOTE: Comments on white background are for information only and cannot be typed.

Terminal Window - Sending Control Commands to the Motor	
Position Mode introduced	
MP	Set Position Mode (default power-up mode)
ADT=100	Set acceleration to 100 (1 rev / sec ² , 2 = 4, default is 0)
VT=32768	Set speed to 32768 (1 rps = 32768 = 60 rpm, default is 0)
PRT=4000	Set the relative position of 4000 (1 rev = 4000, default is 0)
G	Start motion
RPA	Returns the absolute position of the motor
OM=0	The current position set to 0
PT=40000	Set the absolute position of 40000 (10rev)
VT=327680	Set speed to 327680 (10rev/s)
G	Start motion
RPA	Returns the absolute position of the motor
Velocity Mode introduced	
MV	Set Velocity Mode
G	Start motion
VT=VT/2	Set half the rate of speed
G	Start motion
VT=-VT	Motor reverse
G	Start motion
X	Motor decelerates to a stop
Torque Mode introduced	
MT	Set Torque Mode
T=1600	Set the torque to ~5% (range +/- 32767)
G	Start motion
T=-T	Motor reverse
G	Start motion
T=T*2	Double the commanded torque
G	Start motion
X	Motor decelerates to a stop
Variables introduced	
a=123	Set the variable a value to 123
Ra	Returns the value of a variable
b=a+2	Set variable b value to the variable a plus 2
Rb	Returns the value of variable b
OFF	Turn off power to the motor coils and terminate motion
Z	Total reset, equivalent to power off and then on

Enter the following in the Program Editor window.

```

Simple Motion Control Program
EIGN(W,0)      *Disable hardware limits
ZS            *Clear all current faults
MP            *Set position mode
ADT=100       *Set accel/decel target
VT=32768     *Set velocity target
PRT=4000     *Set relative position target
G            *Start motion

TWAIT        *Wait for the previous action to complete, then continue
WAIT=1000   *Set wait time (1rps=1000)

RPA          *Show the actual position, then go to the next line
MV          *Set velocity mode

WAIT=1000*4 *Set position target
VT=32768   *Set velocity target
G          *Start motion

TWAIT      *Wait for the previous action to complete, then continue
WAIT=1000 *Set wait time (1rps=1000)
PRINT("Current Position",PA,#13)
MV          *Set velocity mode

WAIT=1000*4 *Set position target
VT=VT/2    *Set velocity target
G          *Start motion

TWAIT      *Wait for the previous action to complete, then continue
WAIT=1000 *Set wait time (1rps=1000)
VT=-VT    *Reverse direction and run at 1/2 previous velocity
G          *Start motion


ENDIF      *End of the IF structure
END        *End of the WHILE loop

LOOP      *End of the WHILE loop
END        *End of the program

*Move to sensor subroutine
C1
MV
ADT=100
VT=32767
OUT(3)=0
G
*While input 1 is low, keep moving
WHILE IN(1)=0
LOOP
*Set output 3 high to indicate stop
OUT(3)=1
X
*Decelerate to a stop
*While input 1 is high, don't move
WHILE IN(1)=1
LOOP
*Set output 3 low to indicate motion
OUT(3)=0
G
*Start moving again
*Toggle I/O port output subroutine
C2
OS (4)
WAIT=2000
OR (4)
WAIT=2000
RETURN
    
```

More programs are available at animatics.com/sample-programs


Download Program to the SmartMotor



I/O Control and Application

I/O Configuration Instructions


The SmartMotor has seven pins (I/O 0 - 6) to provide digital input (DI), digital output (DO) and analog input (AI); the following is a description of the SmartMotor 15-pin I/O:



15 PIN D-Sub I/O	
1 I/O – 0 GP or Enc A or Step Input	10 RS-232 Transmit;
2 I/O – 1 GP or Enc B or Direction Input	For -CDS/7, CAN-L only
3 I/O – 2 Positive Over Travel or GP	11 RS-232 Receive;
4 I/O – 3 Negative Over Travel or GP	For -CDS/7, CAN-H only
5 I/O – 4 GP, IIC or RS-485 A (Com ch. 1)	12 +5 VDC Out
6 I/O – 5 GP, IIC or RS-485 B (Com ch. 1)	13 Common Ground (typ. SIG Ground)
7 I/O – 6 GP, Index Input or "G" Command	14 Common Ground
8 Phase A Encoder Output	15 Main Power: +20-48 VDC; if DE option, Control Power separate from Main Power
9 Phase B Encoder Output	

- NOTES:**
- I/O 2 – Positive overtravel limit (for the CW direction of motor shaft)
 - I/O 3 – Negative overtravel limit (for the CCW direction of motor shaft)
 - I/O 6 – Enables motor movement (equivalent to the G command)
 - I/O ports input impedances = 5 kohm (5 kohm pull-up resistor)
 - GP I/O 0-6 are 25 mAmp Sink or Source, 10 Bit 0-5 VDC A/D

I/O Configuration Example



Wiring diagram example

I/O Control Program Example

```

I/O Applications Introduced
EIGN(W,0)      *Disable hardware limits
ZS            *Clear all current faults
OR (4)        *Reset I/O port 4 output OFF (OV)
GOSUB (1)     *Execute C1 Move to sensor subroutine
WHILE 1
IF IN(0)=0
*Logic loop (to determine the value 1 for infinite loop)
*Logic test to see if the condition is met, if so,
*execute the code within
VT=500000
ADT=100
G
WAIT=1000
*Pause 1 second
GOSUB (2)
*Execute C2 Toggle I/O port output subroutine
VT=-VT/2
ADT=100
G
*Reverse direction and run at 1/2 previous velocity
WAIT=1000
GOSUB (2)
*Pause 1 second
*Execute C2 Toggle I/O port output subroutine
ENDIF
*End of the IF structure
LOOP
*End of the WHILE loop
END
*End of the program

*Move to sensor subroutine
C1
MV
ADT=100
VT=32767
OUT(3)=0
G
*While input 1 is low, keep moving
WHILE IN(1)=0
LOOP
*Set output 3 high to indicate stop
OUT(3)=1
X
*Decelerate to a stop
*While input 1 is high, don't move
WHILE IN(1)=1
LOOP
*Set output 3 low to indicate motion
OUT(3)=0
G
*Start moving again
*Toggle I/O port output subroutine
C2
OS (4)
WAIT=2000
OR (4)
WAIT=2000
RETURN
    
```

