

SMART Motor

快
速
上
手



SMARTMOTOR 伺服馬達/控制器 應用說明書

MONTROL 敏石系統有限公司

www.montrol.com.tw

330桃園市同德11街58號10樓之2

tel:03.3586008 fax:03.3586009

e-mail:info@montrol.com.tw

單軸RS232通訊

SmartMotor Combo接頭

電腦RS232接頭

**7 Pin Combo D-Sub connection**

A1 +20V to +48V DC*

A2 Power Ground

1 Sync or I/O

2 +5V Out

3 RS232 Transmit (Tx)

4 RS232 Receive (Rx)

5 RS232 Ground (Gnd)

9PIN RS232 connection

2 RS232 Receive (Rx)

3 RS232 Transmit (Tx)

5 RS232 Ground (Gnd)

*注意電源正負極不可接反

*高速運轉之應用需使用48V 電壓輸入



安裝程式



SMIInstall.exe


請執行**SMI**安裝檔並依照選單依序執行下一步即可完成安裝

※**SMI**安裝檔可於敏石系統網站下載




SMI : Smart Motor Interface

建立PC與SmartMotor通訊為使用SMI軟體的第一步驟



在**Configuration**視窗內找到已連接的**ComPort**按右鍵
再按**Address RS-232 Chain**







若通訊成功將出現馬達圖示
此時表示硬體接線及軟體安裝
皆為正確


連按馬達圖示兩次，將顯示出
SmartMotor主要資訊，包括
位置、型號及韌體版本

使用工具

SMI Tools 工具程式
具有多樣及實用功能
使用者可依需求應用
進階操作說明請參考
SMI HELP...



SMI標準控制介面



Configuration

經由自動搜尋後，由此狀態欄可得知所有與電腦連接的馬達狀況。

Terminal

此視窗讓使用者透過即時且直接的指令控制馬達。

Program editor

此視窗讓使用者編輯將傳送到馬達的程式。

基本指令操作

將指令傳送至馬達

--請於 Terminal 視窗下執行--

傳送控制指令至馬達

EIGN(2)	*取消正極限
EIGN(3)	*取消負極限
ZS	*清除異常
MP	*設定為位置模式(程式預設模式，也可以不輸入)
ADT=400	*設定加減速為400 (1rev/sec ² =>4，預設值0)
VT=32768	*設定速度為32768 (1rps=60rpm=>32768，預設值0)
PRT=4000	*設定相對位置為4000 (1rev=>4000，預設值0)
G	*馬達動作開始
RPA	*回報馬達目前實際位置
O=0	*將目前位置設為0
RPA	
PT=12345	*設定絕對位置為12345
VT=327680	*設定速度為327680(10rps)
G	
RPA	
MV	*設定為速度模式
G	
VT=VT/2	*設定目標速度為目前速度的一半
G	
VT=-VT	*設定馬達反轉
G	
X	*馬達減速到停止
MT	*設定為扭力模式
T=1600	*設定扭力為1600 (馬達最大扭力為±32767)
G	
T=1800	
G	
T=-T	
G	
T=1300	
G	
X	*馬達減速到停止
a=123	*設定變數a數值為123
Ra	*回報變數a的數值
b=a+2	*設定變數b數值為a加2
Rb	*回報變數b的數值
OFF	*關閉馬達伺服控制
Z	*RESET，相當於關閉電源後再開機

--請於 Program editor 視窗下執行--

編輯控制程式並下載於馬達

EIGN(2) EIGN(3) ZS	'取消正負極限功能
AT=1000	'設定目標加速度值
DT=600	'設定目標減速度值
VT=30*32768	'設定目標速度值為30rps=1800rpm
PRT=20*4000	'設定目標(相對)位置值為20rev
a=0	'設變數a為0
WHILE a<3	'WHILE之後判斷若為真,則執行與LOOP間指令
a=a+1	'設定a值增加1
G	'執行馬達動作
TWAIT	'等待馬達動作停止,再繼續下一指令
WAIT=1000	'等待時間1秒=1000ms
LOOP	'回到相對應WHILE指令
PRT=1000	
b=0	
WHILE b<6	
b=b+1	
G	
TWAIT	
WAIT=150	
PRT=-PRT	'設定目標位置反轉
LOOP	'以下...可用空白鍵區隔指令
WAIT=2000 VT=VT*2 PT=0 G TWAIT WAIT=1000 RPA	
END	'程式結束

將程式下載於馬達




傳送至馬達後，如右圖所示，執行Run，或是重新啓動電源或按Reset，馬達就會依程式自動執行。

I/O 控制與應用

I/O的配置說明

SmartMotor具有7個接點(I/O 0~6) 提供使用者作數位輸入(DI)、輸出(DO) 以及類比輸入(AI)的應用，以下是 SmartMotor 15 PIN接點的介紹：





15 PIN D-Sub I/O

1 I/O 0	9 Encoder B Out
2 I/O 1	10 SM RS-232 Transmit
3 I/O 2 ※	11 SM RS-232 Receive
4 I/O 3 ※	12 +5V Out
5 I/O 4	13 Ground
6 I/O 5	14 Power Ground(A2)
7 I/O 6 ※	15 Main Power(A1)
8 Encoder A Out	

- ※ I/O 2 預設值為正極限接點 (面向馬達軸心CW方向)
- ※ I/O 3 預設值為負極限接點 (面向馬達軸心CCW方向)
- ※ I/O 6 預設值為執行動作接點 (相當於G指令)
- ※ 警告: SmartMotor內部 I/O 為5V，請勿輸入24V電壓電源

接線範例如右圖





運用類比輸入改變馬達位置

EIGN(2) EIGN(3) ZS

VT=100000

‘設定目標速度

ADT=1000

‘設定目標加減速

WHILE 1

‘無窮迴圈

b=INA(A, 0)

‘設定Input (0) 為類比型態，
並將值存為變數b

PT=b

‘設定目標位置為變數b

G

‘執行動作

LOOP

‘回到WHILE指令


END

‘程式結束

馬達跟隨運動與電子齒輪的應用

Master Motor

Slave Motor



Master 馬達內部 **Encoder** 輸出接腳為 8 與 9，
Slave 馬達接收外部 **Encoder** 的接腳是 1 與 2。

運用Encoder執行馬達跟隨運動

EIGN(2) EIGN(3) ZS

MFR

‘設定為跟隨模式

MFMUL=2

‘設定跟隨比例:分子

MFDIV=21

‘設定跟隨比例:分母

G

‘執行馬達跟隨運動

END

‘程式結束

基本程式流範例

IF ELSEIF ELSE ENDF structure:

```
IF a<b
    PRINT ("a is less than b",#13)
ELSEIF q==123
    PRINT ("q equals 123",#13)
ELSE 'if no condition above was true
    PRINT ("nothing above was true",#13)
ENDIF
```

WHILE LOOP structure:

```
a=0
    WHILE a<10
        a=a+1
    LOOP
PRINT ("loop code executed 10 times",#13)
```

GOTO, GOSUB structure:

```
C1
IF a>b
    GOTO (1)
ELSEIF b>c
    GOSUB (5)
ENDIF
GOTO (6)
C5
PRINT("b is greater than c",#13)
RETURN
C6
END
```

SWITCH CASE BREAK structure:

```
SWITCH a
    CASE 1
        PRINT("A=1",#13)
    BRAKE
    CASE 2
        PRINT("a=2",13)
    BRAKE
    DEFAULT
        PRINT("A DOES NOT EQUAL 1 OR 2 ",#13)
    BRAK
END
```

運用扭力控制模式

```

EIGN(2)
EIGN(3)
SLD
ZS
WHILE 1
  WHILE IN(1)==0
    ADT=500
    VT=327680
    PT=80000
    G
    TWAIT
    WAIT=1000
    OUT(4)=0
    MT
    T=1600
    q=100
    WHILE q>4
      w=PA
      WAIT=100
      e=PA
      q=e-w
    LOOP
    MP
    WAIT=3000
    OUT(4)=1
    ADT=250
    VT=6103
    PT=0
    G
    TWAIT
    WAIT=1000
  LOOP
LOOP
END

```

定位控制完成後，切換為扭力模式，當馬達運動受到阻礙(Encoder值不變)時停住並施以固定扭力及特定時間，再轉為定位模式回到原點

類比控制方向速度及位置教導

```


EIGN(2)
EIGN(3)
SLD
ZS
ADT=400
i=1
WHILE 1
  GOSUB(1)
  GOSUB(2)
  GOSUB(3)
LOOP
END
C1
IF IN(6)==0
  MV
  WHILE IN(6)==0
    h=INA(A,2)-16384
    VT=h*10
    G
  LOOP
  OFF
ENDIF
PRETURN
C2
IF IN(5)==0
  CLK=0
  WHILE IN(5)==0
    LOOP
    IF CLK>2000
      IF i==1
        a=PA
      ELSE
        b=PA
      ENDIF
      i=i-1
    ENDIF
  LOOP
  RETURN
C3
IF IN(3)==0
  MP
  VT=600000
  IF i==1
    PT=a
  ELSE
    PT=b
  ENDIF
  i=i-1
  G
  TWAIT
ENDIF
RETURN

```

C1:讓馬達產生位移，亦可用手推動
 C2:將位置點儲存於a,b變數
 C3:執行a,b點來回運動

多軸控制接線及定址

RS232 串接




9Pin RS232

- 2 RS232 Receive (Rx)
- 3 RS232 Transmit (Tx)
- 5 RS232 Ground (Gnd)

7 Pin Combo D-Sub

- A1 +20V to +48V DC
- A2 Power Ground
- 1 Sync or I/O
- 2 +5V Out
- 3 RS232 Transmit (Tx)
- 4 RS232 Receive (Rx)
- 5 RS232 Ground (Gnd)

RS485 並接



RS232/485轉接器

- 1 +5V
- 2 GND
- 3 RS-485A
- 4 RS-485B

15 Pin D-Sub

- 12 +5V out
- 13 Ground
- 5 I/O E
- 6 I/O F

- ※ RS485A連接 I/O#4，RS485B連接 I/O#5
- ※ RS485B與Ground之間需連接pull-down電阻(500Ω)
- ※ 如果最後一顆SmartMotor距離很遠，可能必需於RS485A與B之間連接shunt電阻(250Ω)
- ※ 採用雙絞線金屬隔離網，並且僅一端與Hoset Gnd接地，有較佳的防干擾作用
- ※ RS232/485轉接器之5V電源，最好由外部(非馬達)電源供應


定址 (Addressing)

目的：為了能夠將通訊的指令傳達到指定的馬達，所以必須先定義每個馬達在整個系統中的位址。

方法：SmartMotor 提供兩種方式來定義馬達位址：

- 1) 自動定址(Auto-Addressing)：每次開機後,系統依照接線順序自動做定址
- 2) 預設定址(Pre-Addressing)：預先將位址儲存至每一個馬達程式內

自動定址(Auto-Addressing)




執行SMI功能表上的按鈕



(Addressing)

馬達位址以馬達和電腦之間的接線順序自動決定，最靠近電腦的為馬達1，其次為馬達2，依此類推。

當完成後，系統將自動偵測，馬達狀態將會顯示如右圖



預設定址(Pre-Addressing)

我們依序將下列指令儲存在馬達內：

```
SADDRn  預先設定馬達位址為n(n=1,2,3,..)  
ECHO    開啓回應※  
END
```

※ 使用RS-232多軸通訊，全部的馬達必須開啓回應(ECHO)

※ 使用RS-485多軸通訊，全部的馬達必須關閉回應(ECHO OFF)

重新啓動電源 (Reset)後，不需再經由自動定址的步驟，即可完成定址的動作。

多軸指令

CANBUS多軸指令

2PT:3=1234

3PT:0=0

4PT=345

0G

0G:0

VTS=100000

ATS=1000

DTS=100

PTS(123000;1,20000;2)

GS

'Bank2中的Motor3目標位置設定 為1234

'Bank3全部的目標位置設定為0

'只Bank4的第一顆馬達目標位置 設定為345

'所有Bank的第一顆馬達執行G指令

所有的馬達執行G指令


設定多軸補間速度

設定多軸補間加速度

設定多軸補間減速度

設定多軸補間位置

執行多軸補間



多軸控制範例

0EIGN(2)	
0EIGN(3)	
0ZS	
0MP	'設定所有馬達為位置模式(程式預設模式)，也可不輸入
0ADT = 500	'設定所有馬達加速度為500(4 = 1rev/sec ²)
0VT = 32768	設定所有馬達速度為32768(32768 = 1rps = 60 rpm)
0PRT = 4000	'設定所有馬達相對位置為4000(4000 = 1rev)
0G	所有的馬達動作開始
1RPA	'回報馬達1的位置
2RPA	'回報馬達2的位置
0O = 0	'將所有的馬達目前位置設為原點
1MV	
1VT = 300000	
1ADT = 25	
1G	
1X	
1VT = -100000	
1G	
1X	
2MT	
2T = 1600	
2G	
2X	
2T = 1280	
2G	

※更多的範例程式可於原廠網站
www.SmartMotor.com下載

※圖弧補間運動須以PC通過.dll檔執行,請參考SMIEngine說明檔內容

Reference Key:

- is the IO Bit Number
m - is the mask value of which bits are affected
W - defines it as a word (16 bits)
expression - an expression must contain no more than a total maximum of 32 operators, values, and parenthesis.
value - a number, variable or math expression with one operand
constant - means a fixed integer
gen# Trajectory generator number: 1 or 2
i - Interrupt number , valid values are from 0 to 7

Communication Commands:

ADDR=expression Set motor's serial communications address. Applies for both RS232 and RS485
BAUD(x)=y This allows for COM0 or COM1 to be changed, x is the channel (0 or 1) and y is baud rate
CADDR=expression Set CAN address, can be different from serial address, default is 63
CBAUD=expression Set CAN baud rate, default is 125000
CCHN(RS2,0) Close communication channel command
ECHO Must be used to insure all data received in one motor will be echoed to next motor
ECHO_OFF Default, turn communication's echo off
GETCHR Get the next character from channel 0
GETCHR1 Get the next character from channel 1
LEN Number of characters in channel 0 buffer
LEN1 Number of characters in channel 1 buffer
OCHN(RS2,0,N,9600,1,8,C,1000) Default: (RS232,chan=0, no parity, 9600 baud,1 stopbit, 8 databits, command,1000 ms timeout)
PRINT("Hello World",#13) Print command to say "Hello World", see print section for more detailed examples
PRINT1("Hello World",#13) Print command to say "Hello World" on channel 1, see print section for more detailed example
RCADDR Reports CAN address
RCBAUD Reports CAN baud rate
SILENT Ignore print commands to channel 0 from user program
SILENT1 Ignore print commands to channel 1 from user program
SLEEP Ignore commands for channel 0 except the WAKE command
SLEEP1 Ignore commands for channel 1 except the WAKE command
TALK Enable prints for channel 0 from user program
TALK1 Enable prints for channel 1 from user program
WAKE Wake for channel 0
WAKE1 Wake for channel 1

Program Flow Commands:

CASE expression Switch case statement
C constant Subroutine label, e.g. C10 for subroutine 10, must have a RETURN for each C label
DEFAULT Default action for switch case statement
DITR(i) Individual interrupt disable
EITR(i) Individual interrupt enable

ELSEIF expression Used for IF statements to test another condition, if expression is true, then execute code
END End program execution
ENDIF End statement for IF code structures
ENDS Command for end of switch case statement
GOSUB(value) Call a subroutine, value up to 999
GOTO(value) Jump program execution to a label, value up to 999
IF expression Conditional Test, expression can be multiple math operations
ITR(i, status_wrd#, bit#, s_label#) Interrupt setup
ITRD Global interrupt scanner disable
ITRE Global interrupt scanner enable
LOOP Loop command for while loops
PAUSE Pause program execution, used for interrupts
RESUME Resume program execution
RETURN Return from subroutine
RETURNI Return from interrupt
RUN Start program execution
RUN? Wait at this point for RUN command before program starts to execute
STACK Resets all GOSUB stack returns and Interrupts
SWITCH expression Switch case statement
TWAIT Wait for trajectory to complete, only used in program
TWAIT(gen#) Wait for trajectory generator (gen#) to complete it's move
TSWAIT Wait for synchronized trajectory to complete, down loaded program only * **COMBITRONIC**[®]
WAIT=expression Set wait time in milliseconds
WHILE expression

I/O Commands:

EIGN(#) Assign a single I/O point as general use input
EIGN(W,0) Assign all local I/O as general use inputs
EIGN(W,0,m) Assign a masked word-sized set of local I/O as general use inputs at once
EILN Set port C (I/O-2) as negative over travel limit
EILP Set port D (I/O-3) as positive over travel limit
EIRE Set I/O 6 to capture external encoder's current value
EIRI Set I/O 6 to capture internal encoder's current value
EOBK(#) Configure a given output to control an external brake
IN(#) x=IN(#), assign the state of a specific I/O to a variable (x in this case)
IN(W,0) x=IN(W,0), assign the state of the first word of local I/O to the variable x
INA(A,#) x=INA(A,#), raw analog reading: 10 bit resolution spanned over signed 16 bit range
INA(V,#) x=INA(V,#), input voltage in millivolts of analog input value for a given I/O defined by #
INA(V1,#) x=INA(V1,#), scaled 0-5 VDC reading in millivolts directly, 3456 would be 3.456 VDC
OR(value) Reset output (turn off)
OS(value) Set output (turn on)
OUT(#)=expression if expression LSB = 1, then it's true(1), otherwise it's false (0)

Math Commands:

- Subtract
I| Bitwise exclusive OR
!= Not equal to
% Modulo (remainder) division
& Bitwise AND
***** Multiply
/ Divide
^ Power limited to 4th power and below, integers only
| Bitwise inclusive OR
+ Add
< Less than
<= Less than or equal to
= Equal to
> Greater than
>= Greater than or equal to
ABS(value) Absolute Value
ACOS(value) Arc Cosine
ASIN(value) Arc Sine
ATAN(value) Arc Tangent
COS(value) Cosine
FABS(value) Floating point absolute value
FSQRT(value) Floating point square root
RANDOM=expression Set the random seed value 0 to 2³¹ - 1
RRANDOM Report the next available random number in the range 0 to 2³¹ - 1
SIN(value) Sine
SQRT(value) Square Root
TAN(value) Tangent
TMR(x,t) Sets timer x for t milliseconds

Motion Commands:

ADT=expression Set the accel/decel at once for a move * **COMBITRONIC**[®]
ADTS=expression Set sync accel/decel at once for a move
Ai(0) Arm index rising edge of internal encoder
Ai(1) Arm index rising edge of external encoder
Ai(j)(0) Arm index rising edge then falling edge internal encoder
Ai(j)(1) Arm index rising edge then falling edge external encoder
Aj(0) Arm index falling edge of internal encoder
Aj(1) Arm index falling edge of external encoder
Aj(i)(0) Arm index falling edge then rising edge internal encoder
Aj(i)(1) Arm index falling edge then rising edge external encoder
AMPS=expression Current limit value. 0-1023
AT=expression Set the acceleration target for a move
ATS=expression Set sync acceleration target for a move * **COMBITRONIC**[®]
BREAK Break out of while loop
BRKENG Manually Engage the brake
BRKRLS Manually Release the brake
BRKSRV Brake Servo, engage the brake when the drive is not active (default)
BRKTRJ Brake Trajectory
CTR(0) Present value of internal encoder
CTR(1) Present value of external encoder
DEL=expression Set maximum allowable derivative error limit
DT=expression Set the deceleration target for a move
DTS=expression Set sync deceleration for

a move * **COMBIBTRONIC**™

LE-expression Set maximum allowable following error limit

ENC1 Enable external encoder for servo

ENC0 Enable internal encoder for servo

F Set tuning values

G Go, initiates all buffered modes of operation

G(gen#) Go, initiate motion in trajectory generator (gen#)

GS Go synchronized, initiates linear interpolated moves * **COMBIBTRONIC**™

KA=expression Feed forward gain

KD=expression Derivative gain coefficient

KG=expression Gravity offset

KI=expression PID integral gain

KL=expression PID integral limit

KP=expression PID proportional gain

KS=expression Differential sample rate

KV=expression Velocity feed forward gain

MC Initiate electronic camming

MC(2) Set Trajectory Generator 2 to run in electronic camming

MDB Enable TOB when in one of the 2 trapezoidal modes

MDE Set motor to enhanced trapezoidal mode commutation by using encoder

MDS Set motor to sine mode commutation

MDT Set motor to trapezoidal mode commutation using hall sensors (default mode)

MFA(value) Accel over value master distance. Default is zero (off)

MFD(value) Decel over value master distance. Default is zero (off)

MFDIV=expression Assign Incoming counts Divisor

MFML=expression Assign Incoming counts Multiplier

MF0 Initiate and zero counter, but do not follow

MFR Select follow mode using quadrature encoder input.

MFR(2) Set Trajectory Generator 2 to run in Mode Follow Ratio (electronic Gearing)

MFSLEW(value) Stay at slew for value distance, then decel

MINV(0) Default motor commutation direction

MINV(1) Invert commutation, shaft rotates opposite direction

MP Initiate Position Mode

MP(1) Set Trajectory Generator 1 to run in Position Mode

MS0 Initiate and zero counter, but do not follow

MSR Calculate Mode Step Ratio and prepare to follow

MT Initiate Torque Mode (Open Loop)

MTB Enable mode torque brake

MV Initiate Velocity Mode

MV(1) Set Trajectory Generator 1 to run in Velocity Mode

O=expression Set origin, set present position to some value

O(gen#)=expression Set origin for move gen# to some value

OFF Turn the amplifier off

OSH=expression Origin shift of position counter on the fly

OSH(gen#)=expression Shift origin for move gen# by some value

PML=expression Sets the position modulo limit wrap value

PMT=expression Set the position modulo target

PRT=expression Set the relative target position

tion

PRTS=(dist1,axis1,dist2,axis2,dist3,axis3) Set synchronized relative target position

* **COMBIBTRONIC**™

PRSS=(dis1,axis) Set supplemental synchronized relative target position * **COMBIBTRONIC**™

PT=expression Set the absolute target position

PTS=(dist1,axis1,dist2,axis2,dist3,axis3) Set synchronized absolute target position

* **COMBIBTRONIC**™

PTSS=(dist1,axis) Set supplemental synchronized absolute target position * **COMBIBTRONIC**™

S Instantly stop motor

S(gen#) Instantly stop trajectory generator (gen#)

T=expression Set the commanded torque while in MT mode

TH=expression Set maximum allowable thermal limit (degrees C)

VT=expression Set the velocity target for a move

VTS=expression Set synchronized velocity target for a move * **COMBIBTRONIC**™

X Decelerate to a stop at present deceleration rate

X(gen#) Decelerate to a stop, trajectory generate (gen#)

Status Commands:

Ba Over current bit, status word 0, bit 4 status word 1, bit 3

Be Excessive position error, status word 0, bit 6

Bh Excessive temperature occurred, status word 0, bit 5

Bl Left (-) over travel limit, status word 0, bit 13

Bm Left (-) over travel limit active, status word 0, bit 15

Bo Motor is off, status word 0, bit 1

Bp Right (+) over travel limit active, status word 0, bit 14

Br Right (+) over travel limit, status word 0, bit 12

Bt Trajectory in progress, status word 0, bit 2

Bv Velocity limit, status word 0, bit 7

CLK=expression System Clock value in milliseconds

RAC Report commanded acceleration

RAT Report target acceleration

RA Report value of variable 'a'

Rab[0] Report value of ab[0]

Raf[0] Report floating point value of af[0]

Ral[0] Report value of al[0]

Raw[0] Report value of aw[0]

RCKS Report Checksum

RB(sw,b) Report status bit, b, from status word, sw

RCLK Report system clock in milliseconds

RCTR(0) Report present value of internal encoder

RCTR(1) Report present value of external encoder

RDEA Report actual derivative error

RDEL Report commanded derivative error limit

RDET Report target deceleration

REA Report actual following error

REL Report commanded following error limit

RI (0) Report where the rising edge of the internal index was detected

RI (1) Report where the rising edge of the external index was detected

RIN(#) Report the state of a I/O

RIN(W,0) Report the first word of local I/O

RINA(V,#) Reports voltage level (scaled from supply) of analog input value for a given I/O defined by #

RINA(V1,#) Reports voltage level (scaled 0-5 VDC) of analog input value for a given I/O defined by #

RJ(0) Report where the falling edge of the internal index was detected

RJ(1) Report where the falling edge of the external index was detected

RMFDIV Report Divisor

RMFMUL Report Multiplier

RPA Report present actual position

RPC Report present commanded position

RPC(gen#) Report commanded position for trajectory generator (gen#)

RPMA Report the current modulo counter

RPML Report position modulo limit

RPMT Report the most recent setting of PMT (position modulo target)

RPRA Report actual relative position

RPRC Report commanded relative position

RPRT Report present relative target position

RPT Report present target position

RRES Report encoder resolution of motor

RSP Report sampling rate and firmware version

RTMR(x) Report timer x (present time left in milliseconds)

RT Report commanded torque

RV Report commanded velocity

RVT Report target velocity

RUIA Reports current (Amps=UJA/1000)

RUJA Reports bus voltage (Volts=UJA/1000)

RW(value) Report status word

Z(sw,b) Clears/zeroes status word bits

Za Reset over current bit

Ze Reset position error bit

Zh Reset over temperature bit

Zl Reset left(-) historical limit bit

Zr Reset right(+) historical limit bit

ZS Clear all errors, reset system latches to power up state

Zw Reset wraparound bit

Variable Commands:

a=expression Variable, 32 bit signed integers, a-z, aa-zz, aaa-zzz, 78 total variables

ab[x]=expression Array variables, 8 bit byte arrays, x can be 0-203

af[x]=expression Floating point array variables, x can be 0-7

al[x]=expression Array variables, 32 bit long arrays, x can be 0-50

aw[x]=expression Array variables, 16 bit word arrays, x can be 0-101

EPTR=expression EEPROM pointer, non-volatile memory, use before VLD and VST commands

VLD(variable,quantity) Load values from EEPROM to variables starting at EPTR location

VST(variable,quantity) Store values to EEPROM from variables starting at EPTR location

Note: See users guide for complete list of commands and full syntax. Many commands such as Cam mode and dual trajectory mode commands are not fully explained here.