



PLC Commissioning of LinMot Servo Drives

Application Note / How-to

Latest version:

<https://shop.linmot.com/E/product/0185-1120-E>

© 2023 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

All other product and company names and marks mentioned in this document are the property of their respective owners and are mentioned for identification purposes only.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Table of Contents

Table of Contents	3
Use of This Document	10
Version History	11
Trademarks	12
1 General	13
1.1 Abbreviations.....	13
1.1.1 LinMot Drive System Generations (SG).....	13
1.1.2 LinMot Drive Interface Extensions	13
1.2 LinMot Drives with multi-interface (MI) Overview / C1250-xx replacement	14
1.3 Available LinMot Libraries	16
1.4 Documentation / User Manuals / Application Notes.....	17
1.5 UPID (Unique Parameter ID)	18
1.6 Recent Version of LinMot-Talk and Drive Firmware.....	18
1.7 YouTube Video Tutorials	18
1.8 LinMot Product Information	18
2 Overview	19
2.1 LinMot Profile (Commissioning using the LinMot Libraries).....	19
2.2 Drive Profiles (Direct Integration as Motion Axis using standardized Drive Profiles).....	20
3 LinMot Profile: Beckhoff TwinCAT 2&3	21
3.1 Overview	21
3.2 Configuration and Connection of the LinMot Drive	22
3.2.1 Motor Configuration.....	22
3.2.2 XML Files	22
3.2.3 EtherCAT Connection	22
3.3 PLC Setup EtherCAT (E1450-EC-QN, E1250-EC-UC, C1x00-EC-XC-xx).....	23
3.3.1 Insert LinMot Drive as Slave	23
3.3.2 Config Module	24
3.3.3 Links to PLC Control	25
3.3.4 Check EoE settings.....	26
3.4 Add Additional Parameters or Variables to the Process Data.....	27
3.5 Check with LinMot-Talk if the Fieldbus is running	27
3.6 Next Steps.....	27
4 LinMot Profile: Siemens TIA	28
4.1 Overview	28
4.2 Configuration and Connection of the LinMot Drive	29
4.2.1 Motor configuration	29
4.2.2 GSD / GSDML files	29
4.2.3 PROFIBUS Connection	29
4.2.4 PROFINET Connection	31
4.3 PLC Setup PROFIBUS (E1430-DP-QN, E1230-DP-UC, E1130-DP-xx)	32
4.4 PLC Setup PROFINET (E1450-PN-QN, E1250-PN-UC, C1250-PN-UC, C1150PN-UC)	34
4.4.1 Assigning the Device Name and IP Address.....	36
4.5 Check with LinMot-Talk if the Fieldbus is running	39
4.6 Next Steps.....	39
5 LinMot Profile: Rockwell Automation Studio 5000 (Outdated).....	40
5.1 Overview	40
5.2 Minimum Requirements	40
5.3 Configuration and Connection of the LinMot Drive	41
5.3.1 Motor Configuration.....	41

5.3.2 EDS Files (Requires Studio 5000 V20 or higher)	41
5.3.3 EtherNet/IP Connection	41
5.3.4 IP Address	41
5.4 PLC Setup EtherNet/IP	42
5.4.1 RSLinx Classic	42
5.4.2 Add a LinMot drive using AOP (E1250-IP-xx, C1250-IP-xx)	43
5.4.3 Add a LinMot drive using the EDS file (recommended for Studio <V31)	47
5.4.4 Add a LinMot drive as Generic Ethernet Module (ETHERNET-MODULE)	50
5.5 Check with LinMot-Talk if the Fieldbus is running	52
5.6 Next Steps	52
6 LinMot Profile: B&R Automation Studio	53
6.1 Overview	53
6.2 Configuration and Connection of the LinMot Drive	54
6.2.1 Motor configuration	54
6.2.2 XDD File	54
6.2.3 Powerlink Connection	54
6.2.4 Node ID	55
6.3 Hardware Configuration	56
6.3.1 Add the LinMot drive to the Powerlink network	56
6.3.2 Configuration	57
6.3.3 I/O Mapping	58
6.4 Parameter Access	59
6.5 Add Additional Parameters or Variables to the Process Data	59
6.6 Next Steps	59
7 LinMot Profile: CODESYS	60
7.1 Overview	60
8 LinMot Profile: Mitsubishi GX Works	61
8.1 Overview	61
8.2 Configuration and Connection of the LinMot Drive	62
8.2.1 Motor configuration	62
8.2.2 CSP+ files	62
8.2.3 CC Link Connection	62
8.2.4 IP Address	63
8.3 PLC Setup CC Link	64
8.4 Check with LinMot-Talk if the Fieldbus is running	68
8.5 Next Steps	68
9 Drive Profile: Rockwell Automation Motion (CIP Sync)	69
9.1 Overview	69
10 Drive Profile: Siemens TIA, PROFIdrive	70
10.1 Overview	70
10.2 Configuration and Connection of the LinMot Drive	71
10.2.1 Motor Configuration	71
10.2.2 GSDML File	72
10.2.3 PROFINET Connection	72
10.3 PLC Setup	73
10.3.1 Install GSDML File(s)	73
10.3.2 Insert the LinMot Drive as Device (-PD Drives)	73
10.3.3 Insert the LinMot Drive as Device (-MI Drives)	74
10.3.4 Set PROFINET Name and IP Address	75
10.3.5 Insert and Setup a new Technology object (Linear Axis)	77
10.3.6 Insert and Setup a new Technology object (Rotary Axis)	83

10.4 Home / Set Reference	89
10.4.1 Active Homing for both linear and rotary motors with incremental encoders.....	89
10.4.2 Set Reference for both linear and rotary motors with absolute encoders.....	92
10.4.3 Application based example to home a LinMot Linear Axis.....	93
10.5 Parameter Access (RAM).....	95
10.6 Add Additional Parameters / Variables to the Real-Time Channel	96
10.6.1 Drive Configuration	96
10.6.2 PLC Configuration.....	97
10.7 Telegram 750 / TDB	98
10.7.1 LinMot MI Drives	98
10.7.2 LinMot PD Drives	99
10.8 Using the Closed Loop Force/Torque Control Technology Function	102
10.8.1 Add 1 Monitoring and 2 Parameter Channels / Drive Setup	103
10.8.2 Scaling the Parameter and Monitoring Channels	105
10.8.3 Example Sequence	106
10.9 Tuning the Control Loops	108
10.9.1 Drive Control Loop	108
10.9.2 PLC Control Loop.....	110
10.10 Check with LinMot-Talk if the Fieldbus is running.....	111
11 Drive Profile: Beckhoff TwinCAT 2/3, CoE DS402	112
11.1 Overview.....	112
11.2 Configuration and Connection of the LinMot Drive	113
11.2.1 Motor Configuration.....	113
11.2.2 XML File	114
11.2.3 EtherCAT Connection.....	114
11.3 PLC Setup	115
11.3.1 EtherCAT Device Description File XML.....	115
11.3.2 Scanning the EtherCAT for new Devices	115
11.3.3 Setting up the Process Data of the LinMot Drive	117
11.3.4 Check EoE settings	119
11.3.5 Setting up the NC Axis	120
11.4 Encoder Parameter Examples for Linear and Rotary Motors (Axis > Enc).....	124
11.4.1 Linear Motors PS01 / PS10.....	124
11.4.2 Rotary Motors RS01 & RS02	125
11.4.3 Rotary Motors EC02.....	126
11.4.4 Other motors	127
11.5 Homing	128
11.5.1 Homing using the MC_Home function block and simulate a reference CAM	128
11.5.2 Homing using the drive-controlled homing (Mode of Operation 6)	129
11.6 Visualization	130
11.7 Drive Reset.....	130
11.8 Asynchronous Parameter Access	131
11.9 Add Positive and Negative torque/force limit (0x1711) to the Process Data.....	133
11.10 Add Additional Parameters or Variables to the Process Data	135
11.11 Using the Closed Loop Force/Torque Control Technology Function	139
11.11.1 Drive Setup	139
11.11.2 PLC Setup	140
11.11.3 Example Sequence	141
12 Drive Profile: Beckhoff TwinCAT 2/3, SoE (Outdated)	142
12.1 Overview	142
12.2 Configuration and Connection of the LinMot Drive	143

12.2.1 Motor Configuration.....	143
12.2.2 XML File	144
12.2.3 EtherCAT Connection	144
12.3 PLC Setup.....	145
12.3.1 EtherCAT Device Description File XML	145
12.3.2 Scanning the EtherCAT for new Devices	145
12.3.3 Setting up the Process Data of the LinMot Drive	147
12.3.4 Check EoE settings.....	149
12.3.5 Setting up the NC Axis	150
12.4 Encoder Parameter Examples for Linear and Rotary Motors	152
12.4.1 Linear Motors PS01 / PS10	152
12.4.2 Rotary Motors RS01 & RS02	152
12.4.3 Rotary Motors EC02.....	153
12.4.4 Other motors	153
12.5 Homing	154
12.6 Visualization	155
12.7 Drive Reset.....	155
12.8 Asynchronous Parameter Access	156
12.9 Add Additional Parameters or Variables to the Process Data (MDT 1 / AT 1)	158
13 Drive Profile: Schneider Electric PacDrive 3, FSP_DRIVE.....	161
13.1 Overview	161
13.2 Configuration and Connection of the LinMot Drive	162
13.2.1 Motor Configuration.....	162
13.2.2 Sercos Connection.....	163
13.2.3 Sercos Address	164
13.3 PLC Setup.....	165
13.3.1 General Device Properties.....	165
13.3.2 Add the LinMot Drive to the Sercos	166
13.3.3 Device Configuration.....	167
13.3.3.1 Identification	167
13.3.3.2 Motor/Mechanic using a LinMot linear motor.....	168
13.3.3.3 Motor/Mechanic using a rotary motor	169
13.3.3.4 Realtime channel	170
13.4 Homing (Linear Motors)	171
13.4.1 Homing using the Schneider template (FB_Home)	171
13.4.1.1 Setup.....	171
13.4.2 Drive-Based Homing (S-0-0148).....	172
13.5 Parameter Access	173
13.5.1 Supported UPID Functions via IDN Access over the Sercos Service Channel	173
13.5.2 Read RAM Parameter Example.....	174
13.5.3 Write RAM Parameter Example	175
13.6 Enable/Disable Drive Warnings	176
14 Drive Profile: CODESYS SoftMotion, CiA402	177
14.1 Overview	177
14.2 Configuration and Connection of the LinMot Drive	178
14.2.1 Motor Configuration.....	178
14.2.2 XML File	179
14.2.3 EtherCAT Connection	179
14.3 PLC Setup.....	180
14.3.1 EtherCAT Device Description File XML	180
14.3.2 Add and setup the LinMot drive	180

14.3.3 Check EoE settings.....	182
14.4 Homing	183
14.5 Visualization	184
14.6 Parameter Access	185
14.7 Add Additional Parameters or Variables to the Process Data.....	186
15 Drive Profile: B&R NC Motion, CiA402.....	189
15.1 Overview	189
15.2 Preconditions to use DS402 / CiA402.....	190
15.3 Supported operating modes.....	190
15.4 Configuration and Connection of the LinMot Drive	191
15.4.1 Motor Configuration.....	191
15.4.2 XDD File	192
15.4.3 Powerlink Connection	192
15.4.4 Node ID	192
15.5 Automation Studio Physical View.....	193
15.5.1 Add the LinMot drive to the Powerlink network.....	193
15.5.2 Configuration	194
15.5.2.1 Linear Axis (10'000 increments per revolution):.....	194
15.5.2.2 Rotary Axis PR01 or PR02 (360'000 increments per revolution):.....	195
15.6 Automation Studio Configuration View.....	196
15.6.1 Add axis objects	196
15.7 Homing	197
15.7.1 Linear Motor	198
15.7.2 Rotary Motor	198
15.8 Parameter access	199
15.8.1 SDO commands	199
15.9 Add Additional Parameters or Variables to the Process Data.....	201
16 Drive Profile: B&R NC Motion, SDC interface	202
16.1 Overview	202
16.2 Compatibility LinMot_SDC <> ACP10 ARNC0	203
16.3 Configuration and Connection of the LinMot Drive	204
16.3.1 Motor Configuration.....	204
16.3.2 XDD File	205
16.3.3 Powerlink Connection	205
16.3.4 Node ID	205
16.4 Short Description of the LinMot SDC interface function block	206
16.4.1 Principle of Operation.....	206
16.4.2 HTML Help	206
16.4.3 LM_Sdclf (Interface Function Block).....	207
16.4.4 enCallType	207
16.4.5 stConfig	207
16.5 Prerequisites	208
16.6 Automation Studio Physical View.....	209
16.6.1 Add the LinMot drive to the Powerlink network.....	209
16.6.2 Configuration.....	210
16.6.3 I/O Mapping.....	211
16.6.4 Powerlink Interface and PLC Configuration	212
16.6.5 Add a B&R drive to generate all NC object specific requirements automatically	213
16.7 Automation Studio Configuration View.....	215
16.7.1 Setup NC Manager and NC Mapping	215
16.7.2 Add new NC Object.....	217

16.7.3 Add TextSystem	218
16.8 Automation Studio Logical View: Linear Motor Example	220
16.8.1 Add the example program to the project	220
16.8.2 ACOPoS Parameter Table	220
16.8.3 Init Parameter Table	221
16.8.4 Check Init Parameters of the SDC function block	222
16.8.5 Assign the example program to Cyclic #1	222
16.9 Automation Studio Logical View: Rotary Motor Example	223
16.9.1 Add the example program to the project	223
16.9.2 ACOPoS Parameter Table	224
16.9.3 Init Parameter Table	226
16.9.4 Check Init Parameters of the SDC function block	227
16.9.5 Assign the example program to Cyclic #1	227
16.10 Homing	228
16.10.1 Linear Motor	228
16.10.2 Rotary Motor	228
16.10.3 Reference Switch (mcHOME_ABS_SWITCH)	229
16.11 Test	231
16.11.1 Switch On	231
16.11.2 Homing	232
16.11.3 Error Acknowledge	232
16.12 Parameter Access	233
16.12.1 Parameter access by LMcf_ParaAccess function block	233
16.12.2 Parameter access by SDO commands	234
16.13 Add Additional Parameters or Variables to the Process Data	236
16.14 Errors (LM_Sdclf outputs)	237
16.14.1 bError	237
16.14.2 diStatusID	237
16.14.3 uiErrorCode	237
17 Drive Profile: OMRON Sysmac Studio, CoE DS402	238
17.1 Overview	238
17.2 Configuration and Connection of the LinMot Drive	239
17.2.1 Motor Configuration	239
17.2.2 XML File	240
17.2.3 EtherCAT Connection	240
17.3 PLC Setup	241
17.3.1 Install EtherCAT Device Description File XML	241
17.3.2 Define EtherCAT node address on LinMot-Device	242
17.3.2.1 Set node address by address selector on device	242
17.3.2.2 Set node address by parameter on device	243
17.3.2.3 Write node address from Sysmac Studio	244
17.3.2.4 Set node address by function block	245
17.3.3 Scanning the EtherCAT network for devices	246
17.3.4 Edit PDO mapping	247
17.3.5 Create a motion axis and link it to your physical LinMot axis	248
17.3.6 Setting up the motion axis	250
17.4 Homing procedure on Sysmac with ABS Encoder	252
17.5 Drive Based Homing (INC Encoder)	252
17.5.1 Settings on LinMot drive	252
17.5.2 Function blocks required on Sysmac	253
17.5.2.1 EC_CoESDORRead	253

17.5.2.2 EC_CoESDOWrite	253
17.5.2.3 MC_ResetFollowingError	253
17.5.2.4 MC_HomeWithParameter	253
17.5.3 Homing procedure on Sysmac (motors with INC Encoder)	254
17.6 Drive reset to clear axis error	256
17.7 Control of force / torque	256
17.7.1 Limiting force or torque output in Position-Control-Mode	256
17.7.2 Control force or torque output in Torque-Control-Mode (CST Mode 10)	257
17.7.2.1 Speed Limiter for Torque/Force-Control-Mode	257
17.7.2.2 Torque/Force-Control-Mode in CST Mode 10	258
17.8 Parameter Access	260
17.8.1 PDO Access	260
17.8.2 Example for user defined PDO access	260
17.8.2.1 PDO Map	260
17.8.2.2 I/O Map	261
17.8.2.3 Scaling of mapped PDO	262
17.8.3 SDO Access	264
18 Drive Profile: TRIO, CiA402	265
18.1 Overview	265
18.2 Configuration and Connection of the LinMot Drive	266
18.2.1 Motor Configuration	266
18.2.2 XML File	267
18.2.3 EtherCAT Connection	267
18.2.4 Set the node address / station alias by address selectors on the drive	267
18.3 Controller Setup	268
18.3.1 EtherCAT Device Description File (XML)	268
18.3.2 Add and setup the LinMot drive	268
18.3.3 UNITS for Linear and Rotary Motors	273
18.4 Homing	274
18.5 Parameter Access	275
18.6 Examples	276
19 Troubleshooting	277
Appendix I: Basic Position Control Loop Tuning	279
Appendix II: Basic Closed Loop Torque/Force Control Loop Tuning	281
Notes	284
Contact & Support	285

Use of This Document

This document is an Application Note / How-To to help the user connecting LinMot drives to different PLC types.

It provides guides when using function block libraries provided by NTI AG / LinMot and guides to integrate LinMot drives using standardized drive profiles.

This document is provided by NTI AG / LinMot free of charge with no warranty for updates.

Also, LinMot accepts no liability for damages that may be caused by using this document or programming examples referred to.

Drives: Various

Classification: Application Note
 Installation Guide
 User Manual
 Documentation
 LinMot internally

Version History

Version	Date	Author	Description
1V0	31/05/2017	fj	Initial Release
1V1	13/06/2017	fj	Minor corrections
1V2	10/07/2017	fj	Added chapter 14 Drive Profile: CODESYS SoftMotion, CiA402
1V3	27/03/2019	fj / mm	Added chapter 9 Drive Profile: Rockwell Automation Motion (CIP Sync) Added chapter 12.4 Encoder Parameter Examples for Linear and Rotary Motors Added chapter 11 Drive Profile: Beckhoff TwinCAT 2/3, CoE DS402 Added chapter 13.3.3.3 Motor/Mechanic using a rotary motor Added chapter 16 Drive Profile: B&R NC Motion, SDC interface Updated chapter 10 Drive Profile: Siemens TIA, PROFIdrive Removed chapter OMRON with EC drives (obsolete) Various minor updates and corrections
1V4	03/06/2019	fj	Minor: added library compatibility list: chapter 16.2 Minor: fixed screenshot and description in chapter 16.13
1V5	26/02/2020	fj	Added chapter 13.4.1 Homing using the Schneider template (FB_Home) Added chapter Trademarks Various minor updates and corrections
1V6	06/08/2020	fj / mr	Updated chapter 17.1 Overview of Drive Profile: OMRON Sysmac Studio, CoE DS402 Updated chapter 10.4.3 Application based example to home a LinMot Linear Axis and created new example projects Added chapter 8 LinMot Profile: Mitsubishi Removed/Updated contact information on page 2 and the last page
1V7	13/07/2021	fj / pk	Added chapter 6 LinMot Profile: B&R Automation Studio Added chapter 7 LinMot Profile: CODESYS Added chapter 10.7 Telegram 750 / TDB Added chapter 10.8 Using the Closed Loop Force/Torque Control Technology Function Updated chapter 11 Drive Profile: Beckhoff TwinCAT 2/3, CoE DS402 for Firmware 6.10 Updated chapter 11.5 Homing: added MC_Home example Added chapter 11.11 Using the Closed Loop Force/Torque Control Technology Function Added chapter 15 Drive Profile: B&R NC Motion, CiA402 Updated chapter 17 Drive Profile: OMRON Sysmac Studio, CoE DS402 for FW 6.10 Added chapter 18 Drive Profile: TRIO, CiA402 Added chapter Appendix II: Basic Closed Loop Torque/Force Control Loop Tuning Small corrections, updates, and improvements over all document
1V8	07/09/2021	fj	Rearranged homing variants in chapter 10.4 Home / Set Reference
1V9	01/11/2021	fj	Updated/Corrected chapter 11.4
1V10	22/09/2022	fj / pk / mr	Added chapter 1.2 LinMot Drives with multi-interface (MI) Overview / C1250-xx replacement Updated chapter 10.9.1 Updated all chapters to support LinMot C125x-MI drives

Trademarks

Product and company names and logos referenced may be either trademarks or registered trademarks of their respective companies. The sole purpose of any trademarks in this document is the identification of the corresponding products.

Company	Trademarks / Registered Trademarks
Siemens AG	SIEMENS®, SIMATIC®, TIA Portal®, Step 7®
Rockwell Automation, Inc	Rockwell Automation®, Allen-Bradley®, CompactLogix™, ControlLogix®, Studio 5000®, Studio 5000 Logix Designer®, RSLogix 5000®, Stratix®, RSLinx®,
Beckhoff Automation GmbH	Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®
Schneider Electric	PacDrive®, SoMachine®
Bosch Rexroth	IndraControl, IndraMotion
3S-Smart Software Solutions GmbH	CODESYS
B&R Industrial Automation GmbH	B&R Automation Studio®, Ethernet POWERLINK®
Omron	SYSMAC®
Profibus and Profinet International (P.I.)	Profibus®, Profinet®
Interests Group SERCOS interface e.V	SERCOS interface®
ODVA, Inc	EtherNet/IP™, CIP™, CIP Sync™
Trio Motion Technology Ltd	<i>Motion Perfect</i>

All other product and company names and marks mentioned in this document are the property of their respective owners and are mentioned for identification purposes only.

1 General

1.1 Abbreviations

1.1.1 LinMot Drive System Generations (SG)

SG	Drives
SG3	Family E1100 (GP, CO, DN, DP) (LC/HC/XC)
SG4	Family B1100 (VF, PP, GP, ML) (LC/HC/XC)
SG5	Family E1200 (GP, DP, DS, EC, IP, PD, PL, PN, SC, SE, LU) Family E1400 (GP, DP, DS, EC, IP, PD, PL, PN, SC, SE, LU) (0S/1S) Family B8000-ML (GP, EC, IP, PL, PN, SC)
SG6	Family C1250 (MI, DS, EC, CM, IP, PD, PL, PN, SC, SE, LU, CC) (0S/1S) Family C1251 (MI) (2S) Family E1400V2 (GP, DP, DS, EC, IP, PD, PL, PN, SC, SE, LU) (0S/1S) Family C1400 (GP, DS, EC, IP, PD, PL, PN, SC, SE, LU) (0S/1S)
SG7	Family A1100 Family C1100 (GP, DS, EC, PD, PN, SE) (0S/1S)

1.1.2 LinMot Drive Interface Extensions

Extension	Interface
GP	General Purpose (Depends on system generation and installed FW: LinRS and/or CANopen and/or DeviceNet)
CO	CANopen (LinMot Profile)
DN	DeviceNet (LinMot Profile)
DP	PROFIBUS (LinMot Profile)
PN	PROFINET (LinMot Profile)
PD	PROFIdrive (PROFIdrive Standard Telegram 5 & 9, SIEMENS Telegram 105)
PDS	PROFISAFE (Safety Standard Telegram 30), PROFINET (LinMot Profile) & PROFIdrive (PROFIdrive Standard Telegram 5 & 9, SIEMENS Telegram 105)
EC	EtherCAT (LinMot Profile)
SE	EtherCAT SoE (Servo Drive Profile over EtherCAT)
DS	EtherCAT CoE (DS402/CiA402)
PL	Powerlink (DS402/CiA402, LinMot Profile)
IP	EtherNet/IP (LinMot Profile)
CM	EtherNet/IP (CIP Sync, LinMot Profile)
SC	Sercos III (FSP_DRIVE, FSP_IO)
CC	CC-Link IE Field Basic (LinMot Profile)
LU	LinUDP (LinMot Ethernet UDP protocol)
RS	LinRS (LinMot serial protocol for RS232, RS422, RS485)
MI	Multi Interface (PN/PD > MIPD, EC/DS > MIDS, CM > MICM, PL > MIPL, SC > MISC, CC > MICC, LU > MILU)

E.g., C1250-DS-XC-xS -> DS = EtherCAT CoE

1.2 LinMot Drives with multi-interface (MI) Overview / C1250-xx replacement

The table shown on the next page gives an overview of how and if a C1250 drive with a specific interface (e.g., EC, PN, ...) could be replaced by a multi-interface C125x-MI drive. (blue = C1250-MI-XC-xS, yellow = C1251-MI-XC-2S)

The C1250-MI drives can be ordered with a specific interface preinstalled by a defined article number. Even if there is an interface preinstalled the user is free to install any supported interface during firmware installation.

A generic C1250-MI drive is available too where no interface is preinstalled. Any supported interface can be chosen during firmware installation.

The generic versions have the following ordering information:

Item	Article no.
C1250-MI-XC-1S-000	0150-5589
C1250-MI-XC-0S-000	0150-5591
C1250-MI-XC-1S-C00 (Calibrated Measuring Amplifier)	0150-5590
C1250-MI-XC-0S-C00 (Calibrated Measuring Amplifier)	0150-5592

**Note:**

The generic MI drive supports all interfaces of the C1250 series drives **except SE & IP**.
Supported: PD, PN, DS, EC, CM, PL, SC, LU, CC

**Note:**

For MI drives with preinstalled interface the item name is appended with -0xx / -Cxx where xx is the interface type.

E.g., C1250-MI-XC-1S-000 drive with preinstalled PD/PN interface => [C1250-MI-XC-1S-0PD](#)

**Note:**

In the PLC the device type of MI drives is shown with the interface abbreviation appended directly to MI.

E.g., C1250-MI-XC-1S-0PD (or ...-000) is shown in TIA Portal as [C1250-MIPD-XC-1S](#)

		Drive Family				
Interface		C1250-xx-XC-0S	C1250-xx-XC-1S	C1250-MI-XC-0S	C1250-MI-XC-1S	C1251-MI-XC-2S
MI (generic)	Description			C1250-MI-XC-0S-x00	C1250-MI-XC-1S-x00	C1251-MI-XC-2S
	Intf Art no.					
	HW Art no. -000			0150-5591 (-000)	0150-5589 (-000)	0150-2933
	HW Art no. -C00			0150-5592 (-C00)	0150-5590 (-C00)	0150-4185
LU	Description	C1250-LU-XC-0S	C1250-LU-XC-1S	C1250-MI-XC-0S-xLU	C1250-MI-XC-1S-xLU	C1251-MILU-XC-2S
	Intf Art no.			0150-30140	0150-30160	0150-30000
	HW Art no. -000	0150-2491	0150-2492	0150-5748 (-0LU)	0150-5734 (-0LU)	0150-2933
	HW Art no. -C00	0150-4129	0150-4135	0150-5741 (-CLU)	0150-5727 (-CLU)	0150-4185
EC	Description	C1250-EC-XC-0S	C1250-EC-XC-1S	C1250-MI-XC-0S-xDS	C1250-MI-XC-1S-xDS	C1251-MIDS-XC-2S
	Intf Art no.			0150-30142	0150-30162	0150-30002
	HW Art no. -000	0150-1884	0150-2345	0150-5751 (-0DS)	0150-5737 (-0DS)	0150-2933
	HW Art no. -C00	0150-4125	0150-4126	0150-5744 (-CDS)	0150-5730 (-CDS)	0150-4185
DS	Description	C1250-DS-XC-0S	C1250-DS-XC-1S	C1250-MI-XC-0S-xDS	C1250-MI-XC-1S-xDS	C1251-MIDS-XC-2S
	Intf Art no.			0150-30142	0150-30162	0150-30002
	HW Art no. -000	0150-2415	0150-2416	0150-5751 (-0DS)	0150-5737 (-0DS)	0150-2933
	HW Art no. -C00	0150-4123	0150-4124	0150-5744 (-CDS)	0150-5730 (-CDS)	0150-4185
SE	Description	C1250-SE-XC-0S	C1250-SE-XC-1S			
	Intf Art no.					
	HW Art no. -000	0150-1897	0150-2350			
	HW Art no. -C00	0150-4144	0150-4145			
PL	Description	C1250-PL-XC-0S	C1250-PL-XC-1S	C1250-MI-XC-0S-xPL	C1250-MI-XC-1S-xPL	C1251-MIPL-XC-2S
	Intf Art no.			0150-30144	0150-30164	0150-30004
	HW Art no. -000	0150-1885	0150-2347	0150-5749 (-0PL)	0150-5735 (-0PL)	0150-2933
	HW Art no. -C00	0150-4138	0150-4139	0150-5742 (-CPL)	0150-5728 (-CPL)	0150-4185
PD	Description	C1250-PD-XC-0S	C1250-PD-XC-1S	C1250-MI-XC-0S-xPD	C1250-MI-XC-1S-xPD	C1251-MIPD-XC-2S
	Intf Art no.			0150-30145	0150-30165	0150-30010
	HW Art no. -000	0150-2618	0150-2619	0150-5746 (-0PD)	0150-5732 (-0PD)	0150-2933
	HW Art no. -C00	0150-4136	0150-4137	0150-5739 (-CPD)	0150-5725 (-CPD)	0150-4185
PN	Description	C1250-PN-XC-0S	C1250-PN-XC-1S	C1250-MI-XC-0S-xPD	C1250-MI-XC-1S-xPD	C1251-MIPD-XC-2S
	Intf Art no.			0150-30145	0150-30165	0150-30010
	HW Art no. -000	0150-1888	0150-2348	0150-5746 (-0PD)	0150-5732 (-0PD)	0150-2933
	HW Art no. -C00	0150-4140	0150-4141	0150-5739 (-CPD)	0150-5725 (-CPD)	0150-4185
IP	Description	C1250-IP-XC-0S	C1250-IP-XC-1S			
	Intf Art no.					
	HW Art no. -000	0150-1886	0150-2346			
	HW Art no. -C00	0150-4127	0150-4128			
CM	Description	C1250-CM-XC-0S	C1250-CM-XC-1S	C1250-MI-XC-0S-xCM	C1250-MI-XC-1S-xCM	C1251-MICM-XC-2S
	Intf Art no.			0150-30147	0150-30167	0150-30008
	HW Art no. -000	0150-2900	0150-2901	0150-5747 (-0CM)	0150-5733 (-0CM)	0150-2933
	HW Art no. -C00	0150-4121	0150-4122	0150-5740 (-CCM)	0150-5726 (-CCM)	0150-4185
SC	Description	C1250-SC-XC-0S	C1250-SC-XC-1S	C1250-MI-XC-0S-xSC	C1250-MI-XC-1S-xSC	C1251-MISC-XC-2S
	Intf Art no.			0150-30149	0150-30169	0150-30009
	HW Art no. -000	0150-1887	0150-2349	0150-5750 (-OSC)	0150-5736 (-OSC)	0150-2933
	HW Art no. -C00	0150-4142	0150-4143	0150-5743 (-CSC)	0150-5729 (-CSC)	0150-4185
CC	Description	C1250-CC-XC-0S	C1250-CC-XC-1S	C1250-MI-XC-0S-xCC	C1250-MI-XC-1S-xCC	C1251-MICC-XC-2S
	Intf Art no.			0150-30150	0150-30170	0150-30010
	HW Art no. -000	0150-4023	0150-4024	0150-5752 (-OCC)	0150-5738 (-OCC)	0150-2933
	HW Art no. -C00	0150-4146	0150-4147	0150-5745 (-CCC)	0150-5731 (-CCC)	0150-4185
PDS	Description					C1251-MIPD-XC-2S
	Intf Art no.					0150-31005
	HW Art no. -000					0150-2933
	HW Art no. -C00					0150-4185

1.3 Available LinMot Libraries

LinMot provides several function block libraries for different PLCs and fieldbus systems to allow a fast and comfortable integration of LinMot drives into almost any control concept.

An overview of available LinMot libraries can be downloaded from the LinMot website:
<http://www.linmot.com/support/plc-library/>


Or search for the document reference ([0185-1105](#)) in the LinMot eCatalogue:
<http://shop.linmot.com>



Note: The available libraries can be downloaded from: http://download.linmot.com/plc_lib/libraries
For preliminary libraries that are not available for download please contact the LinMot support team.
support@linmot.com

1.4 Documentation / User Manuals / Application Notes

Beside the documentation included in the libraries available for download, reading the following user manuals is essential to understand the communication between the PLC and the LinMot drive. The manuals are included in the LinMot-Talk software (*Menu Manuals → All Documents or Relevant Documents* if logged in to a drive) or can be downloaded from the LinMot eCatalogue (search by document reference): <http://shop.linmot.com>



User Manuals: General	System Generation	Document Reference
LinMot-Talk	All	0185-1059
Motion Control Software	SG3 & SG4	0185-1092
Motion Control Software	SG5 - SG7	0185-1093
User Manuals: Configuration Over Fieldbus	System Generation	Document Reference
Drive Configuration Over Fieldbus	SG3 & SG4	0185-1072 (SG3), 0185-1073 (SG4)
Drive Configuration Over Fieldbus	SG5 - SG7	0185-1074
User Manuals: Interfaces	System Generation	Document Reference
EtherCAT (LinMot Profile)	SG5 - SG7	0185-1079
EtherCAT CoE (CiA402, CANopen over EtherCAT)	SG5 - SG7	0185-1103
EtherCAT SoE (Servo Drive Profile over EtherCAT)	SG5 - SG7	0185-1080
PROFIBUS DP	SG3, SG5 & SG6	0185-1089
PROFINET IO	SG5 - SG7	0185-1090 / 0185-1154 (-MI)
PROFINET PROFIdrive	SG6	0185-1132 / 0185-1154 (-MI)
Sercos III (FSP_DRIVE or FSP_IO)	SG5 & SG6	0185-1091
EtherNet/IP	SG5 & SG6	0185-1081
EtherNet/IP CIP Sync	SG6	0185-1165
Powerlink	SG5 & SG6	0185-1088
CC-Link IE Field Basic	SG6 (C1250-CC-..)	0185-1171
CANopen	SG3 & SG4	0185-1075
CANopen	SG5 - SG7	0185-1076
DeviceNet	SG3 & SG4	0185-1078
LinRS (LinMot serial protocol)	SG3 - SG7	0185-1082
LinUDP (LinMot Ethernet UDP protocol) up to FW6.3	SG5 & SG6	0185-1083
LinUDP V2 (LinMot Ethernet UDP protocol) from FW6.3	SG5 & SG6	0185-1108
Application Notes		Document Reference
HT Config over Realtime		0185-0142-E / 0185-0142-D
HT Oscilloscope		0185-0132-E / 0185-0132-D
HT Position Loop Tuning		0185-1156-E / 0185-1156-D
HT Closed Loop Force/Torque Tuning		0185-0144-E / 0185-0144-D

1.5 UPID (Unique Parameter ID)

The value of any parameter of a LinMot drive is stored as an integer value (raw data) in the memory space of the drive. The parameter is identified through its Unique Parameter ID (UPID), which is a 16 Bit integer number.



Note: Detailed information about LinMot drive parameters can be found in the user manual *Drive Configuration Over Fieldbus*. See chapter 1.4 Documentation / User Manuals



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus* ([0185-1074](#)) user manual
> see chapter Documentation / User Manuals

1.6 Recent Version of LinMot-Talk and Drive Firmware

The most recent LinMot-Talk version including all drive firmware, device description files and documentation can be downloaded from

either (standard):

<https://linmot.com/download/linmot-talk-drive-configuration/>

or (alternative link):

<http://download.linmot.com/LinMot-Talk/Release/>



Hint:

LinMot C1250, C1450 & E1450 series drives support configuration over several interfaces (PROFINET, EtherNet/IP, EtherCAT, Sercos III & LinUDP).

This allows to login with LinMot-Talk into the drive and change parameters, monitor the drive, import/export the drive configuration, etc.

The application note “Config over Realtime” covering this topic is available from:

<https://shop.linmot.com/E/product/0185-0142-E>

<https://shop.linmot.com/E/product/0185-0142-D>

1.7 YouTube Video Tutorials

LinMot provides videos for a wide range of topics covering login, firmware installation, motor wizard, integration, and maintenance on the website.

[YouTube https://linmot.com/support/linmot-tutorials/drive-configuration/](https://linmot.com/support/linmot-tutorials/drive-configuration/)

1.8 LinMot Product Information

Datasheets, Installation Guides, Application Notes, drivers, EPlan, CAD Files and so on for LinMot products can be found in the eCatalogue: <https://shop.linmot.com/>



Note: To find all relevant information about a product just enter the article number in the search box on <https://shop.linmot.com/>

Search

0150-2473

2 Overview

2.1 LinMot Profile (Commissioning using the LinMot Libraries)

The following table shows working combinations of different PLC types and LinMot drives. For these combinations function block libraries and/or example projects are available. Click the link in the *See chapter* column to directly open the according chapter (if available).

PLC Type	Interface	LinMot I/F Extension	Type	Language	See chapter
Beckhoff TwinCAT 2&3	EtherCAT CANopen PROFIBUS	-EC & -MI -GP -DP	Library	ST (Structured Text)	3
Siemens Step 7 V5.5 (S7-300 and higher)	PROFINET PROFIBUS	-PN & -MI -DP	Library	AWL	4
Siemens TIA (S7-300, S7-1500)	PROFINET PROFIBUS	-PN & -MI -DP	Library	AWL	4
Siemens TIA (S7-1200, S7-1500)	PROFINET PROFIBUS	-PN & -MI -DP	Library	SCL	4
Rockwell Automation	EtherNet/IP	-IP -CM & -MI	Addon Instructions (AOI)	LD (Ladder)	5 9
B&R	Powerlink CANopen	-PL & -MI -GP	Library	ST	6
CODESYS (based)	Various	Various	Library	ST	7
Mitsubishi	CC-Link IE Field Basic	-CC & -MI	Library	ST	8

2.2 Drive Profiles (Direct Integration as Motion Axis using standardized Drive Profiles)

The following table shows the drive profiles supported by LinMot servo drives. Based on your PLC type the correct LinMot drive can be selected. Click the link in the *See chapter* column to directly open the according chapter (if available).

PLC Type	Interface	LinMot I/F Extension	Integration	Drive Profile	See chapter
Rockwell Automation	EtherNet/IP (CIP Sync)	-CM & -MI	As motion axis	LinMot PVA Streaming	9
Siemens (Simotion, S7-1500, ...)	PROFIdrive	-PD & -MI	As axis (TO)	Standard Telegram 5 SIEMENS Telegram 105	10
Beckhoff TwinCAT 2&3	EtherCAT CoE	-DS & -MI	As axis (NC)	CoE (DS402/CiA402)	11
Beckhoff TwinCAT 2&3	EtherCAT SoE	-SE	As axis (NC)	SoE	12
Schneider Electric (PacDrive 3)	Sercos III	-SC & -MI	As axis	FSP Drive	13
CODESYS Motion	EtherCAT CoE	-DS & -MI	As axis	CoE (DS402/CiA402)	14
B&R	Powerlink CiA402	-PL & -MI	As axis	CoE (DS402/CiA402)	15
B&R	Powerlink	-PL & -MI	As SDC axis	LinMot PV Streaming	16
Omron (NJ501-1500)	EtherCAT CoE	-DS & -MI	As axis	CoE (DS402/CiA402)	17
TRIO (MC4N ECAT, P904)	EtherCAT	-DS & -MI	As axis	CoE (DS402/CiA402)	18
Bosch Rexroth (IndraControl / IndraMotion)	Sercos III	-SC & -MI	As axis	FSP Drive	Footnote ¹

¹ See Bosch Rexroth online help for GAT compact. The LinMot Sercos (-SC) drives are integrated as sercosDrive.

3 LinMot Profile: Beckhoff TwinCAT 2&3

3.1 Overview

This chapter shows how a LinMot drive with *LinMot EtherCAT* interface (e.g., C1250-EC-XC-0S) can be integrated and setup in a Beckhoff TwinCAT environment to be used with the library provided by LinMot. For this example, TwinCAT 2 is used. The steps are generally similar for TwinCAT 3.

Download:

The library for TwinCAT 2&3 can be downloaded from:

http://download.linmot.com/plc_lib/libraries/Beckhoff/ (named *Beckhoff_LinMot_Library_...*)

**Note:**

More information can be found in the library documentation (part of the above-mentioned download) and in the user manual EtherCAT (LinMot Profile) (see chapter 1.4 Documentation / User Manuals)




Image Source: <http://www.beckhoff.com/>

EtherCAT is the open real-time Ethernet network originally developed by Beckhoff. The LinMot acts as Slave in this network and is implemented with the standard ASIC ET1100 from Beckhoff.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>

3.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

3.2.1 Motor Configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



See Appendix I: Basic Position Control Loop Tuning

3.2.2 XML Files

Install the XML file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherCAT: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML\
- EtherCAT: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML\ (-MI drives)





XML file names:

NTIL_LM_Servos_Vx_xrx.xml	LinMot EC drives SG6-7
NTIL_LM_SG5_Servos_Vx_xrx.xml	LinMot EC drives SG5
NTIL_CiA402_Servos_MI_Vx_xrx.xml	LinMot MI drives SG6

3.2.3 EtherCAT Connection

The drive is connected to the EtherCAT network using the X17 & X18 connectors.

The below pictures show the ports of an E1250-EC-UC drive. On all other LinMot drives supporting EtherCAT the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



3.3 PLC Setup EtherCAT (E1450-EC-QN, E1250-EC-UC, C1x00-EC-XC-xx)

3.3.1 Insert LinMot Drive as Slave

The required XML files can be found in the following folder (default):

C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML
 C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_NX\XML (-MI Drives)

These files must be copied to the IO folder of TwinCAT:


- C:\TwinCAT\Io\EtherCAT\ (for TwinCAT 2)
- C:\TwinCAT\3.1\Config\Io\EtherCAT\ (for TwinCAT 3)



Note: You may have to restart the developing environment to have the new XML file to be recognized.



Insert a new device by right-click on the EtherCAT-Master and *Append Box* (figure below) or restart the PLC to “Config Mode” and scan for the devices attached to the EtherCAT bus.



ATTENTION:

For **-MI drives** (they show up as CiA402 drives, e.g., *C1250-MIDS-1S V1.0r0*) make sure that **input PDOs 0x1B00 and 0x1B08** as well as **output PDOs 0x1700 and 0x1708** are selected.

3.3.2 Config Module

The *Config Module* provides access to parameters, curve profiles, command table and so on of a LinMot drive.



If the config function blocks of the library are used the „Config Module“ inputs and outputs (**0x1B08 & 0x1708**) must be enabled and linked as well.

The screenshot shows two side-by-side configurations of the 'Box 1 (C1250-EC-XC-05)' device under 'Device 3 (EtherCAT)'. Both configurations are set to the 'Process Data' tab.

Configuration 1 (Top):

- Sync Manager:** PDO 2 is selected as an Output (Size: 32).
- PDO Assignment (0x1C12):** PDO 0x1708 is checked.

SM	Size	Type	Flags
0	128	MbxOut	
1	128	MbxIn	
2	32	Outputs	
3	26	Inputs	

Configuration 2 (Bottom):

- Sync Manager:** PDO 3 is selected as an Input (Size: 26).
- PDO Assignment (0x1C13):** PDO 0x1B08 is checked.

SM	Size	Type	Flags
0	128	MbxOut	
1	128	MbxIn	
2	32	Outputs	
3	26	Inputs	

3.3.3 Links to PLC Control

To be able to link the input and output data of the LinMot drive you must create an instance of the *tstLM_Axis* data type (part of the library) in the global variables of your PLC project.




The inputs and outputs of the modules must be linked as shown below:

Name	Linked to
StateVar	StateVar . .Axis_A_Axis.DrvToPlc . Inputs . Standard . Li...
StatusWord	StatusWord . .Axis_A_Axis.DrvToPlc . Inputs . Standard ...
WarnWord	WarnWord . .Axis_A_Axis.DrvToPlc . Inputs . Standard
DemandPosition	ComDemandPosition . .Axis_A_Axis.DrvToPlc . Inputs
ActualPosition	ComActualPosition . .Axis_A_Axis.DrvToPlc . Inputs . S...
DemandCurrent	ComActualCurrent32 . .Axis_A_Axis.DrvToPlc . Inputs
Config Status Word	CfgStatusWord . .Axis_A_Axis.DrvToPlc . Inputs . Stand...
Config Index In	CfgIndexIn . .Axis_A_Axis.DrvToPlc . Inputs . Standard
Config Value In	CfgValueIn . .Axis_A_Axis.DrvToPlc . Inputs . Standard
Control Word	ControlWord . .Axis_A_Axis.PlcToDrv . Outputs . Standar...
Motion Command Header	MCHeader . .Axis_A_Axis.PlcToDrv . Outputs . Standar...
Motion Command Par 1	MCParaDWord_00_03 . .Axis_A_Axis.PlcToDrv . Output...
Motion Command Par 2	MCParaDWord_04_07 . .Axis_A_Axis.PlcToDrv . Output...
Motion Command Par 3	MCParaDWord_08_11 . .Axis_A_Axis.PlcToDrv . Output...
Motion Command Par 4	MCParaDWord_12_15 . .Axis_A_Axis.PlcToDrv . Output...
Motion Command Par 5	MCParaDWord_16_19 . .Axis_A_Axis.PlcToDrv . Output...
Config Control Word	CfgControlword . .Axis_A_Axis.PlcToDrv . Outputs . St...
Config Index Out	CfgIndexOut . .Axis_A_Axis.PlcToDrv . Outputs . Stand...
Config Value Out	CfgValueOut . .Axis_A_Axis.PlcToDrv . Outputs . Stand...

Hint:


It is possible to change multiple links at once. Just select the names you want to link > right-click > Change Multi Link. Don't forget to check "All Types" and "Continuous".



3.3.4 Check EoE settings

On supported drives (C1250-..., C1450-... & E1450-...) please check the EoE (Ethernet over EtherCAT) settings.

LinMot drives do NOT support the DHCP mode yet. A fix IP must be assigned (select *IP Address*) or the EoE feature must be completely disabled (disable Virtual Ethernet Port).



Note:


EoE can be used to login into the drive with LinMot-Talk directly over EtherCAT. E.g., to change drive settings or for monitoring and tracing.

3.4 Add Additional Parameters or Variables to the Process Data

To add additional parameters or variables for read and write access to the process data please see chapter [11.10 Add Additional Parameters or Variables to the Process Data](#).

3.5 Check with LinMot-Talk if the Fieldbus is running

LinMot-Talk shows the status of the fieldbus. Open the variables EtherCAT and check if the bus is running (EtherCAT State = Operational State).



3.6 Next Steps

Now you can start implementing your application using the function blocks and documentation from the download link in chapter [3.1 Overview](#).

4 LinMot Profile: Siemens TIA

4.1 Overview

This chapter shows how a LinMot drive with either *PROFIBUS* or *PROFINET* interface (LinMot Profile) can be connected to a Siemens PLC using TIA Portal (for Step 7 the general steps are similar).

Download:

The libraries for TIA / Step 7 can be downloaded from:

http://download.linmot.com/plc_lib/libraries/Siemens/ (named *Siemens_TIA...* or *Siemens_Step7...*)



Note:

More information can be found in the library documentation (part of the above-mentioned download) and in the user manuals PROFINET & PROFIBUS (LinMot Profile) (see chapter 1.4 Documentation / User Manuals)




Image Source: <http://automation.siemens.com/>

PROFINET is an Industrial Ethernet Standard. The LinMot PROFINET drives act as PROFINET-IO slaves in this network.

PROFIBUS is a fieldbus standardized in IEC 61158. The LinMot PROFIBUS drives are PROFIBUS-DP slaves.

For further information on PROFINET / PROFIBUS please visit:

<http://www.PROFIBUS.com>

4.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

4.2.1 Motor configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



See Appendix I: Basic Position Control Loop Tuning

4.2.2 GSD / GSDML files


Install the GSD/GSDML file(s) that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- PROFIBUS: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Profibus\GSD
- PROFINET: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\ProfiNet\GSDML
- PROFINET: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\ProfiNet_Nx\GSDML_PD
(For -MI drives)

4.2.3 PROFIBUS Connection

The drive is connected to the PROFIBUS network using the X9 connector of the LinMot drive.

X9 PROFIBUS DP																					
	<table border="1"> <tr> <td>1</td><td>Not connected</td></tr> <tr> <td>2</td><td>Not connected</td></tr> <tr> <td>3</td><td>RxD/TxD-P</td></tr> <tr> <td>4</td><td>CNTR-P</td></tr> <tr> <td>5</td><td>GND (isolated)</td></tr> <tr> <td>6</td><td>+5V (isolated)</td></tr> <tr> <td>7</td><td>Not connected</td></tr> <tr> <td>8</td><td>RxD/TxD-N</td></tr> <tr> <td>9</td><td>Not connected</td></tr> <tr> <td>case</td><td>Shield</td></tr> </table>	1	Not connected	2	Not connected	3	RxD/TxD-P	4	CNTR-P	5	GND (isolated)	6	+5V (isolated)	7	Not connected	8	RxD/TxD-N	9	Not connected	case	Shield
1	Not connected																				
2	Not connected																				
3	RxD/TxD-P																				
4	CNTR-P																				
5	GND (isolated)																				
6	+5V (isolated)																				
7	Not connected																				
8	RxD/TxD-N																				
9	Not connected																				
case	Shield																				
DSUB-9 (f)	Max. Baud rate: 12Mbaud																				

The only setting that must be done on the drive according to the PROFIBUS interface is setting the node address. By default, it is set with the address selectors S1 & S2 on the front of the drive. Alternatively (not recommended) it can be set with the parameter “Node Address Parameter Value” (UPID 2076h). This requires the parameter “Node Address Selection” (UPID 206Ch) to be set to “On”.



Set the node (Profibus) address using the address selectors S1 & S2

S1 - S2		Address Selectors	
E1100 E1200 V1	E1200 V2 E1400 C1x00	S1 (5 .. 8)	Bus ID High (0 ... F). Bit 5 is LSB, bit 8 MSB.
		S2 (1 .. 4)	Bus ID High (0 ... F). Bit 1 is LSB, bit 4 MSB.


The rotary switches are hexadecimal.



Attention: Do not change any other PROFIBUS interface parameters on the drive!



Attention: To activate the PROFIBUS Interface on E1130-DP-xx drives, the Dip-Switch S3.4 “Interface” at the bottom of the drive has to be set to “ON” (factory default)





Attention:

According to the PROFIBUS standard the **maximal node address is 127** (addresses 126 and 127 are reserved for special purpose and should normally not be used).

4.2.4 PROFINET Connection

The drive is connected to the PROFINET network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-PN-UC drive. On all other LinMot drives supporting PROFINET the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.

**Attention:**

The PROFINET parameters in the drive are left to default values!

The name and IP address are set using the TIA Portal, see chapter 4.4.1

4.3 PLC Setup PROFIBUS (E1430-DP-QN, E1230-DP-UC, E1130-DP-xx)

The following procedure can be used for all Siemens PLCs compatible with TIA Portal.




First, install the GSD file for the drive.
(TIA Portal → Options → Install general station description file (GSD))


The required GSD file can be found by default in the following folder:

C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\PROFIBUS\GSD\

Drag and drop the desired drive from the catalogue to the network view and connect it to the Profibus network (1 & 2)



Afterwards insert the required modules into the available slots as shown in the figure below.



Note: Set the name and the PROFIBUS address of the device according to the requirements of your application

4.4 PLC Setup PROFINET (E1450-PN-QN, E1250-PN-UC, C1250-PN-UC, C1150PN-UC)

The following procedure can be used for both CPU S7-1200 and CPU S7-1500.




First, install the GSDML file for the drive.
(TIA Portal → Options → Manage general station description file (GSD))

The required GSDML file can be found by default in the following folder:


C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\ProfiNet\GSDML\
C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\ProfiNet_Nx\GSDML_PD\ (for -MI drives)

Drag and drop the desired drive from the catalogue to the network view, connect the drive with the PLC (draw line from 1 to 2) and assign the drive to the PLC (3).




Afterwards in the Device View the module „Default IO mapping with Config“ is dropped into the available slot as shown the figure below.

By default, when adding a new **LinMot -PN drive**, this module is already present in slot 1.



When adding a **C125x-MI drive** (e.g., C1250xMIPD 1S V3.0) insert the **DO SERVO Module** first and then add the **Submodule LinMot telegram 516**:



Tip:


It is possible to add up to 4 parameter and 4 monitoring channels to write or read specific parameters or variables in the process data.

Please check chapter **10.6 Add Additional Parameters / Variables to the Real-Time Channel** for details.


4.4.1 Assigning the Device Name and IP Address

The following three steps show how to assign the PROFINET device name to the LinMot drive using TIA Portal. The IP address is assigned automatically when PROFINET starts.


1. Set the IP address and the device name in the device properties:



2. Choose the device you want to assign the name to (right-click on the device):




3. Search for the LinMot drive you want to name. The safest way to identify the drive is by either activating the "Flash LED" function in TIA Portal or to verify the MAC address (can be found on the housing of the drive).



4.5 Check with LinMot-Talk if the Fieldbus is running

LinMot-Talk shows the status of the fieldbus. Open the variables PROFIBUS / PROFINET and check if the Node Address / IP Address is correct.



If the “Receive Data Counter” is counting and there is a valid “Receive IO Cycle Time” is shown the bus is properly running.

4.6 Next Steps

Now you can start implementing your application using the function blocks and documentation from the download link in chapter **4.1 Overview**.

5 LinMot Profile: Rockwell Automation Studio 5000 (Outdated)

5.1 Overview



Update July 2022: LinMot recommends -CM or -MI drives instead of -IP drives for new applications

The most recent instruction set for LinMot CM and MI drives (CIPSync Motion) now also supports LinMot -IP drives. Please find the instruction set with included example projects and documentation here:

http://download.linmot.com/plc_lib/examples/Rockwell_CM/

This chapter shows how a LinMot drive with *LinMot EtherNet/IP* interface (e.g., C1250-IP-XC-0S) can be integrated and setup in a Rockwell Automation environment to be used with the library provided by LinMot.

Download:

The Add-On Instructions for Rockwell Automation controllers can be downloaded from:

http://download.linmot.com/plc_lib/libraries/Rockwell/ (named *Rockwell_LM_AOI_Set_...*)



Note:

More information can be found in the library documentation (part of the above-mentioned download) and in the user manual EtherNet/IP (see chapter 1.4 Documentation / User Manuals)




Image Source: <http://www.rockwellautomation.com/>

EtherNet/IP is an industrial Ethernet network that implements the Common Industrial Protocol (CIP).

For further information on EtherNet/IP please visit:

<http://www.odva.org>



YouTube video series (LinMot Integration – Rockwell Automation EtherNet/IP):
<https://youtube.com/playlist?list=PLMSLCScLnf94pEISNCovUf2-RpGJ8L6R>

5.2 Minimum Requirements



Important:

Use only Allen-Bradley controller firmware revision 18.0 or higher!

For EDS support Allen-Bradley controller firmware revision 20.0 or higher is required!

The AOP for C1250-IP-XC-xS and E1250-IP-UC drives are included in Studio 5000 from V31!

For Studio 5000 versions older than V31 the AOP installation package can be downloaded from:
http://download.linmot.com/plc_lib/libraries/Rockwell/ (*LM_DRIVE_Rel15_RELEASE.zip*)

Attention:

When you have installed the AOP manually, e.g., from the link above, it is highly recommended to uninstall them before installing Studio V31. As they are part of Studio V31 errors may occur during installation.

5.3 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

5.3.1 Motor Configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



See Appendix I: Basic Position Control Loop Tuning

5.3.2 EDS Files (Requires Studio 5000 V20 or higher)


Install the EDS file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherNet/IP: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherNetIP\EDS

5.3.3 EtherNet/IP Connection

The drive is connected to the EtherNet/IP network using the X17 & X18 connectors.



5.3.4 IP Address

The default IP address is 192.168.001.xxx, where the last byte xxx is defined via the two address selectors S1 & S2. S1 sets the high and S2 the low digit. E.g., S1 = 5, S2 = A -> 5A (hex) = 90 (dec) -> IP = 192.168.1.90



Set IP address (last byte, xxx from above) by S1 & S2

S1 - S2		Address Selectors	
E1100 E1200 V1	E1200 V2 E1400 C1x00	S1 (5 .. 8)	Bus ID High (0 ... F). Bit 5 is LSB, bit 8 MSB.
		S2 (1 .. 4)	Bus ID High (0 ... F). Bit 1 is LSB, bit 4 MSB.



Attention:


The switch value **S1 = S2 = 0 (factory default setting)** is a special configuration which acquires the IP address via DHCP (e.g., for use with the BOOTP-DHCP Tool from Rockwell Automation)!

5.4 PLC Setup EtherNet/IP

5.4.1 RSLinx Classic

After setting the IP address the new LinMot device should appear in RSLinx Classic as "Unrecognized Device" (e.g., IP 192.168.1.90 see below).

If the EDS file is installed, the LinMot drive will appear in RSLinx with its Device Type (e.g., IP 192.168.1.89).

**Important:**

If no AOP or EDS file is used the LinMot must be setup as Generic Ethernet Module.
See chapter 5.4.4

5.4.2 Add a LinMot drive using AOP (E1250-IP-xx, C1250-IP-xx)

**Important:**

The AOP for C1250-IP-XC-xS and E1250-IP-UC drives are included in Studio 5000 from V31!

For Studio 5000 version <V31 the AOP installation package for manual installation can be downloaded from:

http://download.linmot.com/plc_lib/libraries/Rockwell/ (LM_DRIVE_Rel15_RELEASE.zip)


**Attention:**

When you have installed the AOP manually it is highly recommended to uninstall them before installing Studio V31.

How to uninstall AOP:

- 1) You need to have the installation files for the version of the AOP you are currently running unzipped and available.
- 2) Go to a DOS (command) window. Then navigate to the folder where you have the installation files for the version of the AOP you wish to uninstall.
- 3) Execute this command: MPSETUP/CU
- 4) Follow the prompts and make sure that you check the UNINSTALL checkbox.
- 5) Click "Next". Expand the tree in the left pane to see choices for which AOP(s) you wish to uninstall. Select which AOPs to uninstall.
- 6) Follow the prompt to finish the uninstall

1. Add a new module by right-clicking on Ethernet in the I/O configuration:



2. Select module type (LMDrive):

Select Module Type

Catalog Module Discovery Favorites


Module Type Category Filters Module Type Vendor Filters

Analog Allen-Bradley
 CIP Motion Converter Advanced Energy Industries, Inc.
 Communication Cognex Corporation
 Communications Adapter Endress+Hauser


Catalog Number	Description	Vendor	Category
LMDrive	C1250IPXC0S Servo Drive	NTI Limited	Communication
LMDrive	C1250IPXC1S Servo Drive	NTI Limited	Communication
LMDrive	E1250-IP-UC Servo Drive	NTI Limited	Communication
LMDrive	E1450-IP-QN	NTI Limited	Generic Device(keyable)
LMDrive	E1450IPQN0S	NTI Limited	Generic Device(keyable)
LMDrive	E1450IPQN1S	NTI Limited	Generic Device(keyable)
IMM-0000000000000000	0000000000000000	NTI Limited	Generic Device(keyable)

7 of 536 Module Types Found


Close on Create



3. Set name and IP address:




4. Setup connection (Set desired RPI and check that “Use Unicast Connection ... “ is selected)



Now you can download your project to the controller and check if the connection is running, as described in chapter 5.5.


5.4.3 Add a LinMot drive using the EDS file (recommended for Studio <V31)

1. The EDS files can be installed using the EDS Hardware Installation Tool:




Follow the wizard and install the EDS files from the location mentioned in chapter 5.3.2.


2. Add a new module by right-click on Ethernet in the I/O configuration:



3. Select Module Type:





4. Set Name and IP Address



5.4.4 Add a LinMot drive as Generic Ethernet Module (ETHERNET-MODULE)

1. Add a new *ETHERNET-MODULE* by right-click on Ethernet in the I/O Configuration:





2. Setup of the Module Properties:

- Name
- Comm Format
- IP Address
- Input and output assembly size

**Attention:**


Be careful when defining these parameters, because only a correct setting will run in the EtherNet/IP network. Only the name and the RPI (Requested Packet Interval) can be defined freely.

The IP must be set according to the IP settings of the LinMot drive or vice-versa.



5.5 Check with LinMot-Talk if the Fieldbus is running

LinMot-Talk shows the status of the fieldbus. Open the variables *Ethernet/IP* for actual IP address, Net Mask or *Ethernet/IP:O->T, T->O config* to check the connection.



5.6 Next Steps

Now you can start implementing your application using the function blocks and documentation from the download link in chapter 5.1 Overview.

6 LinMot Profile: B&R Automation Studio

6.1 Overview

LinMot drives with *Powerlink* interface (e.g., C1250-PL-XC-1S) can be integrated in a B&R environment as point-to-point axis using the LinMot function block library.

Download:

Demo projects can be downloaded from:

http://download.linmot.com/plc_lib/libraries/BR/ (named *BR_AS4x_LinMot_Powerlink_noUpgrades...*)

The library itself can be download from:

http://download.linmot.com/plc_lib/libraries/BR/ (named *LM_BR_Library_inclSources_...*)

> Choose the library *...inclSources...* to compile it on your system for your specific AS and AR versions.



For a detailed description of the library function blocks please check the Beckhoff library documentation which is part of the download in **chapter 3.1 (page 21)**.

Both the Beckhoff and B&R library contain the same function blocks and are therefore identical in documentation.



The library itself contains a HTML Help that can be opened by selecting the library in Automation Studio and press F1 key.





Image Source: <http://www.br-automation.com/>

For further information on Ethernet POWERLINK please visit: <http://www.ethernet-powerlink.org>

6.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

6.2.1 Motor configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



See Appendix I: Basic Position Control Loop Tuning

6.2.2 XDD File

Install the XDD file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software.

It is located by default:



- Powerlink: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Powerlink\XDD
- Powerlink: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Powerlink_Nx\XDD (-MI drives)

There are separate XDD files available for either AS3 or AS4.

6.2.3 Powerlink Connection


The drive is connected to the Powerlink network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-PL-UC drive. On all other LinMot drives supporting Powerlink the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



6.2.4 Node ID

The Node ID of the LinMot drive is set using the hardware address selectors.

S1 - S2		Address Selectors	
E1100 E1200 V1		E1200 V2 E1400 C1x00	 S1 (5 .. 8) Bus ID High (0 ... F). Bit 5 is LSB, bit 8 MSB. S2 (1 .. 4) Bus ID High (0 ... F). Bit 1 is LSB, bit 4 MSB.


E.g.: Node ID **18 dec** = **12 hex** = **0001 0010 bin**

=> S1 = **1 hex** = **0001 bin** (Dip Switch 5 = ON), S2 = **2 hex** = **0010 bin** (Dip Switch 2 = ON)

6.3 Hardware Configuration

6.3.1 Add the LinMot drive to the Powerlink network

Install the XDD file(s) using *Tools > Import Fieldbus Device...* in Automation Studio.




The required XDD-file can be found in the following folder (default):

C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\POWERLINK\XDD

In the Hardware Catalog search for the LinMot drive (e.g., C1250...) and drag&drop it onto the Powerlink interface (PLK).

Alternatively select the Product Group *3rd Party Devices* > all installed LinMot drives are shown.



Set the Node ID according to your requirements.

6.3.2 Configuration

In the configuration of the LinMot slave module (right-click on device > Configuration) the following channels must be selected:

Set the **Cyclic transmission** of all channels marked with a red exclamation mark to **Read** or to **Write** respectively.

Name	Value
[-] C1250-PL_lin	
[+] General	
[+] POWERLINK parameters	
[+] Channels	
[+] MCSW_Variables_I4F00 RECORD[0x19]	
[+] MCSW_StateVar_I4F00_S01	
[!] Cyclic transmission	Read
[!] Datatype	UINT
[+] MCSW_StatusWord_I4F00_S02	
[+] MCSW_WamWord_I4F00_S03	
[+] MCSW_ActualPosition32Bit_I4F00_S04	
[+] MCSW_DemandPosition32Bit_I4F00_S05	
[+] MCSW_DemandCurrent_I4F00_S06	
[+] MCSW_ControlWord_I4F00_S07	
[+] MCSW_MotionCommandHeader_I4F00_S08	
[+] MCSW_MotionCommandByte_00_03_I4F00_S09	
[+] MCSW_MotionCommandByte_04_07_I4F00_S0A	
[+] MCSW_MotionCommandByte_08_11_I4F00_S0B	
[+] MCSW_MotionCommandByte_12_15_I4F00_S0C	
[+] MCSW_MotionCommandByte_16_19_I4F00_S0D	
[+] MCSW_MotionCommandByte_20_23_I4F00_S0E	
[+] MCSW_MotionCommandByte_24_27_I4F00_S0F	
[+] MCSW_MotionCommandByte_00_01_I4F00_S10	
[+] MCSW_MotionCommandByte_02_03_I4F00_S11	
[+] MCSW_MotionCommandByte_04_05_I4F00_S12	
[+] MCSW_MotionCommandByte_06_07_I4F00_S13	
[+] MCSW_MotionCommandByte_08_09_I4F00_S14	
[+] MCSW_MotionCommandByte_10_11_I4F00_S15	
[+] MCSW_MotionCommandByte_12_13_I4F00_S16	
[+] MCSW_MotionCommandByte_14_15_I4F00_S17	
[+] MCSW_MotionCommandByte_16_17_I4F00_S18	
[+] MCSW_MotionCommandByte_18_19_I4F00_S19	
[+] UPID_Variables_Values_I4F02 RECORD[0x04]	
[+] Configuration_Module_I4F03 RECORD[0x06]	
[+] TX_Cfg_Module_Control_I4F03_S01	
[+] TX_Cfg_Module_Index_Out_I4F03_S02	
[+] TX_Cfg_Module_Value_Out_I4F03_S03	
[+] RX_Cfg_Module_Status_I4F03_S04	
[+] RX_Cfg_Module_Index_In_I4F03_S05	
[+] RX_Cfg_Module_Value_In_I4F03_S06	
[+] Device specific parameters	

6.3.3 I/O Mapping

The inputs and outputs (right-click open I/O mapping) of the modules are mapped to the axis structure (datatype `stsLM_Axis`).

In the following example a variable `LM_Axis_1_Axis` of datatype `tstLM_Axis` is defined in the *Main* program.

Channel Name	Process Variable
ModuleOk	::Main:LM_Axis_1_Axis.DrvToPlc.StateVar
MCSW_StateVar_I4F00_S01	::Main:LM_Axis_1_Axis.DrvToPlc.StatusWord
MCSW_StatusWord_I4F00_S02	::Main:LM_Axis_1_Axis.DrvToPlc.WamWord
MCSW_WamWord_I4F00_S03	::Main:LM_Axis_1_Axis.DrvToPlc.ComActualPosition
MCSW_ActualPosition32Bit_I4F00_S04	::Main:LM_Axis_1_Axis.DrvToPlc.ComDemandPosition
MCSW_DemandPosition32Bit_I4F00_S05	::Main:LM_Axis_1_Axis.DrvToPlc.ComActualCurrent32
MCSW_DemandCurrent_I4F00_S06	::Main:LM_Axis_1_Axis.PlcToDrv.ControlWord
MCSW_ControlWord_I4F00_S07	::Main:LM_Axis_1_Axis.PlcToDrv.MCHeader
MCSW_MotionCommandHeader_I4F00_S08	::Main:LM_Axis_1_Axis.PlcToDrv.MCParaDWord_00_03
MCSW_MotionCommandByte_00_03_I4F00_S09	::Main:LM_Axis_1_Axis.PlcToDrv.MCParaDWord_04_07
MCSW_MotionCommandByte_04_07_I4F00_S0A	::Main:LM_Axis_1_Axis.PlcToDrv.MCParaDWord_08_11
MCSW_MotionCommandByte_08_11_I4F00_S0B	::Main:LM_Axis_1_Axis.PlcToDrv.MCParaDWord_12_15
MCSW_MotionCommandByte_12_15_I4F00_S0C	::Main:LM_Axis_1_Axis.PlcToDrv.MCParaDWord_16_19
MCSW_MotionCommandByte_16_19_I4F00_S0D	::Main:LM_Axis_1_Axis.PlcToDrv.CfgControlWord
TX_Cfg_Module_Control_I4F03_S01	::Main:LM_Axis_1_Axis.PlcToDrv.CfgIndexOut
TX_Cfg_Module_Index_Out_I4F03_S02	::Main:LM_Axis_1_Axis.PlcToDrv.CfgValueOut
TX_Cfg_Module_Value_Out_I4F03_S03	::Main:LM_Axis_1_Axis.DrvToPlc.CfgStatusWord
RX_Cfg_Module_Status_I4F03_S04	::Main:LM_Axis_1_Axis.DrvToPlc.CfgIndexIn
RX_Cfg_Module_Index_In_I4F03_S05	::Main:LM_Axis_1_Axis.DrvToPlc.CfgValueIn
RX_Cfg_Module_Value_In_I4F03_S06	::Main:LM_Axis_1_Axis.DrvToPlc.CfgValueIn

6.4 Parameter Access

For detailed information about accessing drive parameters please check chapter **16.12 Parameter Access (page 233)**.

6.5 Add Additional Parameters or Variables to the Process Data

To add additional parameters or variables for read and write access to the process data please see chapter **16.13 Add Additional Parameters or Variables to the Process Data (page 236)**.

6.6 Next Steps

Now you can start implementing your application using the function blocks and documentation from the download link(s) in chapter **6.1 Overview (page 53)**.

7 LinMot Profile: CODESYS

7.1 Overview

A LinMot drive with *EtherCAT (-EC)* interface (e.g., C1250-EC-XC-1S) can be integrated and setup in a CODESYS environment as I/O device using the LinMot function block library

Download:

A package including the library and example projects is available from:

http://download.linmot.com/plc_lib/libraries/CODESYS/3x/ (named *CoDeSys_3.x_LinMot_Library_...*)



For a detailed description of the library function blocks please check the Beckhoff library documentation which can be downloaded in **chapter 3.1 (page 21)**

Both the Beckhoff and CODESYS library contain the same function blocks and are therefore identical in documentation.



Image Source: <http://www.raspberrypi.org/>

EtherCAT is the real-time Ethernet network originally developed by Beckhoff. The LinMot acts as Slave in this network and is implemented with the standard ASIC ET1100 from Beckhoff.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>

8 LinMot Profile: Mitsubishi GX Works

8.1 Overview

This chapter shows how a LinMot drive with CC-Link IE Field Basic Interface (LinMot Profile) can be connected to a Mitsubishi PLC using GX Works3.

Download:

The libraries for GX Works3 including documentation can be downloaded from:

http://download.linmot.com/plc_lib/libraries/Mitsubishi/

**Note:**

More information can be found in the library documentation (part of the above-mentioned download) and in the user manual CC-Link IE Field Basic Interface (see chapter Documentation / User Manuals).




Image Source: <https://www.mitsubishielectric.com>

CC-Link IE Field Basic is an Industrial Ethernet Standard. The LinMot CC-Link IE Field Basic drives act as CC-Link IE Field Basic slaves in this network.

For further information on CC-Link IE Field Basic please visit:

<https://www.cc-link.org/en/index.html>

8.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:

<http://www.linmot.com/download/linmot-talk-drive-configuration/>

8.2.1 Motor configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



See Appendix I: Basic Position Control Loop Tuning

8.2.2 CSP+ files

Install the CSP+ file(s) that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:


- \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\CCLinkIEFB\CSPP

8.2.3 CC Link Connection

The drive is connected to the CC Link network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an C1250-CC drive.

X17 – X18	ETHERCAT Connector		
	Pin	Wire color code	Assignment 100BASE-TX
	1	WHT/ORG	Rx+
	2	ORG	Rx-
	3	WHT/GRN	Tx+
	4	BLU	-
	5	WHT/BLU	-
	6	GRN	Tx-
	7	WHT/BRN	-
	8	BRN	-
	case	-	-
RJ-45	Use standard patch cables (twisted pair, S/UTP, AWG26) for wiring. This type of cable is usually referred to as a "Cat5e-Cable".		



8.2.4 IP Address

The default IP address is 192.168.3.**xxx**, where the last byte **xxx** is defined via the two address selectors S1 & S2. S1 sets the high and S2 the low digit. E.g., S1 = 5, S2 = A -> 5A (hex) = 90 (dec) -> IP = 192.168.3.90

For further information about the IP address settings please check the interface manual > [0185-1171](#)



Set IP address (last byte, **xxx** from above) by S1 & S2

NodeID Selectors		
C12x0	S1 (5..8)	Station-ID High Nibble (0 ... F). Bit 5 is the LSB, bit 8 the MSB.
	S2 (1..4)	Station-ID Low Nibble (0 ... F). Bit 1 is the LSB, bit 4 the MSB.
		Setting the Station-ID high & low to 0xFF initiates resetting the drive to manufacturer settings!

8.3 PLC Setup CC Link

The following procedure can be used for all Mitsubishi PLCs compatible with GX Works 3.





First, install the CSP+ file for the drive.
(GX Works 3 → Tool → Profile Management → Register)


The required CSP+ file can be found by default in the following folder:

C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\CCLinkIEFB\CSPP


1. First the corresponding CSPP file of the LinMot Drive must be installed. No project must be open when doing so!




2. Then open your project / create a new one and configure the Ethernet port (IP address, ...)



3. From the hardware catalogue the desired drive can be dragged into the network view.



4. Afterwards the I/O data areas can be read.




Note:

Input registers W are counted hexadecimal, output registers R decimal!


Here:
 Read Drive 1: W0
 Read Drive 2: W20
 Write Drive 1: R0
 Write Drive 2: R32 (1F: 31, 20: 32)

5. On the control side, the participants can then be recognized in GX3 Works via "Detect Now". The IP's can be entered to assign the sequence.



8.4 Check with LinMot-Talk if the Fieldbus is running

LinMot-Talk shows the status of the fieldbus. Open the variables CC-Link IE Field Basic and check if the IP Address is correct.



8.5 Next Steps

Now you can start implementing your application using the function blocks and documentation from the download link in chapter **8.1 Overview**.

9 Drive Profile: Rockwell Automation Motion (CIP Sync)

9.1 Overview

LinMot drives with *LinMot EtherNet/IP CIP Sync* interface (e.g., C1250-CM-XC-1S or C1250-MI-XC-1S) can be integrated and setup in a Rockwell Automation environment as motion axis.

Download:

A demo project including EDS files and a detailed documentation can be found here:
http://download.linmot.com/plc_lib/examples/Rockwell_CM/ (CIPSync_Demo...)



Note:

More information and step by step guides can be found in the project documentation (part of the above-mentioned download) and in the user manual Ethernet/IP (0185-1165, see chapter 1.4 Documentation / User Manuals)



EDS Files:

EDS files for **-CM** and **-MI** drives located by default :
 \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherNetIP_NX\EDS



Image Source: <http://www.rockwellautomation.com/>

EtherNet/IP is an industrial Ethernet network that implements the Common Industrial Protocol (CIP).

For further information on EtherNet/IP please visit:

<http://www.odva.org>



YouTube video series (LinMot Integration – Rockwell Automation CIP Sync):
<https://youtube.com/playlist?list=PLMSLCSLnf95PmjyZv8sl6zuHKhci8uln>



Attention: The following minimum requirements must be met!

Rockwell Automation controller revision **must be V30 or later**

LinMot drive firmware **must be 6.8 Build 20190315 or later**

10 Drive Profile: Siemens TIA, PROFIdrive

10.1 Overview

This chapter shows how a LinMot drive with *PROFIdrive* interface (e.g., a C1250-PD-XC-1S) can be integrated and setup in SIEMENS TIA Portal using SIEMENS Telegram 105. For this example, TIA 15 and a S7-1517F-3 PN/DP is used.

Download:

An example project can be downloaded from:

http://download.linmot.com/plc_lib/examples/Siemens_PD/

Components used:

- LinMot C1250-PD-XC-1S-000 (article number 0150-2619) with firmware 6.10 Build 20210521
- CPU 1517F-3 PN/DP (article number 6ES7 517-3FP00-0AB0) with firmware V 2.6.1
- TIA Portal V15.1 Update 4




Image Source: <https://mall.industry.siemens.com>

PROFINET is an open real-time Ethernet network

The LinMot drive acts as slave in this network and is implemented with the TPS1 chip from Renesas.

For further information on PROFINET and the PROFIdrive fieldbus protocols please visit:

<http://www.profibus.com/>



YouTube video series (LinMot Integration – Siemens PROFIdrive):

https://youtube.com/playlist?list=PLMSLCSLnf97_39VIYddSslm57rr-N0su



Attention:

SIEMENS Telegram 105 requires firmware 2.0 and higher installed in the S7-1500 CPU. Some older S7-1500 hardware revisions do not support firmware 2.0. In that case use Standard Telegram 5.



Note:

From firmware 6.6 Build 20170522 the LinMot drive supports the SIEMENS Technology data block:

Functions

Technology data block:

Ja

[Change...](#)

Response to alarm:

Remove all enables (default)

10.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

10.2.1 Motor Configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select "No Drive Homing" in the Motor Wizard as with SIEMENS Telegram 105 the homing of the axis is done in the PLC.

Step 7/10: Homing I

Home Position Search Move

Speed: 0.01 m/s

Mode: No Drive Homing

The drive executes no homing, at power up the homed bit in the Status Word is already set. Mainly used in drive profile applications, where the homing is made in the superior system.

Derived Settings	Value	Comment

Help < Back Next > Finish Cancel Create MDF



See Appendix I: Basic Position Control Loop Tuning

10.2.2 GSDML File

Install the GSDML file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- PROFIdrive: \\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\ProfiNet\GSDML_PD
- PROFIdrive: \\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\ProfiNet_Nx\GSDML_PD (-MI drives)

10.2.3 PROFINET Connection

The drive is connected to the PROFINET network using the X17 (Port1, IN) & X18 (Port 2, OUT) connectors.

X17 – X18	RealTime Ethernet 10/100 Mbit/s	
	X17 RT ETH In	SIEMENS: Port 1, X1.X1
	X18 RT ETH Out	SIEMENS: Port 2, X1.X2
RJ-45		

10.3 PLC Setup

10.3.1 Install GSDML File(s)

The GSDML files for the drives are located by default in the LinMot-Talk installation path:

C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\ProfiNet\GSDML_PD


C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\ProfiNet_Nx\GSDML_PD

In TIA Portal select in the menu bar “Options > Manage general station description files (GSD)” and navigate to the directory you have put the GSDML file(s) in.


10.3.2 Insert the LinMot Drive as Device (-PD Drives)

Select the LinMot C1250-PD-XC-1S drive from the catalogue and drag&drop it to the network view.

Then connect it to your PROFINET network.




Add the SIEMENS Telegram 105 module in the device view to slot 1 and select the MC-Servo OB under I/O addresses:




10.3.3 Insert the LinMot Drive as Device (-MI Drives)

Select the LinMot C1250-MI-XC-1S (C1250xMIPD 1S V3.0) drive from the catalogue and drag&drop it to the network view.

Then connect it to your PROFINET network.



Add the **DO Servo Module** and afterwards the submodule **SIEMENS telegram 105** and optionally **Supplementary telegram 750** in the device view and select the MC-Servo OB under I/O addresses:



10.3.4 Set PROFINET Name and IP Address

In the device properties assign a name and an IP address according to your network setup to the drive:

Module	Rack	Slot
cpu1517axis1	0	0
PNIO	0	0 X1
DO with SIEMENS telegr. 10...	0	1
Parameter Access Point	0	1 1
SIEMENS telegram 105, P...	0	1 2
0	0	2
0	0	3
0	0	4
0	0	5

Properties Dialog - General Tab (cpu1517axis1 [C1250xPD 1S V1.1])

- General** (selected)
- PROFINETinterface [X1]**
 - General
 - Ethernet addresses (selected)
 - Advanced options
 - Hardware identifier
 - Identification & Maintenance
 - Hardware identifier

Ethernet addresses (PROFINETinterface [X1] - Ethernet addresses)

Subnet: PN/IE_1
Add new subnet



IP protocol (PROFINETinterface [X1] - Ethernet addresses)

IP address: 10 . 3 . 8 . 181
Subnet mask: 255 . 255 . 0 . 0
Use router:



Note:


If the PROFINET device name is not assigned automatically you can either right-click the device in the topology view and select "Assign device name" or in the project tree under "Online access".




Normally the PROFINET name and IP address are assigned automatically to the devices if the topology is defined.

10.3.5 Insert and Setup a new Technology object (Linear Axis)


1. Add new object:




2. Select a name and the type of the axis and click OK:



3. Open the axis configuration:



4. Basic Parameters:



Note:

From TO version V6.0 there is a new option to select "Standard motor" or "Linear motor". Choose "Standard motor"

Axis type


Virtual axis

Linear


Rotary

Standard motor

Linear motor




5. Hardware Interface > Drive:

**Note:**

Make sure the correct drive is selected.

6. Hardware Interface > Encoder:



Set Encoder type to “*Incremental*”


**Note:**

If an absolute encoder is connected to the LinMot drive, select “Absolute” as Encoder Type.

Encoder type:

Please also check the note in chapter 10.4.3 Application based example to home a LinMot Linear Axis!


7. Hardware Interface > Data exchange with the drive:



- 1:** Set the reference speed according to the setting within the drive.
E.g., drive: 2 m/s => $2000 \text{ mm/s} * 60 = 120'000 \text{ 1/min}$


LinMot-Talk 6.6

File Search Drive Services Options Window Tools Manuals Help



- 2:** Set to the maximum force of the motor.
This value can be found in the data sheet of the connected motor (*Max. Force @72VDC*).
The motor in this example has 255 N peak force.

8. Hardware interface > Data exchange with encoder:



The internal resolution of the LinMot drive is 0.1um.

**Note:**

If an absolute encoder is connected to the LinMot drive and setup in *Hardware Interface > Encoder*, then set the fine resolution for both *Gx_XIST1* and *Gx_XIST2* to **0 bit**.

Fine resolution

Bits in Gx_XIST1:	0	bit
Bits in Gx_XIST2:	0	bit

Please also check the note in chapter 10.4.3 Application based example to home a LinMot Linear Axis!

9. Extended parameters > Mechanics:

Encoder mounting type: On load side
 Invert encoder direction

Drive mechanism
 Invert drive direction

Load gear
 Number of motor revolutions: 1
 Number of load revolutions: 1

Position parameters
 Leadscrew pitch: 1.0 mm/rot

Make sure the Leadscrew pitch is set to 1 mm/rot.



Attention TIA16:

In TIA16 this parameter is not shown any more if the "Measuring system" is set to *Linear*. This seems to be a bug in TIA16 as the original value (10mm/rot) is taken anyway.

Workaround: Set in **Step 8. above** the "Measuring System" to *Rotary*, change the parameter to 1 mm/rot and then set back "Measuring System" to *Linear*.

Automatic transfer of encoder parameter values

Measuring system: Linear

The parameters of the encoder must match specifications in the device configuration.

Distance between increments: 0.0001 mm

10. Extended parameters > Limits > Torque Limits:

Basic parameters

► Hardware interface

▼ Extended parameters

- Mechanics
- Dynamic default values
- Emergency stop
- Limits
- Position limits
- Dynamic limits
- Torque limits
- Fixed stop detection
- Homing
- Active homing
- Passive homing
- Position monitoring
- Control loop

Torque limits

Default setting for torque limiting

Effective: On motor side
 Torque limit: 0.0 Nm


The limit values are in effect when set at the Motion Control instance for the "Limit" parameter.

Set Effective to *On motor side*.


10.3.6 Insert and Setup a new Technology object (Rotary Axis)

In this example we setup a RS01-52x40 motor (rotary part of a LinMot PR01-52x40...)


1. Add new object:



2. Select a name and the type of the axis and click OK:



3. Open the axis configuration:



4. Basic Parameters:

Basic parameters

Name: Axis2_rot

User program → Technology object axis → Drive → Motor

Axis type

Virtual axis

Linear

Rotary

Measuring units

Measuring unit position:

Measuring unit velocity: °/s

Measuring unit torque: Nm

Modulo

Enable modulo

Modulo start value: 0.0

Length: 360.0

5. Hardware Interface > Drive:

Drive

PLC → Data exchange → Drive → Power → Motor

Encoder data

Drive

Drive type: PROFIdrive

Data connection: Drive


Drive: cpu1517axis2.D0 with SIEMEN...



Note:

Make sure the correct drive is selected.


6. Hardware Interface > Encoder:




The used RS01-52x40 motor (rotary part of a LinMot PR01-52x40...) has a single turn absolute encoder feedback.

Therefor select "Cyclic absolute" as encoder type.

7. Hardware Interface > Data exchange with the drive:




- Set the reference speed according to the settings within the drive:



- Set to the maximum torque of the motor according to the datasheet. The motor in this example has 1.5 Nm peak torque.

8. Hardware interface > Data exchange with encoder:




- 1:** The used RS01-52x40 motor (rotary part of a LinMot PR01-52x40...) has a single turn absolute encoder feedback.
Set the increments according to the settings within the LinMot-Talk Motor Wizard (default 36mm / 360'000 ticks). By default, this motor has 360'000 ticks per revolution.

**Note:**

Following an overview of LinMot rotary motors showing encoder type and increments per revolution.
 - RS01: cyclic absolute (single turn), 360'000 increments per revolution
 - EC02: cyclic absolute (single turn), 524'288 increments per revolution

LinMot supports a wide range of rotary motor. Just check the motor wizard for how many ticks per revolution the motor used has.



9. Extended parameters > Limits > Torque Limits:

The screenshot shows the 'Torque limits' configuration screen. On the left, there is a navigation tree with the following structure:


- Basic parameters
- Hardware interface
- Extended parameters
 - Mechanics
 - Dynamic default values
 - Emergency stop
 - Limits
 - Position limits
 - Dynamic limits
 - Torque limits**
 - Fixed stop detection
 - Homing
 - Active homing
 - Passive homing
 - Position monitoring
 - Control loop

The 'Torque limits' option under 'Limits' is selected and highlighted in blue. On the right, the 'Default setting for torque limiting' panel is displayed. It includes a dropdown menu labeled 'Effective:' with the value 'On motor side' selected, and a text input field for 'Torque limit' containing '0.0 Nm'. A note to the right states: 'The limit values are in effect when they are set at the Motion Control instance for the "Limit" parameter.' Below the panel is a 3D rendering of a motor connected to a gear assembly.

Set Effective to “On motor side”.

10.4 Home / Set Reference**10.4.1 Active Homing for both linear and rotary motors with incremental encoders**

From firmware 6.8 Build 20190315 and later it is possible to use a zero mark via PROFIdrive telegram to execute an active homing using the MC_Home function block of SIEMENS.




On the following pages there are two examples showing the setup in the LinMot drive using the LinMot-Talk software.

Example 1: Generating the zero mark using the Range Indicator 1 functionality of the LinMot drive. The current of the motor should be monitored to detect the hard stop. As soon as the motor current exceeds a set limit the zero mark is generated.


From firmware **6.9 Build xxxxxxxx** the Range Indicator 1 can be used to generate the zero mark via PROFIdrive telegram.

Set the “Reference mark 1 Source” to “NOT Range Indicator 1” (for this example)



As example the motor current or difference position can be used to generate the zero mark.

The *Range Indicator 1* can be setup here (Choose UPID 1B93h as Minuend UPID and set the Low and High Limit Raw Data):



In this case the Range Indicator 1 Bit is set when the Demand Current is between -10A and 10A. Therefor the zero mark will be generated when the motor current is >10A or <-10A.

The active homing itself can then be executed using the **MC_HOME** function block with mode 3 or 5.

Example 2: Generating the zero mark using a Home Switch (external 24V DC signal connected to the drive)

If you have a reference cam/switch then setup a digital input of the LinMot drive to “Home Switch”:

Name	Value
<input type="radio"/> None	Off
<input checked="" type="radio"/> Home Switch	On
<input type="radio"/> Limit Switch Negative	Off
<input type="radio"/> Limit Switch Positive	Off
<input type="radio"/> PTC 1	Off
<input type="radio"/> PTC 2	Off
<input type="radio"/> Capture Input	Off
<input type="radio"/> Ctrl Word: Switch On	Off
<input type="radio"/> Ctrl Word: /Quick Stop	Off
<input type="radio"/> Ctrl Word: Enable Operation	Off
<input type="radio"/> Ctrl Word: /Abort	Off

Set “Reference mark 1 Source” to “Home Switch”:

Name	Value
<input checked="" type="radio"/> Home Switch	On
<input type="radio"/> Z on X13	Off
<input type="radio"/> Range Indicator 1	Off
<input type="radio"/> NOT Range Indicator 1	Off

The active homing itself can then be executed using the **MC_HOME** function block with mode 3 or 5.

10.4.2 Set Reference for both linear and rotary motors with absolute encoders

As the rotary motor used in this example has a single turn absolute encoder it is only required to set the reference flag of the axis. This is also valid for linear axes with absolute encoders too (please check the note below).

This can be done using the function block **MC_HOME** with mode 6 (Absolut encoder adjustment (relative)) and Position = 0.0.



Note:

Please check the SIEMENS Information System for more information about the Motion Control function blocks.



Note for linear absolute encoders:

1. If a linear motor with absolute encoder is used, then first a homing in the drive must be completed once to set the absolute encoder offset in the drive. (e.g., use homing mode "Mechanical Stop Negative Search" > UPID 13C4h [set back to "No Drive Homing" when completed!]).

This can be performed by controlling the motor in the LinMot-Talk Control Panel:

Control	>>	Status	>>	Monitoring
<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	0: Switch On.....1	0: Operation Enabled.....1		Connection Status: Online
<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	1: STO.....1	1: Switch On Active.....1		Firmware Status: Running
<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	2: /Quick Stop.....1	2: Enable Operation.....1		Motor Status: Switched On
<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	3: Enable Operation.....1	3: Error.....0		
<input type="checkbox"/>	4: /Abort.....1	4: Voltage Enable.....1		
<input type="checkbox"/>	5: /Freeze.....1	5: /Quick Stop.....1		
<input type="checkbox"/>	6: Go To Position.....0	6: Switch On Locked.....0		
<input type="checkbox"/>	7: Error Acknowledge.....0	7: Warning.....0		
<input type="checkbox"/>	8: Jog Move +.....0	8: Event Handler Active.....0		
<input type="checkbox"/>	9: Jog Move -.....0	9: Special Motion Active.....0		
<input type="checkbox"/>	10: Special Mode.....0	10: In Target Position.....1		
<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	11: Home.....1	11: Homed.....1		Op. State: Homing
<input type="checkbox"/>	12: Clearance Check.....0	12: Fatal Error.....0		
<input type="checkbox"/>	13: Go To Initial Position.....0	13: Motion Active.....0		Actual Position: 0.00 mm
<input type="checkbox"/>	14: Linearizing.....0	14: Range Indicator 1.....1		Demand Position: 0.00 mm
<input type="checkbox"/>	15: Phase Search.....0	15: Range Indicator 2.....0		Force Factor: 100.00 %
Control Word: 083Fh		Status Word: 4C37h		Motor Current: -0.78 A
<input type="checkbox"/>	Override Value	Op. Main State 09h		Logic Supply Volt.: 23.69 V
<input type="checkbox"/>	Enable Manual Override	Op. Sub State 0Fh		Motor Supply Volt.: 72.10 V



2. After that the absolute encoder adjustment in the PLC must be performed **ONCE** using mode 6 or 7 of the function block MC_Home (check SIEMENS Information System):

Mode 6: Absolute encoder adjustment (relative)

Mode 7: Absolute encoder adjustment (absolute)

This will cause the PLC to store the calculated absolute value offset retentively in the CPU.
(`<TO>.StatusSensor[n].AbsEncoderOffset`)

ATTENTION: If the Actual Position in the Control Panel of LinMot-Talk is showing a negative value when using the MC_Home it is recommended to use mode 7 (absolute) and set the input Position to the value of the Actual Position in the Control Panel. Then the correct offset (negative) is stored in the PLC.

10.4.3 Application based example to home a LinMot Linear Axis

If for any reason the active homing procedure as explained in chapter 10.4.1 can't be used it is also possible to do the homing application based.

Using the torque limiting functionality (MC_TORQUELIMITING) of SIEMENS Telegram 105 it is possible to make a referencing to a mechanical stop with a desired force limit.

If the hard stop should be detected when the motor reaches the set force limit then check for "InLimitation" in state 5 of the following example, or if the hard stop should be detected by the position lag ("Axis1".Clamping.FollowingErrorDeviation) then use "InClamping".

The next page shows how an application-based homing can be performed.

Following a very basic example homing routine that is also part of the example project:

```

CASE "GVL".iHomeState OF
  0: //Idle
    IF "GVL".bHomeExecute THEN
      "GVL".iHomeState := 1;
    END_IF;

  1: //Check motor powered
    IF "MC_POWER_Axis1".Status THEN
      "GVL".iHomeState := 2;
    ELSE
      "MC_POWER_Axis1".Enable := TRUE;
    END_IF;

  2: //Enable Torque Limiting and start moving direction hard stop
    IF NOT "MC_TORQUELIMITING_Axis1".Busy THEN
      "MC_TORQUELIMITING_Axis1".Mode := 1; //Detect hard stop
      "MC_TORQUELIMITING_Axis1".Limit := 100; //Motor force limit in Newton [N]
      "MC_TORQUELIMITING_Axis1".Enable := TRUE; //Enable Torque Limiting
      "Axis1".Clamping.FollowingErrorDeviation := 0.5; //Set clamping detection window [mm]
      "Axis1".Clamping.PositionTolerance := 0.3; //Set clamping position tolerance [mm]
    END_IF;

    "MC_MOVEVELOCITY_Axis1".Velocity := -10; //Velocity to find the hard stop. Values <10mm/s!
    "MC_MOVEVELOCITY_Axis1".Execute := TRUE;

    IF "MC_MOVEVELOCITY_Axis1".Busy THEN
      "GVL".iHomeState := 3;
    END_IF;

  3: // Check axis in limitation & clamping (wait MoveVelocity aborted) and set axis reference
    IF "MC_TORQUELIMITING_Axis1".InLimitation AND "MC_MOVEVELOCITY_Axis1".CommandAborted THEN
      // Set reference position
      "MC_HOME_Axis1".Mode := 0; //Set absolute reference
      "MC_HOME_Axis1".Position := -2.0; //Reference position
      "MC_HOME_Axis1".Execute := TRUE;
    END_IF;

    IF "MC_HOME_Axis1".Done THEN
      "MC_HOME_Axis1".Execute := FALSE;
      "GVL".iHomeState := 5;
    END_IF;

  5: //Move away from hard stop
    "MC_MOVEABSOLUTE_Axis1".Position := 0.0; //Move to 0 position
    "MC_MOVEABSOLUTE_Axis1".Execute := TRUE;
    "MC_MOVEABSOLUTE_Axis1".Velocity := 1; //Slow velocity
    IF "MC_MOVEABSOLUTE_Axis1".Done THEN
      "MC_MOVEABSOLUTE_Axis1".Execute := FALSE;
      "GVL".iHomeState := 10;
    END_IF;

  10: //Clean up
    "MC_MOVEABSOLUTE_Axis1".Execute := FALSE;
    "MC_MOVEABSOLUTE_Axis1".Velocity := -1;
    "MC_HALT_Axis1".Execute := FALSE;
    "MC_HOME_Axis1".Execute := FALSE;
    "MC_MOVEVELOCITY_Axis1".Execute := FALSE;
    "MC_TORQUELIMITING_Axis1".Enable := FALSE;

    "GVL".bHomeExecute := FALSE;
    "GVL".iHomeState := 0;

  ELSE
  ;
END_CASE;

```

10.5 Parameter Access (RAM)

Read/Write access to the RAM value of LinMot drive parameters/variables can be done using the SIEMENS function block “SINA-PARA” (FB286) from the library “DriveLib_S71500” that is installed with SINAMICS Startdrive.

The RAM and ROM values of the drive parameters can be accessed by their parameter number (UPID) added with an offset of 0x2000 (UPID+0x2000).

More information about accessing parameters can be found on the SIEMENS support page:
<https://support.industry.siemens.com> (Entry ID: 99412590)

Example:

Read the value of the parameter Maximal Current (UPID 16#13A6):

Name: Maximal Current

UPID: 16#13A6 = 5030

Type: SInt32 = DINT

Scale: 0.001 A

> .ParaNo = 1 (read 1 parameter)

> .sxParameter[1].siParaNo = 16#2000 + 16#13A6 = 16#33A6 = 13222

Name	...	Display format	Monitor value	Modify value	⚡	Comment
"SINA_PARA_Axis1".Start		Bool	TRUE	TRUE	<input checked="" type="checkbox"/>	
"SINA_PARA_Axis1".ReadWrite		Bool	FALSE	FALSE	<input checked="" type="checkbox"/>	
"SINA_PARA_Axis1".ParaNo		DEC+/-	1	1	<input checked="" type="checkbox"/>	
"SINA_PARA_Axis1".AxisNo		Hex	16#00		<input type="checkbox"/>	
"SINA_PARA_Axis1".hardwareId		DEC	267		<input type="checkbox"/>	
"SINA_PARA_Axis1".Done		Bool	TRUE		<input type="checkbox"/>	
"SINA_PARA_Axis1".Busy		Bool	FALSE		<input type="checkbox"/>	
"SINA_PARA_Axis1".Error		Bool	FALSE		<input type="checkbox"/>	
"SINA_PARA_Axis1".Errord		Hex	16#0000_0000		<input type="checkbox"/>	
"SINA_PARA_Axis1".sxParameter[1].sdValue		DEC+/-	7000	0	<input checked="" type="checkbox"/>	
"SINA_PARA_Axis1".sxParameter[1].silIndex		DEC+/-	0		<input type="checkbox"/>	
"SINA_PARA_Axis1".sxParameter[1].siParaNo		DEC+/-	13222	13222	<input checked="" type="checkbox"/>	// 16#2000 + UPID = 16#33A6 = 13222
"SINA_PARA_Axis1".sxParameter[1].srValue		Floating-point nu...	0.0		<input type="checkbox"/>	
"SINA_PARA_Axis1".sxParameter[1].swErrorNo		Hex	16#0000		<input type="checkbox"/>	
"SINA_PARA_Axis1".sxParameter[1].syFormat		Hex	16#07		<input type="checkbox"/>	

Set .Start TRUE.

As soon as Done becomes TRUE the read data is shown in .sxParameter[1].sdValue

Supported Services:

Request ID	Description
0x01	Request Parameter, reads the RAM value of the parameter
0x02	Change parameter, changes the RAM value of the parameter
0x41	Read ROM value of parameter, only valid with value attribute
0x42	Write ROM value of parameter, only valid with the value attribute

10.6 Add Additional Parameters / Variables to the Real-Time Channel

It is possible to add additional parameters or variables of the drive to the real-time channel to allow read and write access (RAM). There are 4 channels from the Drive to the PLC (32Bit each, Mon Channel 1-4) and 4 channels from the PLC to the Drive (32Bit each, Par Channel 1-4) available.

10.6.1 Drive Configuration

In LinMot-Talk the UPID (parameter/variable address) is entered in the particular channel.

As example in Monitoring Channel 1 the UPID *1B93h (Demand Current)* and in Parameter Channel 1 & 2 the UPID *13FCh (Maximal Current Positive)* and *13FDh (Maximal Current Negative)* are entered.

Name	Value	Raw Data
Channel 1 UPID	1B93h (Demand Current)	1B93h
Channel 2 UPID	0000h	0000h
Channel 3 UPID	0000h	0000h
Channel 4 UPID	0000h	0000h

Name	Value	Raw Data
Channel 1 UPID	13FCh (Maximal Current P...)	13FCh
Channel 2 UPID	13FDh (Maximal Current N...)	13FDh
Channel 3 UPID	0000h	0000h
Channel 4 UPID	0000h	0000h




Attention:

The above used parameters are thought to be an example only and should not be used if SIEMENS telegram 105 is used.


If the parameters in Parameter Channel 1 & 2 have a value of 0 the motor cannot move as they limit the maximal allowed positive and negative motor current in the drive.

10.6.2 PLC Configuration

In the HW Config drag&drop the desired modules from the catalogue to the slots of the drive:



In the IO tags of each Monitoring/Parameter Channel a name can be assigned:


Note:

On SIEMENS PLCs, the double words are transmitted in big endian organization. Therefore, it is required to swap the high and the low word.

This can be done by using the function ROR().

E.g. `DemandCurrent:=ROR(DemandCurrent,16);`

10.7 Telegram 750 / TDB

It is possible to add telegram 750 for additional torque/force functionality using a data block.

10.7.1 LinMot MI Drives


Using LinMot MI drives the telegram 750 can be / is directly connected in the TO configuration.

Telegram 750 is a supplementary telegram for torque/force control containing the following data:


- The PLC sends the additive torque/force (M_ADD) as well as the positive and negative torque/force limit (M_LIMIT_POS, M_LIMIT_NEG) to the drive.
- The drive sends the actual torque/force (M_ACT) to the PLC.

PZD01	PZD02	PZD03
M_ADD	M_LIMIT_POS	M_LIMIT_NEG
M_ACT	---	

- Drag and drop the "Supplementary telegram 750" from the catalogue to a free slot in the Device view:



- Select / check the additional telegram in the TO configuration (Data exchange with the drive):



10.7.2 LinMot PD Drives

Using LinMot PD drives the telegram 750 can be used by following these instructions.

Telegram 750 is a supplementary telegram for torque/force control containing the following data:

- The PLC sends the additive torque/force (M_ADD) as well as the positive and negative torque/force limit (M_LIMIT_POS, M_LIMIT_NEG) to the drive.
- The drive sends the actual torque/force (M_ACT) to the PLC.

▼ Axis1_TorqueData	PD_TEL750
■ □ Input	PD_TEL750_IN
■ □ ActualTorque	Word
■ □ Output	PD_TEL750_OUT
■ □ AdditiveTorque	Word
■ □ UpperTorqueLimit	Word
■ □ LowerTorqueLimit	Word

PZD01	PZD02	PZD03
M_ADD	M_LIMIT_POS	M_LIMIT_NEG
M_ACT	---	


Note:

The data types **PD_TEL750**, **PD_TEL750_IN** and **PD_TEL750_OUT** are automatically added to the project when you set them in the Data type column (they don't show up in the dropdown list).
Do not create your own data types.


- Add the telegram “Data object with SIEMENS teleg. TDB” in the device overview:

The screenshot shows the Siemens SIMATIC Manager Device Overview. A red arrow points to the row for "Data object with SIEMENS teleg. TDB_1". The catalog on the right side lists various data objects, including "Data object with SIEMENS teleg. TDB_1".


- Add two tags in the PLC tags of type **PD_TEL750_IN** and **PD_TEL750_OUT** and assign the addresses from above:

The screenshot shows the SIMATIC Manager PLC tags window. It displays two tags: "Q_Axis1_TEL750" and "I_Axis1_TEL750". Both tags have their "Data type" set to "PD_TEL750_OUT" and "PD_TEL750_IN" respectively. The "Address" column shows "%Q20.0" for the output tag and "%I20.0" for the input tag. The "Access" column has checkboxes for Read, Write, and Visible, all of which are checked for both tags.


3. Create a global data block with the following attributes and create a new tag of type PD_TEL750:



4. Connect the before created tag to the axis TO:



5. Add the organization blocks *MC-PreServo* and *MC-PostServo* to your program blocks. Read the input in *MC-PreServo* and write the output(s) in *MC-PostServo*:



10.8 Using the Closed Loop Force/Torque Control Technology Function

This chapter shows a way to switch from using Telegram 5/105 with a TO Axis to the closed loop force/torque control run mode inside the LinMot drive and vice versa.

This chapter does not cover the general setup of force/torque sensor and the according control loop parameters.

**Attention:**

To use closed loop force/torque control the technology function **TF-Force Control** (0150-2503) is required. Check the manual for more information: <https://shop.linmot.com/E/product/0150-2503>

**Attention:**

Drive firmware **6.10 Build 20210521 or later** is required.

**Note:**


This example was done using the rotary part of a LinMot PR02 Linear Rotary Module with torque sensor. Nevertheless, the same principle is applicable for linear motors with force sensors.



See Appendix II: Basic Closed Loop Torque/Force Control Loop Tuning

10.8.1 Add 1 Monitoring and 2 Parameter Channels / Drive Setup

- In the TIA Portal in the Device overview add the following modules from the catalogue:



- Assign a tag name in their properties to use them in your program:

Par Channel 1_1 [Par Channel 1]

General IO tags System constants Texts				
Name	Type	Address	Tag table	
QD_Axis1_RunMode	DInt	%QD20	Standard-Variablenabelle	

Par Channel 2_1 [Par Channel 2]

General IO tags System constants Texts				
Name	Type	Address	Tag table	
QD_Axis1_TargetTorque	DInt	%QD24	Standard-Variablenabel	

Mon Channel 1_1 [Mon Channel 1]

General IO tags System constants Texts				
Name	Type	Address	Tag table	
ID_Axis1_MeasuredTorque	DInt	%ID20	Standard-Variablenata	

3. Setup the UPIDs for the channels within the drive using the LinMot-Talk software:

Name	Value	Raw ...	Value (RAM)	UPID	Type
Channel 1 UPID	1450h (Run Mode Selection)	1450h	*** (Run Mode Selection)	20B0h	UInt16
Channel 2 UPID	1EA0h (Target Force)	1EA0h	*** (Target Force)	20B1h	UInt16
Channel 3 UPID	0000h	0000h	***	20B2h	UInt16
Channel 4 UPID	0000h	0000h	***	20B3h	UInt16

Name	Value	Raw ...	Value (RAM)	UPID	Type
Channel 1 UPID	1EA1h (Measured Force)	1EA1h	*** (Measured Force)	20A8h	UInt16
Channel 2 UPID	0000h	0000h	***	20A9h	UInt16
Channel 3 UPID	0000h	0000h	***	20AAh	UInt16
Channel 4 UPID	0000h	0000h	***	20ABh	UInt16

4. Enable a Speed Limit to avoid too fast moves in closed loop force/torque control:

Name	Value	Raw Data	Value (RAM)	UPID
Speed Limit	1199.99988241291 °/s	0001D4C0h	*** °/s	1511h

10.8.2 Scaling the Parameter and Monitoring Channels

The *Axis1_TargetTorque* and *Axis1_MeasuredTorque* tags can be scaled and rotated to Nm. This is done at the beginning (monitoring) and the end (parameter) of the program block (here in OB1).

```
▼ Network 1: Read Axis 1 Monitoring Channels
Comment
1 // Torque scaling is 0.000572957795113082 Nm for the used rotary motor (PR02 with 360000 ticks per motor revolution)
2 "Axis1_MeasuredTorque" := INT_TO_REAL((ROR(IN := "ID_Axis1_MeasuredTorque", N:=16)) * 0.000572957795113082;
3

▼ Network 7: Write Axis 1 Parameter Channels
Comment
1 // Torque scaling is 0.000572957795113082 Nm for the used rotary motor (PR02 with 360000 ticks per motor revolution)
2 "QD_Axis1_TargetTorque" := ROR(IN := REAL_TO_DINT("Axis1_TargetTorque" / 0.000572957795113082), N := 16);
3
4 // "Axis1_RunModeSelection" allows switching the drive run mode
5 // 1     = Motion Command Interface [normal operation with telegram 5/105
6 // 14    = Closed Loop Force Control [only visible in LinMot-Talk when logged in as "Service"]
7 "QD_Axis1_RunMode" := ROR(IN := "Axis1_RunModeSelection", N := 16);
```

10.8.3 Example Sequence

The following state machine is an example how the mode can be changed from **controlled by the TO (technology object)** to **closed loop force/torque control inside the drive** and back.

In this example the axis is controlling a rotary motor.

```

//*****
// LinMot Drive Based Torque Control Demo
// - Switch from Telegram 5/105 DSC to closed loop force control and back
//*****
//



CASE "GVL".iTCtrlState OF
 0: // Idle
    // *****
    IF "GVL".bTCtrlExecute THEN
      "Axis1_TargetTorque" := 0;
      "Axis1_RunModeSelection" := 1; // Positioning Mode (Drive Run Mode 1, Telegram 5 / 105)
      "GVL".iTCtrlState := "GVL".iTCtrlState + 1;
    END_IF;

 1: // Move Velocity to disable position-controlled mode and position monitoring
    // *****
    "MC_MOVEVELOCITY_Axis1".Execute := TRUE;
    "MC_MOVEVELOCITY_Axis1".Velocity := 120;
    "MC_MOVEVELOCITY_Axis1".PositionControlled := FALSE; //Important: Disable position controlled. Otherwise, there will be jumps when switching back

    IF "MC_MOVEVELOCITY_Axis1".InVelocity AND "Axis1_MeasuredTorque" > 0.15 THEN // Check actual torque to switch
      "MC_MOVEVELOCITY_Axis1".Execute := FALSE;

      // Change to drive based Torque Control and set target torque
      // *****
      "Axis1_TargetTorque" := 0.2; // Target Torque 0.2 Nm
      "Axis1_RunModeSelection" := 14; // Torque Control Mode (Drive Run Mode 14)

      "GVL".iTCtrlState := "GVL".iTCtrlState + 1;
    END_IF;

 2: // Check target torque reached
    // *****
    IF "Axis1_MeasuredTorque" >= "Axis1_TargetTorque" - 0.02
      // AND ABS(IN := "Axis1_RS02".ActualSpeed) < 2
    THEN
      // Halt axis
      // *****
      "MC_HALT_Axis1".Execute := TRUE;
      "GVL".iTCtrlState := "GVL".iTCtrlState + 1;
    END_IF;

 3: // Check axis halted
    // *****
    IF "MC_HALT_Axis1".Done THEN
      "MC_HALT_Axis1".Execute := FALSE;

      // Reset axis to position control mode (Telegram 5/105)
      // *****
      "Axis1_RunModeSelection" := 1; // Positioning Mode (Drive Run Mode 1, Telegram 5 / 105)

      // Decrement Actual Position a little
      // *****
      "MC_MOVEABSOLUTE_Axis1".Position := "Axis1_RS02".ActualPosition - 0.1; // Increment Actual Position
      "MC_MOVEABSOLUTE_Axis1".Velocity := 3600; //
      "MC_MOVEABSOLUTE_Axis1".Acceleration := 72000; //
      "MC_MOVEABSOLUTE_Axis1".Deceleration := 72000; //
      "MC_MOVEABSOLUTE_Axis1".Direction := 3; // Shortest way!!!
      "MC_MOVEABSOLUTE_Axis1".Execute := TRUE;

      "GVL".iTCtrlState := "GVL".iTCtrlState + 1;
    END_IF;

```

```
4: // Wait move absolute done
// ****
"MC_MOVEABSOLUTE_Axis1".Done THEN
    // Clean up
    // ****
    "MC_MOVEABSOLUTE_Axis1".Execute := FALSE;
    "MC_MOVEVELOCITY_Axis1".Execute := FALSE;
    "MC_HALT_Axis1".Execute := FALSE;

    "Axis1_TargetTorque" := 0;
    "Axis1_RunModeSelection" := 1; // Positioning Mode (Drive Run Mode 1, Telegram 5 / 105)

    "GVL".bTCtrlExecute := FALSE;

    "GVL".iTCtrlState := 0; // Cycle completed
END_IF;

100:// Reset
// ****
"MC_MOVEABSOLUTE_Axis1".Execute := FALSE;
"MC_MOVEVELOCITY_Axis1".Execute := FALSE;
"MC_HALT_Axis1".Execute := FALSE;

"Axis1_TargetTorque" := 0;
"Axis1_RunModeSelection" := 1; // Positioning Mode (Drive Run Mode 1, Telegram 5 / 105)

"GVL".bTCtrlExecute := FALSE;


"GVL".iTCtrlState := 0;
ELSE
;
END_CASE;
```

10.9 Tuning the Control Loops

10.9.1 Drive Control Loop

To start tuning use the **default stiff** settings in the Motor Wizard within LinMot-Talk (motor depending).


In case the motor becomes too loud and vibrates reduce the P and D Gains.



- Make sure the “Enable Noise Filter” is unchecked.
- Set the D Filter Time to 250-500us.
- Set the I Gain to 20-50 A/(mm*s).

After finishing the motor wizard and restarting the drive, the control loop parameters can be tuned in the *Control Parameter Set A* (mainly P, D and I Gains):

LinMot-Talk 6.8



The screenshot shows the LinMot-Talk 6.8 software interface. The left pane displays a tree view of project settings, including Control Panel, Parameters (OS, Motion Control SW, Position Controller), and various sub-options like Drive Configuration, Motor Configuration, and Control Parameter Set A/B. The right pane is a table titled "Control Parameter Set A" with columns "Name" and "Value". The table lists several parameters with their current values:

Name	Value
FF Constant Force	0 A
FF Friction	0.294 A
FF Spring Compensation	0 A/m
FF Damping	0 A/(m/s)
FF Acceleration	0.046 A/(m/s ²)
Spring Zero Position	0 mm
P Gain	7.5 A/mm
D Gain	12.5 A/(m/s)
D Filter Time	500 us
I Gain	50 A/(mm*s)
Integrator Limit	15 A
Maximal Current	15 A
Maximal Current Positive	25 A
Maximal Current Negative	25 A
Noise Deadband Width	0 mm



Up to firmware 6.6 Build 20170410 the I Gain in the Control Parameters Set A of the LinMot drive must be set to 0 (zero).


From firmware 6.6 Build 20170522 the I-Gain must be set to an appropriate value to exactly reach the end position.



Also check chapter Appendix I: Basic Position Control Loop Tuning

10.9.2 PLC Control Loop

Within the technology object configuration set the Gain (Kv factor) to 100. From this value increase until you reach the required stiffness and accuracy.




Make sure DSC is enabled.

Now you are ready to enable the motor and start some movements to optimize the control parameters in both the drive and the PLC.

10.10 Check with LinMot-Talk if the Fieldbus is running

LinMot-Talk shows the status of the fieldbus. Open the variables *PROFIdrive* and check if the Node Address / IP Address is correct.



11 Drive Profile: Beckhoff TwinCAT 2/3, CoE DS402

11.1 Overview

This chapter shows how a LinMot drive with *DS402 (CoE) / CiA402* interface (e.g., C1250-DS-XC-1S) can be integrated and setup in a Beckhoff TwinCAT environment.

For this example, TwinCAT 3 is used. The steps are generally similar for TwinCAT 2.

**Attention:**

Drive firmware **6.10 Build 20210521 or later** is required to use all the functionality shown in this chapter.

Download:

Example projects can be downloaded from:

http://download.linmot.com/plc_lib/examples/Beckhoff_CoE/ (named *LM_CoE_Demo_TCx_...*)




Image Source: <http://www.beckhoff.com/>

EtherCAT is the real-time Ethernet network originally developed by Beckhoff. The LinMot acts as Slave in this network and is implemented with the standard ASIC ET1100 from Beckhoff.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>

**Note:**

In this chapter the following Modes of Operation of the DS402 / CiA402 profile are used:

6 = homing mode

8 = cyclic synchronous position (csp)

10= cyclic synchronous torque (cst)

The modes are switched by setting object 6060h (Mode of operation) to the according value.
The drive shows the active mode in object 6061h (Mode of operation display).

11.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

11.2.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select a homing mode in the Motor Wizard when the drive-based homing should be used as shown in chapter 11.5.2 Homing using the drive-controlled homing (Mode of Operation 6) (e.g., Mechanical Stop Negative Search):



Otherwise select “No Drive Homing” as Mode.



See Appendix I: Basic Position Control Loop Tuning



For **Drive Based Homing** please refer to chapter 11.5.2

11.2.2 XML File

Install the XML file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML\
- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML\ (-MI drives)





XML file names:

NTIL_CiA402_Servos_Vx_xrx.xml	LinMot DS drives SG6-7
NTIL_CiA402_SG5_Servos_Vx_xrx.xml	LinMot DS drives SG5
NTIL_CiA402_Servos_MI_Vx_xrx.xml	LinMot MI drives SG6

11.2.3 EtherCAT Connection

The drive is connected to the EtherCAT network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-DS-UC drive. On all other LinMot drives supporting EtherCAT CoE the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



11.3 PLC Setup

11.3.1 EtherCAT Device Description File XML

The EtherCAT device description file (XML) is located by default in the LinMot-Talk installation path:
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML

Copy the required file to your local TwinCAT installation path:

- C:\TwinCAT\Io\EtherCAT\ (for TwinCAT 2)
- C:\TwinCAT\3.1\Config\Io\EtherCAT\ (for TwinCAT 3)



Note: You may have to restart the developing environment to have the new XML file to be recognized.


11.3.2 Scanning the EtherCAT for new Devices

Follow these steps to add the LinMot drive to your Beckhoff PLC.

1. Restart your PLC into the *Config Mode* to be able to scan for attached devices.




2. Right-Click in the project tree on *Devices* and select *Scan*




Select and insert the found EtherCAT master (e.g., *Device 3 (EtherCAT)*).
You can now directly scan for boxes. If you select yes, then skip the next step.

3. Right-Click on your EtherCAT master (the one found in the previous step) and select *Scan*




4. If the LinMot drive(s) is found the following message is shown:



Select OK

5. You should now have a new axis in your NC configuration:



In the next chapter the configuration of the process data of the LinMot drive is shown

11.3.3 Setting up the Process Data of the LinMot Drive

1. Move to the tab Process Data

Solution Explorer:

- Solution 'LM_CoE_Demo_MC_Home_TC3' (1 project)
 - SYSTEM
 - MOTION
 - PLC
 - SAFETY
 - ANALYTICS
 - I/O
 - Devices
 - Device 3 (EtherCAT)
 - Image
 - Image-Info
 - SyncUnits
 - Inputs
 - Outputs
 - InfoData
 - Drive 1 (C1250-DS-XC-1S)
 - Cyclic Inputs 2
 - Cyclic Position Velocity Torque Mode
 - Torque/force limits
 - WcState
 - InfoData
 - Mappings
 - NC-Task 1 SAF - Device 3 (EtherCAT) 1
 - CoEDemo Instance - Device 3 / EtherCAT 1

Process Data Tab:

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A02	16.0	Cyclic Mode Inputs	F	0	
0x1A03	14.0	Cyclic Mode Inputs 2	F	3	0
0x1A12	14.0	Cyclic Inputs	F	0	
0x1A20	0.0	User Defined Inputs		0	
0x1B08	8.0	Config Module	F	0	
0x1B10	4.0	Input DemVel	F	0	
0x1B11	4.0	Input ActVel	F	0	
0x1B12	4.0	Input ActVelFilt	F	0	
0x1B28	4.0	Mon Channel 1	F	0	
0x1B29	4.0	Mon Channel 2	F	0	

PDO Assignment (0x1C12):

Index	Size	Offs	Name	Type	Default
0x6041:00	2.0	0.0	Statusword	UINT	
0x6064:00	4.0	2.0	Position actual value (units)	DINT	
0x1B8A:00	4.0	6.0	DemandPosition	DINT	
0x1B93:00	4.0	10.0	DemandCurrent	DINT	
0x6061:00	1.0	14.0	Mode of Operation display	SINT	
---	1.0	15.0	---		

PDO Content (0x1A02):

Index	Size	Offs	Name	Type	Default
0x6041:00	2.0	0.0	Statusword	UINT	
0x6064:00	4.0	2.0	Position actual value (units)	DINT	
0x1B8A:00	4.0	6.0	DemandPosition	DINT	
0x1B93:00	4.0	10.0	DemandCurrent	DINT	
0x6061:00	1.0	14.0	Mode of Operation display	SINT	
---	1.0	15.0	---		

2. Click Outputs and select PDOs 0x1604 & 0x1711 for the PDO Assignment (0x1C12)

Process Data Tab:

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A02	16.0	Cyclic Mode Inputs	F	0	
0x1A03	14.0	Cyclic Mode Inputs 2	F	3	0
0x1A12	14.0	Cyclic Inputs	F	0	
0x1A20	0.0	User Defined Inputs		0	
0x1B08	8.0	Config Module	F	0	
0x1B10	4.0	Input DemVel	F	0	
0x1B11	4.0	Input ActVel	F	0	
0x1B12	4.0	Input ActVelFilt	F	0	
0x1B28	4.0	Mon Channel 1	F	0	

PDO Assignment (0x1C12):

Index	Size	Offs	Name	Type	Default
0x6041:00	2.0	0.0	Statusword	UINT	
0x6064:00	4.0	2.0	Position actual value (units)	DINT	
0x1B8A:00	4.0	6.0	DemandPosition	DINT	
0x1B93:00	4.0	10.0	DemandCurrent	DINT	
0x6061:00	1.0	14.0	Mode of Operation display	SINT	
---	1.0	15.0	---		

PDO Content (0x1A02):

Index	Size	Offs	Name	Type	Default
0x6041:00	2.0	0.0	Statusword	UINT	
0x6064:00	4.0	2.0	Position actual value (units)	DINT	
0x1B8A:00	4.0	6.0	DemandPosition	DINT	
0x1B93:00	4.0	10.0	DemandCurrent	DINT	
0x6061:00	1.0	14.0	Mode of Operation display	SINT	
---	1.0	15.0	---		

Download:

- PDO Assignment
- PDO Configuration

0x1604 = Cyclic Position Velocity Torque Mode

0x1711 = Torque/Force Limits (optional)

3. Click **Inputs** and select **0x1A03** for the PDO Assignment (0x1C13)

The screenshot shows the 'Sync Manager' and 'PDO List' sections of the software. In the 'Sync Manager' on the left, a red arrow points to the 'Inputs' row (index 3) in the table. In the 'PDO List' on the right, the row for index 0x1711 is selected. Below these, the 'PDO Assignment (0x1C13)' section shows a list of PDOs, with '0x1A03' selected and highlighted with a red box. The 'PDO Content (0x1711)' section shows the details for PDO 0x1711, which includes Positive torque/force limit (0x60E0:00) and Negative torque/force limit (0x60E1:00). At the bottom, there are download options and predefined assignment buttons.

! The mapping of drive and NC axis should look as follows:

Name	Type	Size	In/Out	Linked to
Statusword	UINT	2.0	Input	nState1, nState2
Position actual value (units)	DINT	4.0	Input	nDataIn1 . In . Inputs . Enc . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Position demand value	DINT	4.0	Input	
Torque actual value	INT	2.0	Input	nDataIn3[0] . nDataIn3 . In . Inputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Mode of Operation display	SINT	1.0	Input	nState5 . In . Inputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
WcState	BIT	0.1	Input	nState4, nState4
InputToggle	BIT	0.1	Input	nState4, nState4
State	UINT	2.0	Input	
AdsAddr	AMSAADDR	8.0	Input	
AoeNetId	AMSNETID	6.0	Input	
Chn0	USINT	1.0	Input	
DcOutputShift	DINT	4.0	Input	nDcOutputTime . In . Inputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
DcInputShift	DINT	4.0	Input	nDcInputTime . In . Inputs . Enc . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Controlword	UINT	2.0	Output	nCtrl1, nCtrl2
Target position	DINT	4.0	Output	nDataOut1 . Out . Outputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Target velocity	DINT	4.0	Output	nDataOut2 . Out . Outputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Target torque	INT	2.0	Output	nDataOut4[0] . nDataOut4 . Out . Outputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Mode of Operation	SINT	1.0	Output	nCtrl5 . Out . Outputs . Drive . Axis 1 . Axis 1 . Axes . NC-Task 1 SAF
Positive torque/force limit	UINT	2.0	Output	GVL.iAxisTorqueLimitPos[1], GVL.iAxisTorqueLimitPos . PlcTask Outputs . CoEDemo Instance . CoEDemo
Negative torque/force limit	UINT	2.0	Output	GVL.iAxisTorqueLimitNeg[1], GVL.iAxisTorqueLimitNeg . PlcTask Outputs . CoEDemo Instance . CoEDemo


Important:

At this point the positive and negative force/torque limits must be mapped/linked as shown above. Otherwise, the motor current will be set to 0 when activating the project and it won't be possible to move.

11.3.4 Check EoE settings

On supported drives (C1250-..., C1450-... & E1450-...) please check the **EoE** (Ethernet over EtherCAT) settings.

LinMot drives do **NOT** support the DHCP mode yet. A fix IP must be assigned (select *IP Address*) or the EoE feature must be completely disabled (disable Virtual Ethernet Port).



Note:

EoE can be used to login into the drive with LinMot-Talk directly over EtherCAT. E.g., to change drive settings or for monitoring and tracing.

11.3.5 Setting up the NC Axis

The following steps show how to basically setup the NC axis (red framed = mandatory).

1. **Axis Drive and AXIS_REF:** Make sure the correct drive and AXIS_REF are selected under “Settings” > “Link To I/O...” and “Link To PLC..”



2. Axis Encoder: Setup the axis encoder as shown. Make sure the correct drive is selected “Link To (all....).

NC-Encoder tab (LinMot linear axis. **For different setups check chapter 11.4)**

The screenshot shows two windows of the Beckhoff TwinCAT 2/3 software interface. The top window is titled 'LM_CoE_Demo_MC_Home_TC3' and displays the 'NC-Encoder' tab. The bottom window is also titled 'LM_CoE_Demo_MC_Home_TC3' and displays the 'Parameter' tab.

Top Window (NC-Encoder Tab):

- Solution Explorer:** Shows the project structure with 'Solution 'LM_CoE_Demo_MC_Home_TC3' (1 project)' expanded, revealing 'SYSTEM', 'MOTION', 'NC-Task 1 SAF', 'Axes', and 'Axis 1'. A red arrow points to the 'Enc' node under 'Axis 1'.
- NC-Encoder Tab:** Shows the tab bar with 'General', 'NC-Encoder' (highlighted with a red border), 'Parameter', 'Time Compensation', and 'Online'. Below the tabs, it says 'Link To (all Types)...' and 'Drive 1 (C1250-DS-XC-1S)'. The 'Type:' field is set to 'Encoder CANopen DS402/MDP 513 (e.g. AX20xx-B1x0/B510)'.

Bottom Window (Parameter Tab):

- Solution Explorer:** Shows the same project structure as the top window.
- Parameter Tab:** Shows the parameter configuration for the encoder. Several parameters are highlighted with red boxes:
 - Scaling Factor Numerator:** 0.0001
 - Scaling Factor Denominator (default: 1.0):** 1.0
 - Invert Direction for Homing Sensor Search:** TRUE
 - Invert Direction for Sync Impuls Search:** FALSE
 - Home Position (Calibration Value):** -2.0
 - Reference Mode (Sync condition):** 'Default'
 - Homing Sensor Source:** 'Default: PLC Cam (MC_Home)'

Depending on what Homing sequence you prefer you can setup some of the Homing parameters here.

3. Axis Drive: Setup the drive as shown (red framed = mandatory)

Parameter tab (LinMot linear axis. **For different setups check chapter 11.4**)


Parameter	Offline Value
Output Settings:	
Invert Motor Polarity	FALSE
Reference Velocity	2200.0
at Output Ratio [0.0 ... 1.0]	1.0
Position and Velocity Scaling:	
Output Scaling Factor (Position)	1.0
Output Scaling Factor (Velocity)	125.0
Output Delay (Velocity)	0.0
Minimum Drive Output Limitation [-1.0 ... 1.0]	-1.0
Maximum Drive Output Limitation [-1.0 ... 1.0]	1.0
Torque and Acceleration Scaling:	
Input Scaling Factor (Actual Torque)	0.1
Input P-T1 Filter Time (Actual Torque)	0.0
Input P-T1 Filter (Actual Torque Derivative)	0.0
Output Scaling Factor (Torque Setpoint)	10.0
Output Scaling Factor (Torque Offset)	10.0
Output Delay (Torque Offset)	0.0
Output Scaling Factor (Acceleration)	0.0
Output Delay (Acceleration)	0.0

4. Axis Ctrl: Set Type as SERCOS controller

NC-Controller tab

Type:
SERCOS controller (Position by SERCOS)

You are now ready to activate the configuration of the PLC and to enable and move the axis in the Online tab of the NC axis



11.4 Encoder Parameter Examples for Linear and Rotary Motors (Axis > Enc)**11.4.1 Linear Motors PS01 / PS10**

The internal position resolution of the LinMot drive is 0.1um for linear motors.

Therefor the following parameters must be set accordingly:

- *Scaling Factor Numerator* must be set to **0.0001** (=1mm / 10'000 Increments)
- *Scaling Factor Denominator* is left to **1.0**

General	NC-Encoder	Parameter	Sercos	Time Compensation	Online
Parameter					Offline Value
-					
Encoder Evaluation:					
Invert Encoder Counting Direction					FALSE
Scaling Factor Numerator					0.0001
Scaling Factor Denominator (default: 1.0)					1.0
Position Bias					0.0
Modulo Factor (e.g. 360.0°)					360.0
Tolerance Window for Modulo Start					0.0
Encoder Mask (maximum encoder value)					0xFFFFFFFF
Encoder Sub Mask (absolute range maximum value)					0x000FFFFF
Reference System					'INCREMENTAL'

11.4.2 Rotary Motors RS01 & RS02

The LinMot RS01 motors (rotary part of LinMot PR01 & PR02 linear rotary motors) have a single turn absolute encoder and by default 360'000 Ticks (Increments) per motor revolution.

Therefor the following parameters must be set accordingly:

- *Scaling Factor Numerator* must be set to **0.001** (=360° / 360'000 Increments)
- *Scaling Factor Denominator* is left to **1.0**

Encoder tab

General	NC-Encoder	Parameter	Sercos	Time Compensation	Online
Parameter				Offline Value	
-					
Encoder Evaluation:					
Invert Encoder Counting Direction				FALSE	
Scaling Factor Numerator				0.001	
Scaling Factor Denominator (default: 1.0)				1.0	
Position Bias				0.0	
Modulo Factor (e.g. 360.0°)				360.0	
Tolerance Window for Modulo Start				0.0	
Encoder Mask (maximum encoder value)				0xFFFFFFFF	
Encoder Sub Mask (absolute range maximum value)				0x000057E40	
Reference System				'ABSOLUTE SINGLETURN RANGE (with single overflow)'	

Drive tab:

General	NC-Drive	Parameter	Time Compensation
Parameter		Offline Value	
-			
Output Settings:			
Invert Motor Polarity		FALSE	
Reference Velocity		7200.0	
at Output Ratio [0.0 ... 1.0]		1.0	
-			
Position and Velocity Scaling:			
Output Scaling Factor (Position)		1.0	
Output Scaling Factor (Velocity)		42.91538516558186	
Output Delay (Velocity)		0.0	
Minimum Drive Output Limitation [-1.0 ... 1.0]		-1.0	
Maximum Drive Output Limitation [-1.0 ... 1.0]		1.0	
-			
Torque and Acceleration Scaling:			
Input Scaling Factor (Actual Torque)		0.1	
Input P-T1 Filter Time (Actual Torque)		0.0	
Input P-T1 Filter (Actual Torque Derivative)		0.0	
Output Scaling Factor (Torque Setpoint)		10.0	
Output Scaling Factor (Torque Offset)		10.0	
Output Delay (Torque Offset)		0.0	

The *Output Scaling Factor (Velocity)* depends on the selected *Encoder Sub Mask*.

$$\text{Scaling} = 125 * 360000 \text{ (16\#000057E40)} / 1048575 \text{ (16\#000FFFFF)} = \underline{\underline{42.915385165581861097203347400043}}$$

11.4.3 Rotary Motors EC02

The LinMot EC02 motors have a single turn absolute encoder and by default 524'288 (2¹⁹) Ticks (Increments) per motor revolution.

Therefor the following parameters must be set accordingly:

- *Scaling Factor Numerator* must be set to 0.006866455078125 (=360° / 524'288 Increments * 10)
- *Scaling Factor Denominator* is set to 10.0 (=1.0 * 10)

Factor 10 is required to have the full resolution in the *Scaling Factor Numerator*

General	NC-Encoder	Parameter	Sercos	Time Compensation	Online
-	Parameter				Offline Value
-	Encoder Evaluation:				
	Invert Encoder Counting Direction				FALSE
	Scaling Factor Numerator				0.006866455078125
	Scaling Factor Denominator (default: 1.0)				10.0
	Position Bias				0.0
	Modulo Factor (e.g. 360.0°)				360.0
	Tolerance Window for Modulo Start				0.0
	Encoder Mask (maximum encoder value)				0xFFFFFFFF
	Encoder Sub Mask (absolute range maximum value)				0x00080000
	Reference System				'ABSOLUTE SINGLETURN RANGE (with single overflow)' ▾

Drive tab:

General	NC-Drive	Parameter	Time Compensation
-	Parameter		Offline Value
-	Output Settings:		
	Invert Motor Polarity		FALSE
	Reference Velocity		7200.0
	at Output Ratio [0.0 ... 1.0]		1.0
-	Position and Velocity Scaling:		
	Output Scaling Factor (Position)		1.0
	Output Scaling Factor (Velocity)		62.500059604701619
	Output Delay (Velocity)		0.0
	Minimum Drive Output Limitation [-1.0 ... 1.0]		-1.0
	Maximum Drive Output Limitation [-1.0 ... 1.0]		1.0
-	Torque and Acceleration Scaling:		
	Input Scaling Factor (Actual Torque)		0.1
	Input P-T1 Filter Time (Actual Torque)		0.0
	Input P-T1 Filter (Actual Torque Derivative)		0.0
	Output Scaling Factor (Torque Setpoint)		10.0
	Output Scaling Factor (Torque Offset)		10.0
	Output Delay (Torque Offset)		0.0
	Output Scaling Factor (Acceleration)		0.0
	Output Delay (Acceleration)		0.0

The *Output Scaling Factor (Velocity)* depends on the selected *Encoder Sub Mask*.

$$\text{Scaling} = 125 * 524288 (16\#00080000) / 1048575 (16\#000FFFFF) = \underline{\underline{62.500059604701618863695968337983}}$$

11.4.4 Other motors

For other motors, the principle is the same to calculate the Numerator, Denominator, and other encoder parameters as well as the Output Scaling Factor (Velocity)

11.5 Homing

There are several ways to home an axis.

Following one option by using the MC_Home function block (11.5.1) and a second option by using a LinMot function block (LM_DSHoming) that controls the drive-based homing (Mode of Operation 6) (11.5.2).

11.5.1 Homing using the MC_Home function block and simulate a reference CAM

The MC_Home function block does not support a block search yet. Nevertheless, it is possible to simulate a calibration cam by a certain force/torque value of the motor.



Attention:

To have the ActualTorque feedback in percent (500% = max. torque/force of the motor) at least firmware **6.10 Build 20210521 or later** is required.

The MC_Home function block *Options* in this example are set to start the search direction negative with 10 unit/s, clear position lag and move away from the calibration cam in positive direction with 50 unit/s.

The calibration cam is set TRUE when the actual motor torque/force is bigger than the set limit in variable rNC_HomeTorqueLimit (500% = max. motor torque/force).

fbMC_Home	ARRAY [1..MAX_AXES] OF MC_Home		
fbMC_Home[1]	MC_Home		
Axis	REFERENCE TO AXIS_REF		Reference to an axis
Execute	BOOL	TRUE	
Position	LREAL	-2	
HomingMode	MC_HOMEINGMODE	MC_DefaultHoming	
BufferMode	MC_BUFFERMODE	MC_Aborting	
Options	ST_HomingOptions		Beckhoff proprietary input
ClearPositionLag	BOOL	TRUE	set actual and set pos... to same value and ...
SearchDirection	MC_DIRECTION	MC_Negative_Direction	
SearchVelocity	LREAL	10	
SyncDirection	MC_DIRECTION	MC_Positive_Direction	
SyncVelocity	LREAL	50	
ReferenceMode	E_ENCODERREFERENCEMODE	ENCODERREFERENCEMODE_DEF...	
bCalibrationCam	BOOL	FALSE	Beckhoff proprietary input
Done	BOOL	TRUE	
Busy	BOOL	FALSE	
Active	BOOL	FALSE	
CommandAborted	BOOL	FALSE	
Error	BOOL	FALSE	
ErrorID	UDINT	16#00000000	
19 (* Call MC_Home*)			
20 // Generate Calibration Cam by monitoring the actual torque/force of the motor. ActTorque scale is 1.0% => ActTorque = torque in percent			
21 // It is directly assigned to the HomingSensor too (Bit 5 of the NC axis ControlDWord > see Beckhoff help)			
22 fbMC_Home[iLoopAxisNr[2..?].bCalibrationCam[??] := Axis_Ref[iLoopAxisNr[2..?].PicToNc.ControlDword[??..?].5[??] := ABS(Axis_Ref[iLoopAxisNr[2..?].NoToPic.ActTorque[??..?] >= (rNC_			
23			
24			

The actual torque is visible in the AXIS_REF structure (**AXIS_REF.NcToPlc.ActTorque**).



Note:

For more details check the example project (link in chapter 11.1 Overview)

11.5.2 Homing using the drive-controlled homing (Mode of Operation 6)

To home the axis, the drive-controlled homing (Mode of Operation 6) can be used.

The example project (see chapter 11.1) contains a function block (LM_DSHoming) to execute the drive-controlled homing.

```

PROGRAM DriveBasedHomingDemo
VAR
    fbMC_Home :IM_DSHoming;
    bHomeExecute :BOOL;
    rHomePosition :LREAL := 0.0; // Home Position
END_VAR

// -----
// DEMO
// -----
// LimMot Drive Based Homing Demo (Drive PDO 0x1604)
// - Switches mode of operation to 6 (Drive base Homing)
// - The function block disables the position lag monitoring of the NC axis, executes the drive based homing,
//   sets the reference flag of the NC axis and it's position and reenables the position lag monitoring.
// - The function block LM_DSHoming uses the following Beckhoff function blocks from TC2_Nc and TC2_MC2:
//   - ADSWRITE
//   - ADSREAD
//   - MC_SetPosition
//   - MC_Reset
//   - MC_WriteNcIoOutput
//   - MC_ReadDriveOperationMode
//   - MC_WriteDriveOperationMode
//
// ATTENTION: To be used with drive PDO 0x1604 (or any other that maps parameter 16#6060 Mode Of Operation)
//
// ATTENTION: This example is provided by NTI AG / LinMot free of charge with no warranty for updates.
// Also, LinMot accepts no liability for damages that may be caused by using this example
//
// This is only an example! A proper implementation on the users machine may differ completely.
//
// For support please contact us
// http://www.linmot.com/support/contact/
//
fbMC_Home(
    Axis      := Axis_Ref[1],
    Execute   := bHomeExecute,
    HomePosition := rHomePosition,
);

```

Inputs of the function block:

Execute (BOOL)

HomePosition (LREAL)

Axis (AXIS_REF)

Start drive-controlled homing

Position the NC axis actual position is set to after homing is completed

Axis reference of the NC axis




Note:

The LM_DSHoming function block uses several Beckhoff function blocks. The following Beckhoff libraries are required:

- **TC2_Standard** (R_TRIG, TON)
- **TC2_System** (ADSREAD, ADSWRITE)
- **TC2_MC2** (MC_Reset, MC_SetPosition, MC_WriteNcIoOutput, MC_ReadDriveOperationMode, MC_WriteDriveOperationMode)


11.6 Visualization

The example project contains a visualization to control the NC axis (including the mentioned homing method in the chapter 11.5.1):



11.7 Drive Reset

To acknowledge an error of a CoE drive the function block *MC_Reset* must be used on TwinCAT systems. This function block is part of the Beckhoff library *TC2_MC2* (*TwinCAT 3*) / *MC* (*TwinCAT 2*).



11.8 Asynchronous Parameter Access

Parameters of the LinMot drive can be accessed using the Beckhoff function block *FB_EcCoESdoRead* and *FB_EcCoESdoWrite* which are part of the *Tc2_EtherCAT (TwinCAT 3) / EtherCAT (TwinCAT 2)* library.

More information about this function blocks can be found in the Beckhoff Information System:
<http://infosys.beckhoff.com> (search for *FB_EcCoESdoRead* & *FB_EcCoESdoWrite*).

Example calls of this function blocks can be found in the example project.

```

1 PROGRAM ParameterAccess
2
3     VAR
4         iLoopAxisNr :INT; (*Loop counter*)
5
6         fbGetAxisAmsAddr : ARRAY[1..MAX_AXES] OF FB_GetAxisAmsAddr; (* Get the NetID and the Port of the drive linked to the NC axis by AxisID *)
7
8         CoERead    :ARRAY[1..MAX_AXES] OF FB_EcCoESdoRead;
9         CoEWrite   :ARRAY[1..MAX_AXES] OF FB_EcCoESdoWrite;
10
11        UPID      :ARRAY[1..MAX_AXES] OF WORD;
12        SubIndex  :ARRAY[1..MAX_AXES] OF BYTE;
13        DataIN    :ARRAY[1..MAX_AXES] OF DINT;
14        DataOUT   :ARRAY[1..MAX_AXES] OF DINT;
15
16 END_VAR
17
18
19 (* Read parameter
20 =====)
21
22 CoERead[iLoopAxisNr]{
23     sNetId:=g_aDrive_AmsAddr[iLoopAxisNr].netId,
24     nSlaveAddr:=g_aDrive_AmsAddr[iLoopAxisNr].port,
25     nIndex:= 16#2000 + UPID[iLoopAxisNr],
26     nSubIndex:= SubIndex[iLoopAxisNr], (*e.g. 16#01 = Access RAM Value*)
27     pDstBuf:= ADR(DataIN[iLoopAxisNr]),
28     cbBufLen:= SIZEOF(DataIN[iLoopAxisNr]),
29     bExecute:= ,
30     tTimeout:= ,
31     bBusy=> ,
32     bError=> ,
33     nErrId=> );
34
35 (* Write parameter
36 =====)
37
38 CoEWrite[iLoopAxisNr]{
39     sNetId:=g_aDrive_AmsAddr[iLoopAxisNr].netId,
40     nSlaveAddr:=g_aDrive_AmsAddr[iLoopAxisNr].port,
41     nIndex:= 16#2000 + UPID[iLoopAxisNr],
42     nSubIndex:= SubIndex[iLoopAxisNr], (*e.g. 16#01 = Access RAM Value*)
43     pSrcBuf:= ADR(DataOUT[iLoopAxisNr]),
44     cbBufLen:= SIZEOF(DataOUT[iLoopAxisNr]),
45     bExecute:= ,
46     tTimeout:= ,
47     bBusy=> ,
48     bError=> ,
49     nErrId=> );
50
51
52
53
54
55
56
57
58
59
60
61
62
63

```

sNetID, nSlaveAddr: AmsNetID & port of the drive.

These can be read using the function block *FB_GetAxisAmsAddr* which is part of the Beckhoff library *Tc2_NC (TwinCAT 3) / TcNC (TwinCAT 2)*.

nDriveNo: NC axis ID

nIndex: Parameter address to be accessed = **16#2000** + UPID

(E.g., Maximal Current (UPID 16#13A6)  **nIndex** = 16#2000 + 16#13A6 = 16#33A6)

nSubIndex: The following commands can be performed

(See user manual 0185-1103 for more information > search on <http://shop.linmot.com>)

SDO Service	Index	SubIndex	Description
Read	2000h+UPID	0x01	Parameter UPID read RAM value
Write	2000h+UPID	0x01	Parameter UPID write RAM value
Read	2000h+UPID	0x02	Parameter UPID read ROM value
Write	2000h+UPID	0x02	Parameter UPID write ROM value
Read	2000h+UPID	0x03	Parameter UPID read minimal value
Read	2000h+UPID	0x04	Parameter UPID read maximal value
Read	2000h+UPID	0x05	Parameter UPID read default value
Write	2000h+UPID	0x06	Parameter UPID write RAM and ROM value
Write	2000h	0x07	Parameter Default OS SW instance
Write	2000h	0x08	Parameter Default MC SW instance
Write	2000h	0x09	Parameter Default Intf SW instance
Write	2000h	0x0A	Parameter Default Appl SW instance
Write	2000h	0x0B	Reset device

pDstBuf, pSrcBuf: Address to the variable containing the value to be read / written (must be of size 4 Bytes!)

cbBufLen: Size of the variable of the value to be read / written (must be of size 4 Bytes!)



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual
> see chapter Documentation / User Manuals



Note:

Use *FB_EcCoESdoRead* & *FB_EcCoESdoWrite* from Beckhoff to access drive parameters.




For every access (read or write) the length of the variable connected to pDstBuf/pSrcBuf must be of **size 4 Bytes** (e.g., datatypes DWORD, DINT, UDINT).

If you access a parameter/variable of a different size (e.g., INT, SINT, ...) then make a typecast afterwards.

11.9 Add Positive and Negative torque/force limit (0x1711) to the Process Data

It is possible to add additional Process Data to PDO for cyclical write access. The additional Output *Torque/force Limits* (0x60E0 & 0x60E1) control the *Maximal Current Positive* (UPID 13FCh) and the *Maximal Current Negative* (UPID 13FDh) of the drive cyclically by adding the PDO 0x1711 in the PDO Assignment.


Note:

The maximum Torque/force Limit value is **5000 (500.0%)** and corresponds to the **maximal Current** of the connected motor. The value **1000 (100.0%)** corresponds approximately to the **nominal Current** of the motor.

Example 1:


Torque/Force Limit Positive: **1000 (100.0%)**
 Motor Maximal Current: 7.5 A
 = Max. Current Positive: 1.5 A

Example 2:

Torque/Force Limit Negative: **5000 (500.0%)**
 Motor Maximal Current: 7.5 A
 = Max. Current Negative: 7.5 A


Note:

Torque/force Limit value is supported from xml version V1.8b7 with Firmware Build 6.8 Build 20190315 and newer.



The screenshot shows the LinMot-Talk 6.10 software interface. On the left, the GVL [Online] window displays a table of variables and their values. Two specific variables are highlighted with red boxes: `iAxisTorqueLimitPos[1]` with a value of 1000 and `iAxisTorqueLimitNeg[1]` with a value of 5000. These correspond to the `g_aDrive_AmsAddr` and `g_aDrive_Ref` variables in the table. On the right, the Project window shows the configuration of a DS402_Demo module. A red arrow points from the highlighted GVL variables to the corresponding parameters in the project tree. The `iAxisTorqueLimitPos[1]` is mapped to the `Maximal Current Positive` parameter, and the `iAxisTorqueLimitNeg[1]` is mapped to the `Maximal Current Negative` parameter.




Attention:

Make sure, that the torque/force limit is not 0. Otherwise, the motor cannot move with a current of 0A.

11.10 Add Additional Parameters or Variables to the Process Data

It is possible to add additional parameters or variables of the drive to PDO for cyclical write or read access.

Example 1: Read the *Min. Motor Temperature reserve (UPID 1C00h)* of the drive cyclically by adding it into the User Defined Inputs (0x1A20):



Name	Value	RawData	UPID	Type	Scale
Motor Hall Sine	3.427734726 V	02BEh	1B6Ch	SInt16	0.004882813 V
Motor Hall Cosine	0.874023527 V	00B3h	1B6Dh	SInt16	0.004882813 V
Motor Hall Check Level	2.553711199 V	020Bh	1B72h	SInt16	0.004882813 V
Motor Actual Position	24.004 mm	0003A9A8h	1B74h	SInt32	0.0001 mm
Motor Actual Velocity	-0.000266 m/s	FFFFFEF6h	1B75h	SInt32	1E-6 m/s
Motor Angle	148.743989648438 °	69C7h	1B73h	UInt16	0.0054931640625
Motor Angle in Revolution	870.380859375 °	FF70h	1B64h	SInt32	0.0054931640625
Motor Correction Angle	-0.791015625 °		1B65h	SInt16	0.0054931640625
Commutation Angle			1B71h	UInt16	0.0054931640625
Motor Hall Switch U	FALSE	0h	1B6Eh	Bool	
Motor Hall Switch V	FALSE	0h	1B6Fh	Bool	
Motor Hall Switch W	FALSE	0h	1B70h	Bool	
Motor Power Losses	0 W	00000000h	1BDDh	UInt32	0.1 W
Motor Power Losses Ph1	0 W	0000h	1BDEh	SInt16	0.1 W
Motor Power Losses Ph2	0 W	0000h	1BDFh	SInt16	0.1 W
Calculated Winding Warn Temp	100 °C	03E8h	1BD5h	SInt16	0.1 °C
Calculated Winding Error Temp	110 °C	044Ch	1BD6h	SInt16	0.1 °C
Full Motor Model Ph1 Winding Temp	25.4 °C	00FEh	1BE4h	SInt16	0.1 °C
Full Motor Model Ph2 Winding Temp	25.4 °C	00FEh	1BE5h	SInt16	0.1 °C
Full Motor Model Ph1 Sealing Compou...	25.4 °C	00FEh	1BE6h	SInt16	0.1 °C
Full Motor Model Ph2 Sealing Compou...	25.4 °C	00FEh	1BE7h	SInt16	0.1 °C
Full Motor Model Housing Temp	25.4 °C	00FEh	1BE8h	SInt16	0.1 °C
Full Motor Model Mounting Temp	25.4 °C	00FEh	1BE9h	SInt16	0.1 °C
Temp Environment	25 °C	00FAh	1BEAh	SInt16	0.1 °C
Max Read Out Motor Temp	25.4901960784314 °C	004Dh	1BF3h	UInt16	0.9803921568627
Motor Temp Ph2	25.4901960784314 °C	004Dh	1BF4h	UInt16	0.9803921568627
Motor Temp Ph1	-50 °C	0000h	1BF5h	UInt16	0.9803921568627
Motor Temp Ph1 v	-50 °C	0000h	1BF6h	UInt16	0.9803921568627
Phase Resistance Ph1	1.53 Ohm	0099h	1BEFh	UInt16	0.01 Ohm
Phase Resistance Ph2	1.53 Ohm	0099h	1BF0h	UInt16	0.01 Ohm
Min. Motor Temperature reserve	64.6 °C	0286h	1C00h	SInt16	0.1 °C
Maximal Force	0 N	00000000h	1BB0h	SInt32	0.1 N
Actual Force	0 N	00000000h	1BFFh	SInt32	0.1 N
Maximal Torque	2.381044 Nm	002454F4h	1BBEh	SInt32	1E-6 Nm
Actual Torque	0 Nm	00000000h	1BFFh	SInt32	1E-6 Nm


Name: Min. Motor Temperature reserve

UPID: 1C00h

Type: Sint16 = INT

Scale: 0.1 °C


1. In the Process Data select *0x1A20 User Defined Inputs* from the PDO List.
2. Right-click on the empty line where only an offset is shown



Index	Size	Name	Flags	SM	SU
0x1A02	16.0	Cyclic Mode Inputs	F	0	
0x1A03	14.0	Cyclic Mode Inputs 2	F	3	0
0x1A12	14.0	Cyclic Inputs	F	0	
0x1A20	0.0	User Defined Inputs		3	0
0x1B08	8.0	Config Module	F	0	
0x1B10	4.0	Input DemVel	F	0	
0x1B11	4.0	Input ActVel	F	0	
0x1B12	4.0	Input Accel/Decel	F	0	

Index	Size	Offs	Name	Type	Default (hex)
0.0					
0x1A20					

3. In the *Edit PDO Entry* window enter the name, the UPID as *Index* and set the *Data Type* to INT (as the Min. Motor Temperature Reserve is of type SINT16)



4. Click OK to finish

Example 2: Write the *Maximal Current* (UPID 13A6h) of the drive cyclically by adding it into the User Defined Outputs (0x1620):

Name	Value	Raw Data	Value...	UPID	Type	Scale
FF Constant Force	0 A	00000000h	0 A	139Ch	SInt32	0.001 A
FF Friction	0 A	00000000h	0 A	139Dh	SInt32	0.001 A
FF Spring Compensation	0 A/m	0000h	0 A/m	139Eh	SInt16	1 A/m
FF Damping	0 A/(m/s)	0000h	0 A/...	139Fh	SInt16	0.01 A/(m/s)
FF Acceleration	0 A/(m/s^2)	0000h	0 A/...	13A0h	UInt16	0.001 A/(m...
Spring Zero Position	0 mm	00000000h	0 mm	13A1h	SInt32	0.0001 mm
P Gain	5 A/mm	0032h	5 A/...	13A2h	UInt16	0.1 A/mm
D Gain	10 A/(m/s)	0064h	10 A/...	13A3h	UInt16	0.1 A/(m/s)
D Filter Time	200 us	00C8h	200 us	13A8h	UInt16	1 us
I Gain	0 A/(mm*s)	0000h	0 A/...	13A4h	UInt16	0.1 A/(mm*s)
Integrator Limit	13.5 A	000034BCh	13.5 A	13A5h	SInt32	0.001 A
Maximal Current	13.5 A	000034BCh	13.5 A	13A6h	SInt32	0.001 A
Maximal Current Positive	25 A	000061A8h	0 A	13FCh	SInt32	0.001 A
Maximal Current Negative	25 A	000061A8h	0 A	13FDh	SInt32	0.001 A
Noise Deadband Width	0.01 mm	0064h	0.01 ...	13A7h	UInt16	0.0001 mm

Name: Maximal Current


UPID: 13A6h

Type: SInt32 = DINT


Scale: 0.001 A

1. In the Process Data select 0x1620 *User Defined Outputs* from the PDO List.

2. Right-click on the empty line where only an offset is shown




3. In the *Edit PDO Entry* window enter the name, the UPID as *Index* and set the *Data Type* to DINT (as the Maximal Current is of type SINT32)



4. Click OK to finish

Now you can see both added parameters in the solution tree and link them:



Variable Definition in the GVLs

```
iMotorSensorTemp      AT %I*:ARRAY[1..MAX_AXES] OF INT;
uiMaximalCurrent     AT %Q*:ARRAY[1..MAX_AXES] OF DINT := [MAX_AXES(1000)]; (*1A*)
uiForceLimitPos      AT %Q*:ARRAY[1..MAX_AXES] OF UINT := [MAX_AXES(5000)]; (*500*)
uiForceLimitNeg      AT %Q*:ARRAY[1..MAX_AXES] OF UINT := [MAX_AXES(5000)]; (*500*)
```

11.11 Using the Closed Loop Force/Torque Control Technology Function

This chapter shows an application example of how the technology function *closed loop force/torque control* inside the LinMot drive can be used.

This chapter does not cover the general setup of force/torque sensor and the according control loop parameters. Please check the according documentation.


Attention:

To use closed loop force/torque control the technology function **TF-Force Control** (0150-2503) is required. Check the manual for more information: <https://shop.linmot.com/E/product/0150-2503>


Attention:

Drive firmware **6.10 Build 20210521 or later** is required.


Note:

This example was done using the rotary part of a LinMot PR02 Linear Rotary Module with torque sensor. Nevertheless, the same principle is applicable for linear motors with force sensors.



See Appendix II: Basic Closed Loop Torque/Force Control Loop Tuning

11.11.1 Drive Setup

To enable the closed loop/force control in *Mode of Operation 10 (CST)* UPID 2070h must be set to “Closed Loop Force/Torque Control Mode”:

Name	Value	Raw Data	Value (RAM)	UPID	Type
Current Command Mode	Off	0000h	Off	2070h	UInt16
Force/Torque Control Mode	Off	0001h	Off	2070h	UInt16
Closed Loop Force/Torque Control Mode	On	0002h	On	2070h	UInt16

Object Inspector

Object Description: What is the Object Inspector?

Object Type	UInt16 RadioChild
Child Name	Closed Loop Force/Torque Control Mode
Child Value	0002h
Parent Name	Operation Mode 10 Config
Parent UPID	2070h
Description	In Operation Mode 10 the closed loop force/torque control mode is activated, the setpoint is given relative, 5000 corresponds to the maximal force/torque.

Open Object Inspector after Login [More...](#) [Close](#)


Note:

If an open loop force/torque control is enough for the application (less accurate and influenced by mechanical properties) one can also use “Force/Torque Control Mode” which sets the requested current.

11.11.2 PLC Setup

Make sure that the input and output scaling factors for torque are set correctly in the NC axis:

Parameter	Offline Value
- Output Settings:	
Invert Motor Polarity	FALSE
Reference Velocity	2200.0
at Output Ratio [0.0 ... 1.0]	1.0
- Position and Velocity Scaling:	
Output Scaling Factor (Position)	1.0
Output Scaling Factor (Velocity)	125.0
Output Delay (Velocity)	0.0
Minimum Drive Output Limitation [-1.0 ... 1.0]	-1.0
Maximum Drive Output Limitation [-1.0 ... 1.0]	1.0
- Torque and Acceleration Scaling:	
Input Scaling Factor (Actual Torque)	0.1
Input P-T1 Filter Time (Actual Torque)	0.0
Input P-T1 Filter (Actual Torque Derivative)	0.0
Output Scaling Factor (Torque Setpoint)	10.0
Output Scaling Factor (Torque Offset)	10.0
Output Delay (Torque Offset)	0.0
Output Scaling Factor (Acceleration)	0.0
Output Delay (Acceleration)	0.0


Note:

The torque unit is in 0.1 percent [%].

Decimal 5000 reflects 500% = motor maximal torque/force.

Torque Actual value (object 0x6077) and Target torque (object 0x6071) are used to read and write the torque/force of the motor in percent.

Therefore, the input scaling factor must be 0.1 and the output scaling factor must be 10.


Attention:

This example requires the drive PDOs setup as shown in chapter 11.3.3.

11.11.3 Example Sequence

The example project from chapter 11.1 contains an example sequence **TorqueForceControlDemo** following that shows how a closed loop force control process could look like.

In the example the axis is controlling a rotary motor.



Attention:

This example should not directly be used as it is shown!
Please adapt it to your machine and error handling concept.

Tested using:

- TwinCAT target version **V3.1 Build 4024.32**
- LinMot C1250-DS-XC-1S drive with **Firmware 6.11 Build 20220628**

```

1 PROGRAM TorqueForceControlDemo
2 VAR
3     fbMC_TorqueControl      :MC_TorqueControl;
4     fbMC_MoveAbsolute        :MC_MoveAbsolute;
5     fbMC_MoveVelocity        :MC_MoveVelocity;
6     fbMC_Halt                :MC_Halt;
7     fbMC_Reset               :MC_Reset;
8
9     rTargetTorque           :REAL := 100.0; // 100.0 % target torque/force (+/-500.0 % = maximal torque/force of the motor)
10    rLimitTorque            :REAL := 70.0; // 70.0 % torque/force limit to switch to torque/force control
11    rSearchSpeed             :REAL := 10.0; // 10 Units
12    rSearchAccDec            :REAL := 100.0; // 100 Units
13    rFastSpeed               :REAL := 4000.0; // 4000 Units
14    rFastAccDec              :REAL := 5000.0; // 5000 Units
15    rStopDec                 :REAL := 50000.0; // 50000 Units
16    rDistance                 :REAL := 0.05; // 0.05 Units, Distance to move away from target after process completed
17    rSmoothJerk              :REAL := 1000000.0; //
18    rStopJerk                 :REAL := 10000.0; //
19
20    State                    :INT; // State machine
21    Execute                  :BOOL; // Start process
22
23    Error                    :BOOL; // Error flag
24    ErrorCode                :UDINT; // Error code
25    ErrorState               :INT; // State Error happened
26
27    Axis                     :Axis_Ref;
28
29    ExecuteOffTrigger         :F_TRIG;
30 END_VAR
31
32 // Read inputs
33 // Axis := Axis_Ref[1]; // Assign axis (1 in this example)
34
35 // DEMO
36 // LinMot Drive Based Torque/Force Control Demo
37 // - Switches mode of operation to 10 (CST, TorqueControl) by using MC_TorqueControl (tc2_mc2 3.3.48.0)
38 // - Inside the drive set parameter UPID 2070h to the desired mode:
39 //     Force/Torque Mode (1): without force/torque cell
40 //     Closed Loop Force/Torque Control Mode (2): closed loop force control inside the drive with force/torque cell feedback
41 //
42 // ATTENTION: Make sure to enable the Speed Limiter in the drive (UPID 1511h) before starting with tests
43 //
44 // ATTENTION: This example is provided by NTI AG / LinMot free of charge with no warranty for updates.
45 // Also, LinMot accepts no liability for damages that may be caused by using this example
46 //
47 // This is only an example! A proper implementation on the users machine may differ completely.
48 ...

```

12 Drive Profile: Beckhoff TwinCAT 2/3, SoE (Outdated)



Important Note:

For new applications with Beckhoff PLCs LinMot recommends using LinMot drives with **CoE (DS402/CiA402)** interface.

See chapter **11 Drive Profile: Beckhoff TwinCAT 2/3, CoE DS402**

12.1 Overview

This chapter shows how a LinMot drive with *Servo Drive Profile over EtherCAT (SoE)* interface (e.g., C1250-SE-XC-1S) can be integrated and setup in a Beckhoff TwinCAT environment. For this example, TwinCAT 3 is used. The steps are generally similar for TwinCAT 2.

Download:

Example projects can be downloaded from:

http://download.linmot.com/plc_lib/examples/Beckhoff_SoE/ (named *LM_SoE_Demo_TCx_...*)




Image Source: <http://www.beckhoff.com/>

EtherCAT is the real-time Ethernet network originally developed by Beckhoff. The LinMot acts as Slave in this network and is implemented with the standard ASIC ET1100 from Beckhoff.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>

12.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

12.2.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select a homing mode in the Motor Wizard as with the SoE interface a drive-based homing is possible (e.g. *Mechanical Stop Negative Search*):



See Appendix I: Basic Position Control Loop Tuning

12.2.2 XML File

Install the XMLfile that is part of the LinMot-Talk software/firmware you are using.



The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherCAT SoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT_SoE\XML

12.2.3 EtherCAT Connection

The drive is connected to the EtherCAT network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-SE-UC drive. On all other LinMot drives supporting EtherCAT SoE the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



12.3 PLC Setup

12.3.1 EtherCAT Device Description File XML

The EtherCAT device description file (XML) is located by default in the LinMot-Talk installation path:
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT_SoE\XML

Copy this file to your local TwinCAT installation path:

- C:\TwinCAT\Io\EtherCAT\ (for TwinCAT 2)
- C:\TwinCAT\3.1\Config\Io\EtherCAT\ (for TwinCAT 3)



Note: You may have to restart the developing environment to have the new XML file to be recognized.


12.3.2 Scanning the EtherCAT for new Devices

Follow these steps to add the LinMot drive to your Beckhoff PLC.

1. Restart your PLC into the *Config Mode* to be able to scan for attached devices.




2. Right-Click in the project tree on *Devices* and select *Scan*




Select and insert the found EtherCAT master (e.g. *Device 3 (EtherCAT)*).

You can now directly scan for boxes. If you select yes, then skip the next step.

3. Right-Click on your EtherCAT master (the one found in the previous step) and select *Scan*




4. If the LinMot drive(s) is found the following message is shown:



Select Yes (Ja)


5. You should now have a new axis in your NC configuration:




In the next chapter the configuration of the process data of the LinMot drive is shown

12.3.3 Setting up the Process Data of the LinMot Drive


- Move to the tab *Process Data*



- Select **AT 1**, right-click the free slot at Offset 6 and select *Insert*



3. Select the S-0-0189 – Following Distance and click OK




4. Select MDT 1, right-click the free slot at Offset 6 and select Insert

Flags	Index	Size	Name	Flags
	S-0-0016	10.0	AT 1	M
	S-0-0024	6.0	MDT 1	M

Index	Size	Offs	Name
S-0-0134	2.0	0.0	Master control word
S-0-0047	4.0	2.0	Position command value
		6.0	

Insert...


5. Select the S-0-0036 – Velocity command value and click OK



12.3.4 Check EoE settings

On supported drives (C1250-..., C1450-... & E1450-...) please check the EoE (Ethernet over EtherCAT) settings.

LinMot drives do NOT support the DHCP mode yet. A fix IP must be assigned (select *IP Address*) or the EoE feature must be completely disabled (disable Virtual Ethernet Port).


Note:


EoE can be used to login into the drive with LinMot-Talk directly over EtherCAT.
E.g. to change drive settings or for monitoring and tracing.

12.3.5 Setting up the NC Axis

The following steps show how to basically setup the NC axis.

1. **Axis Encoder:** Setup the axis encoder as shown:

NC-Encoder tab



Parameter tab (for linear axis. Check chapter 12.4 for rotary examples)


Parameter	Offline Value
- Encoder Evaluation:	
Invert Encoder Counting Direction	FALSE
Scaling Factor Numerator	0.0001
Scaling Factor Denominator (default: 1.0)	1.0
Position Bias	0.0
Modulo Factor (e.g. 360.0°)	360.0
Tolerance Window for Modulo Start	0.0
Encoder Mask (maximum encoder value)	0xFFFFFFFF
Encoder Sub Mask (absolute range maximum value)	0x000FFFFF
Reference System	'INCREMENTAL'

Sercos tab

The screenshot shows the 'Sercos' tab selected. The 'Modulo Scale:' input field contains the value '4294967295' and is highlighted with a red box. Below the input field are three buttons: 'Download', 'Upload', and 'Calculate'.


2. Axis Drive: Setup the drive as shown:

Sercos tab



3. Axis Controller: Setup the controller as shown:

NC-Controller tab



4. You're now ready to activate the configuration of the PLC and to enable and move the axis in the Online tab of the NC axis.

12.4 Encoder Parameter Examples for Linear and Rotary Motors

12.4.1 Linear Motors PS01 / PS10

The internal position resolution of the LinMot drive is 0.1um for linear motors.

Therefor the following parameters must be set accordingly:

- *Scaling Factor Numerator* must be set to **0.0001** (=1mm / 10'000 Increments)
- *Scaling Factor Denominator* is left to **1.0**

General	NC-Encoder	Parameter	Sercos	Time Compensation	Online
Parameter					Offline Value
-	Encoder Evaluation:				
	Invert Encoder Counting Direction		FALSE		
	Scaling Factor Numerator		0.0001		
	Scaling Factor Denominator (default: 1.0)		1.0		
	Position Bias		0.0		
	Modulo Factor (e.g. 360.0°)		360.0		
	Tolerance Window for Modulo Start		0.0		
	Encoder Mask (maximum encoder value)		0xFFFFFFFF		
	Encoder Sub Mask (absolute range maximum value)		0x000FFFFF		
	Reference System		'INCREMENTAL'		

12.4.2 Rotary Motors RS01 & RS02

The LinMot RS01 motors (rotary part of LinMot PR01 & PR02 linear rotary motors) have a single turn absolute encoder and by default 360'000 Ticks (Increments) per motor revolution.

Therefor the following parameters must be set accordingly:

- *Scaling Factor Numerator* must be set to **0.001** (=360° / 360'000 Increments)
- *Scaling Factor Denominator* is left to **1.0**

General	NC-Encoder	Parameter	Sercos	Time Compensation	Online
Parameter					Offline Value
-	Encoder Evaluation:				
	Invert Encoder Counting Direction		FALSE		
	Scaling Factor Numerator		0.001		
	Scaling Factor Denominator (default: 1.0)		1.0		
	Position Bias		0.0		
	Modulo Factor (e.g. 360.0°)		360.0		
	Tolerance Window for Modulo Start		0.0		
	Encoder Mask (maximum encoder value)		0xFFFFFFFF		
	Encoder Sub Mask (absolute range maximum value)		0x00057E40		
	Reference System		'ABSOLUTE SINGLETURN RANGE (with single overflow)'		

12.4.3 Rotary Motors EC02

The LinMot EC02 motors have a single turn absolute encoder and by default 524'288 (2¹⁹) Ticks (Increments) per motor revolution.

Therefor the following parameters must be set accordingly:

- *Scaling Factor Numerator* must be set to **0.006866455078125**
(=360° / 524'288 Increments * 10)
- *Scaling Factor Denominator* is set to **10.0** (=1.0 * 10)

Factor 10 is required to have the full resolution in the *Scaling Factor Numerator*

General	NC-Encoder	Parameter	Sercos	Time Compensation	Online
-	Parameter				Offline Value
-	Encoder Evaluation:				
	Invert Encoder Counting Direction				FALSE
	Scaling Factor Numerator	0.006866455078125			
	Scaling Factor Denominator (default: 1.0)	10.0			
	Position Bias	0.0			
	Modulo Factor (e.g. 360.0°)	360.0			
	Tolerance Window for Modulo Start	0.0			
	Encoder Mask (maximum encoder value)	0xFFFFFFFF			
	Encoder Sub Mask (absolute range maximum value)	0x00080000			
	Reference System	'ABSOLUTE SINGLETURN RANGE (with single overflow)'			


12.4.4 Other motors

For other motors the principle is the same to calculate the Numerator, Denominator and other encoder parameters.

12.5 Homing

To home the axis, the drive-controlled homing procedure command (IDN S-0-0148) can be used.

The example project (see chapter 12.1 Overview) contains a function block (LM_SercosHoming) to do the drive-controlled homing.



The screenshot shows the TwinCAT 3 Solution Explorer with the project 'LM_SoE_Demo_TC3' open. In the 'Programs' folder under 'Axes (PRG)', the 'LM_SercosHoming (FB)' file is selected and highlighted with a red box. The code editor on the right displays the following program:

```

PROGRAM Axes
VAR
    iLoopAxisNr : INT; (*Loop counter*)

    fbHomeAxis : ARRAY[1..MAX_AXES] OF LM_SercosHoming;
    fbMC_Power : ARRAY[1..MAX_AXES] OF MC_Power;
    fbMC_Reset : ARRAY[1..MAX_AXES] OF MC_Reset;
    fbMC_Jog : ARRAY[1..MAX_AXES] OF MC_Jog;
    fbMC_MoveAbsolute: ARRAY[1..MAX_AXES] OF MC_MoveAbsolute;
    fbMC_MoveAbsoluteCycle: ARRAY[1..MAX_AXES] OF MC_MoveAbsolute;

    fbDrvReset: ARRAY[1..MAX_AXES] OF FB_SoEReset;
END_VAR

(* Call Homing function block (procedure command S-0-0148, drive based homing)
=====
*)
IF bNC_Home[iLoopAxisNr] AND Axis_Ref[iLoopAxisNr].Status.Operational THEN (* A
    fbHomeAxis[iLoopAxisNr].Execute := TRUE;
END_IF;

fbHomeAxis[iLoopAxisNr](
    Execute      := ,
    HomePosition := rNC_HomePos[iLoopAxisNr],
    Axis         := Axis_Ref[iLoopAxisNr],
);

IF fbHomeAxis[iLoopAxisNr].Done OR fbHomeAxis[iLoopAxisNr].Error THEN
    fbHomeAxis[iLoopAxisNr](Execute := FALSE, Axis := Axis_Ref[iLoopAxisNr]);
    bNC_Home[iLoopAxisNr] := FALSE;
END_IF;

```


Inputs of the function block:

HomePosition	Position the NC axis actual position is set to after homing is done
Axis	Axis reference of the NC axis

The LM_SercosHoming is using the function block *FB_GetAxisAMsAddr* which is part of the Beckhoff library *Tc2_NC (TwinCAT 3) / TcNC (TwinCAT 2)*.


12.6 Visualization

The example project contains a visualization to control the NC axis (including the mentioned homing function block in the chapter before):



12.7 Drive Reset

To acknowledge an error of a SoE drive the function block *FB_SoEReset* must be used on TwinCAT systems. This function block is part of the Beckhoff library *Tc2_NcDrive* (TwinCAT 3) / *TcMC2Drive* (TwinCAT 2).



Note:

Use FB_SoEReset from Beckhoff to reset drive errors.

12.8 Asynchronous Parameter Access

Parameters of the LinMot drive can be accessed using the Beckhoff function block *FB_EcSoeRead* and *FB_EcSoeWrite* which are part of the *Tc2_EtherCAT (TwinCAT 3) / EtherCAT (TwinCAT 2)* library.

More information about this function blocks can be found in the Beckhoff Information System:
<http://infosys.beckhoff.com> (search for *FB_EcSoeRead & FB_EcSoeWrite*)

Example calls of this function blocks can be found in the example project (see chapter 12.1)

```
MAIN      ParameterAccess  X Library Manager  Axes   Main
1  PROGRAM ParameterAccess
2  VAR
3      iLoopAxisNr :INT; (*Loop counter*)
4
5      SoERead     :ARRAY[1..MAX_AXES] OF FB_EcSoERead;
6      SoEWrite    :ARRAY[1..MAX_AXES] OF FB_EcSoEWrite;
7
8      UPID        :ARRAY[1..MAX_AXES] OF WORD;
9
10     DataIN      :ARRAY[1..MAX_AXES] OF DINT;
11     DataOUT     :ARRAY[1..MAX_AXES] OF DINT;
12 END VAR

13
14 FOR iLoopAxisNr := 1 TO MAX_AXES DO (*Call the following function blocks per axis*)
15
16     SoERead[iLoopAxisNr]{
17         sNetId:=F_CreateAmsNetId(g_aAmsAddr[iLoopAxisNr].netId),
18         nSlaveAddr:=g_aAmsAddr[iLoopAxisNr].port,
19         nIdn:= 16#8000 + UPID[iLoopAxisNr],
20         nElement:= 16#40, (*Value*)
21         nDriveNo:= DWORD_TO_BYTE(Axis_Ref[iLoopAxisNr].NcToPlc.AxisId),
22         bCommand:= ,
23         pDstBuf:= ADR(DataIN[iLoopAxisNr]),
24         cbBufLen:= SIZEOF(DataIN[iLoopAxisNr]),
25         bExecute:= ,
26         tTimeout:= ,
27         bBusy=> ,
28         bError=> ,
29         nErrId=> );
30
31     SoEWrite[iLoopAxisNr]{
32         sNetId:=F_CreateAmsNetId(g_aAmsAddr[iLoopAxisNr].netId),
33         nSlaveAddr:=g_aAmsAddr[iLoopAxisNr].port,
34         nIdn:=16#8000 + UPID[iLoopAxisNr],
35         nElement:=16#40, (*Value*)
36         nDriveNo:= DWORD_TO_BYTE(Axis_Ref[iLoopAxisNr].NcToPlc.AxisId),
37         bCommand:= ,
38         pSrcBuf:= ADR(DataOUT[iLoopAxisNr]),
39         cbBufLen:= SIZEOF(DataOUT[iLoopAxisNr]),
40         bExecute:= ,
41         tTimeout:= ,
42         bBusy=> ,
43         bError=> ,
44         nErrId=> );
```

sNetID, nSlaveAddr: AmsNetID & port of the drive.

These can be read using the function block *FB_GetAxisAmsAddr* which is part of the Beckhoff library *Tc2_NC* (*TwinCAT 3*) / *TcNC* (*TwinCAT 2*).

nDriveNo: NC axis ID

nldn: Parameter address to be accessed = **16#8000 + UPID**
(E.g., Maximal Current (UPID 16#13A6) ► **nldn** = 16#8000 + 16#13A6 = 16#93A6)

nElement: Element of the parameter to be accessed. The following values are allowed

Value	Description
0x01	Data Status
0x02	Name (read only)
0x04	Attribute
0x08	Unit
0x10	Minimum
0x20	Maximum
0x40	Value
0x80	Default

Reading and writing the value (nElement := 16#40) accesses the **RAM** value of the UPID.
Writing to the default value (nElement := 16#80) accesses the **ROM** value of the UPID.

pDstBuf, pSrcBuf: Address to the variable containing the value to be read / written (must be of size 4 Bytes!)

cbBufLen: Size of the variable of the value to be read / written (must be of size 4 Bytes!)



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the life-time of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus* ([0185-1074](#)) user manual
> see chapter Documentation / User Manuals



Note:

Use *FB_EcSoeRead* and *FB_EcSoeWrite* from Beckhoff to access drive parameters.



Advanced: Stop / Start MC_SW and reboot drive

The parameter UPID 2080 allows:

1. stopping the MC_SW for flash access or to setup the drive from the PLC
2. starting the MS_SW after flash access and to load changed ROM values to RAM
3. reset the drive.

Write to RAM (nElement 0x40) and value 0 -> Stop MC_SW

Write to RAM (nElement 0x40) and value 1 -> Start MC_SW

Write to ROM (nElement 0x80) and value 1 -> Reboot drive



For every access (read or write) the length of the variable connected to pDstBuf/pSrcBuf must be of **size 4 Bytes** (e.g., datatypes DWORD, DINT, UDINT).

If you access a parameter/variable of a different size (e.g., INT, SINT, ...) then make a typecast afterwards.

12.9 Add Additional Parameters or Variables to the Process Data (MDT 1 / AT 1)

It is possible to add additional parameters or variables of the drive to PDO for cyclical write or read access.

Example 1: Read the *Demand Current (UPID 1B93h)* of the drive cyclically by adding it to AT 1:

The screenshot shows the LinMot-Talk 6.5 interface. On the left, the Project tree is expanded to show 'C1250 SE XC 1S 000 offline (USER)'. Under 'Variables', the 'Demand Current' entry is highlighted with a red border. On the right, a table lists various process data entries with columns for Name, Value, RawData, UPID, Type, Scale, and Offset. The 'Demand Current' entry has the following values: Value "...", RawData "1B93h", UPID "1B93h", Type "SInt32", Scale "0.001 A", and Offset "0 A".

Name: Demand Current

UPID: 1B93h

Type: SInt32 = DINT

Scale: 0.001 A

1. In the Process Data select AT 1 from the PDO List.
2. Right-click on the empty line where only an offset is shown
3. In the *Edit PDO Entry* window enter the name, the UPID as *Index* and set the *Data Type* to DINT (as the Demand Current is of type SINT32)
4. Click OK to finish

The screenshot shows the Beckhoff TwinCAT 2/3 IDE. The Solution Explorer on the left shows the project 'LM_SoE_Demo_TC3'. The main window is titled 'LM_SoE_Demo_TC3'. It has tabs for General, EtherCAT, DC, Process Data, and Startup. The 'DC' tab is selected. The 'Sync Manager' pane shows a list of Sync Manager entries. The 'PDO List' pane shows a table of PDO assignments. The 'PDO Content (S-0-0016)' pane shows two entries: S-0-0051 (Index: 4.0, Offs: 2.0, Name: Position feedback value 1, Type: DINT, Default (hex): 7059) and S-0-0189 (Index: 4.0, Offs: 6.0, Name: Following distance, Type: DINT, Default (hex): 10.0). A red arrow points from the 'Edit Pdo Entry' dialog at the bottom to the 'Process Data' tab. Another red arrow points from the 'Right-click > Insert...' button in the PDO Content table to the 'Edit Pdo Entry' dialog. The 'Edit Pdo Entry' dialog is open, showing fields for Name (Demand Current), Index (hex) (1B93), Sub Index (0), Data Type (DINT), and Bit Length (32).

Example 2: Write the Maximal Current (UPID 13A6h) of the drive cyclically by adding it to MDT 1:

LinMot-Talk 6.5

File Search Drive Services Options Window Tools Manuals Help

C1250 SE XC 1S 000 offline (USER)

Project C1250 SE XC 1S 000 offline (USER)

- Control Panel
- Parameters
 - OS
 - Motion Control SW
 - Drive Configuration
 - Motor Configuration
 - State Machine Setup
 - Motion Interface
 - Position Controller
 - Feedback Selection
 - Ctrl Par Set Selection
 - Control Parameter Set A
 - Control Parameter Set B
 - Advanced Settings
 - Current Controller
 - Errors & Warnings

25 A


Name	Value	Raw Data	UPID	Type	Scale	Offset
FF Constant Force	0 A	00000000h	139Ch	SInt32	0.001 A	0 A
FF Friction	0 A	00000000h	139Dh	SInt32	0.001 A	0 A
FF Spring Compensation	0 A/m	0000h	139Eh	SInt16	1 A/m	0 A/m
FF Damping	0 A/(m/s)	0000h	139Fh	SInt16	0.01 A/(m/s)	0 A/(m/s)
FF Acceleration	0 A/(m/s^2)	0000h	13A0h	UInt16	0.001 A/(m...)	0 A/(m/s^2)
Spring Zero Position	0 mm	00000000h	13A1h	SInt32	0.0001 mm	0 mm
P Gain	1.5 A/mm	000Fh	13A2h	UInt16	0.1 A/mm	0 A/mm
D Gain	3 A/(m/s)	001Eh	13A3h	UInt16	0.1 A/(m/s)	0 A/(m/s)
D Filter Time	0 us	0000h	13A8h	UInt16	1 us	0 us
I Gain	0 A/(mm*s)	0000h	13A4h	UInt16	0.1 A/(mm*s)	0 A/(mm*s)
Integrator Limit	25 A	000061A8h	13A5h	SInt32	0.001 A	0 A
Maximal Current	25 A	000061A8h	13A6h	SInt32	0.001 A	0 A
Maximal Current Positive	25 A	000061A8h	13FCh	SInt32	0.001 A	0 A
Maximal Current Negative	25 A	000061A8h	13FDh	SInt32	0.001 A	0 A

Name: Maximal Current**UPID:** 13A6h**Type:** SInt32 = DINT**Scale:** 0.001 A

1. In the Process Data select *MDT 1* from the PDO List.
2. Right-click on the empty line where only an offset is shown
3. In the *Edit PDO Entry* window enter the name, the UPID as *Index* and set the *Data Type* to DINT (as the Maximal Current is of type SINT32)
4. Click OK to finish

The screenshot shows the Beckhoff TwinCAT 2/3 software interface for configuring EtherCAT PDOs. The left pane shows the Solution Explorer with the project structure. The right pane is titled "LM_SoE_Demo_TC3" and contains tabs for General, EtherCAT, DC, Process Data, and Startup. The "Process Data" tab is selected. It displays the Sync Manager, PDO List, PDO Assignment (SM 2), and PDO Content (S-0-0024). The "Edit Pdo Entry" dialog is open, showing fields for Name (Maximal Current), Index (hex) (13A6), Sub Index (0), Data Type (DINT), and Bit Length (32). Red arrows point from the "Index (hex)" field in the dialog to the "Index" column in the PDO Content table, and from the "Data Type" field in the dialog to the "Type" column in the same table. A red box highlights the "Index (hex)" field in the dialog, and another red box highlights the "Right-click > Insert..." button in the PDO Content table.

Now you can see both added parameters in the solution tree and link them:



13 Drive Profile: Schneider Electric PacDrive 3, FSP_DRIVE

13.1 Overview

This chapter shows how a LinMot drive with SERCOS (FSP_DRIVE) interface (e.g., C1250-SC-XC-1S) can be integrated and setup in a Schneider Electric PacDrive environment.

Download:

An example project can be downloaded from (The example is based on the QuickMotionProgramming example from Schneider Electric):

http://download.linmot.com/plc_lib/examples/Schneider (named *LMC_LinMot_AxisModule_Example_...*)

Components used:

- LinMot C1250-SC-XC-0S-000 (article number 0150-1887) with firmware 6.8 Build 20191003
- LMC 400C with firmware V01.56.21.13
- SoMachine Motion Logic Builder V4.41 (V4.4 SP1)




Image Source: <http://www.schneider-electric.com/>

Sercos is an open IEC standard universal bus for Ethernet-based real-time communication.

For further information on sercos please visit:

<http://www.sercos.org/>

13.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:

<http://www.linmot.com/download/linmot-talk-drive-configuration/>

13.2.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select a homing mode in the Motor Wizard if you want to use the drive based homing as described in chapter 13.4.2 (e.g. *Mechanical Stop Negative Search*):



If the homing should be done as shown in chapter 13.4.1 *Homing using the Schneider template (FB_Home)*, then choose "No Drive Homing".





See Appendix I: Basic Position Control Loop Tuning

13.2.2 Sercos Connection

The drive is connected to the sercos network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-SC-UC drive. On all other LinMot drives supporting sercos the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



13.2.3 Sercos Address

The sercos address is set via the two ID-switches S1 and S2, where S1 sets the high digit and S2 the low digit. The address can have a value between 1 (01h) and 255 (FFh).



Set the sercos address by S1 & S2

S1 - S2	Address Selectors		
E1100 E1200 V1	E1200 V2 E1400 C1x00	S1 (5 .. 8)	Bus ID High (0 ... F). Bit 5 is LSB, bit 8 MSB.
		S2 (1 .. 4)	Bus ID High (0 ... F). Bit 1 is LSB, bit 4 MSB.

**Note:**


The sercos address has no use with some identification modes like topology-based addressing. If both address selectors are set to 0, the topology address is used as the sercos address when topology-based addressing is configured in the PLC.

13.3 PLC Setup**13.3.1 General Device Properties**


Device Properties	Value
sercos generation	Third generation
sercos version	SC: sercos III V1.1.2; MI: sercos III V1.3.2
Hot-Plug support	only on MI-devices
SERCON100 image version	V2.11 (SC only)
Supported profiles and telegram types	E1x50-SC-xx-xx, C1x50-SC-xx-xx
	C1x50-MI-xx-xx, C1251-MI-XC-2S
	B8050-ML-SC, MB8050-ML-SC
Minimal sercos cycle time	250 µs
Vendor Device ID	'0150-1764' (E1250-SC-UC) '0150-1785' (E1450-SC-QN-0S) '0150-2357' (E1450-SC-QN-1S) '0150-1881' (B8050-ML-SC) '0150-2032' (MB8050-ML-SC) '0150-1887' (C1250-SC-XC-0S-000, C1250-SC-XC-0S-C00) '0150-2349' (C1250-SC-XC-1S-000, C1250-SC-XC-1S-C00) '0150-30149' (C1250-MI-XC-0S-000, C1250-MI-XC-0S-C00) '0150-30169' (C1250-MI-XC-1S-000, C1250-MI-XC-1S-C00) '0150-30009' (C1251-MI-XC-2S-000, C1251-MI-XC-2S-C00)
Vendor Code	342 (0156h)

13.3.2 Add the LinMot Drive to the Sercos

Right-click on SERCOSIII (Sercos Master) and select Add Device:



Insert a name (e.g. DRV_LMAxis1), select SERCOS Drive and click on "Add Device":



Double-click on the new added device to open the configuration.

13.3.3 Device Configuration

13.3.3.1 Identification

All identification modes are support (SerialNumberController (0), SerialNumberMotor (1), TopologyAddress (2), ApplicationTyp (3) and SercosAddress (4)).

Following an example setup where the device is identified by *TopologyAddress* (2)

ConfiguredTopologyAddress: 1 (As it is the first device in the ring in this project)

VendorCode: 342

VendorDeviceID: '0150-2349' (LinMot C1250-SC-XC-1S-000, for others check chapter 13.3.1)

Parameter	Type	Value	Default Value
Identification			
Name	STRING(40)	"	"
WorkingMode	Enumeration of DINT	real / 1	virtual / 0
WorkingState	Enumeration of DINT	virtual / 0	virtual / 0
IdentifyDevice	Enumeration of BOOL	off / 0	off / 0
IdentificationMode	Enumeration of DINT	TopologyAddress / 2	TopologyAddress / 2
ConfiguredTopologyAddress	UINT(1..512)	1	1
TopologyAddress	UINT		
ConfiguredApplicationType	STRING(40)	"	"
ApplicationType	STRING(40)	"	"
ConfiguredSercosAddress	UINT(1..512)	100	100
SercosAddress	UINT(1..299)	1	1
ConfiguredSerialNumber	STRING(80)	"	"
ConfiguredSerialNumberMotor	STRING(20)	"	"
ConfiguredVendorCode	WORD	342	0
VendorCode	WORD		
ConfiguredVendorDeviceId	STRING(80)	'0150-2349'	'SercDrv'
VendorDeviceId	STRING(80)	"	"

13.3.3.2 Motor/Mechanic using a LinMot linear motor

As unit millimeter [mm] is used.

The MaxRPM parameter limits the maximal possible velocity to around 1m/s when using 1.0 as *FeedConstant*.

Therefore, the *FeedConstant* is set to **1'000** and the *FeedbackResolution* to **10'000'000**.


Parameter	Value	Unit
GearIn	1	-
GearOut	1	-
Direction	right	-
FeedConstant	1'000	[Units/Revolution]
FeedbackResolution	10'000'000	[Increments]
MaxRPM	See below	[1/min]
ModuloValue	0	[Increments]
J total	Leave on default or set as required	[kg*cm^2]
Torque Constant	Leave on default or set as required	[0,001*Nm/A]

**MaxRPM:**

Max. Speed (@72VDC, see motor datasheet): e.g., 5.2 [m/s] * 60 => 312 [m/min]
Input value for MaxRPM: 312 [m/min]

13.3.3.3 Motor/Mechanic using a rotary motor

As unit degree [°] is used. As rotary motor, the *FeedbackResolution* depends on the settings done within the LinMot-Talk Motor Wizard. It must be set to the same value as Ticks per revolution in the Motor Wizard.



For a LinMot **RS01** (rotary part of the linear rotary motor PR01) the *FeedbackResolution* is **360'000**.
For a LinMot **EC02** the *FeedbackResolution* is **524'288**.

If the motor should be used as modulo axis (1 revolution) the *ModuloValue* must be set accordingly (same as *FeedbackResolution*).

Example for a LinMot **RS01** motor as modulo axis without gearbox:

Parameter	Value	Unit
GearIn	1	-
GearOut	1	-
Direction	right	-
FeedConstant	360.0	[Units/Revolution]
FeedbackResolution	360'000	[Increments]
MaxRPM	Take from motor datasheet	[1/min]
ModuloValue	0	[Increments]
J total	Leave on default or set as required	[kg*cm^2]
Torque Constant	Leave on default or set as required	[0,001*Nm/A]



Attention:

From drive firmware 6.9 it is possible to use the motor in modulo mode. The modulo mode must be enabled and setup in drive. Make sure that the *ModuloValue* in the PLC is set to the same value as the RawData of *Maximal Position* in the drive. E.g.: 360'000.

Name	Value	Raw Data
Minimal Position	0 °	0
Maximal Position	359.999664723873 °	360000
Start-up Position	0 °	0
Modulo Mode	On	1

13.3.3.4 Realtime channel

Following the recommended configuration of the real-time channel.

If the Realtime channel is configured with a list of IDNs the LinMot StatusWord, StateVar, the velocity feedback (S-0-0040), torque/force feedback (S-0-0084) and the effective current (S-0-0389) can also be mapped directly as part of the real-time process data.

In this example in the MDT also the **Bipolar torque limit** value (S-0-0092) is mapped. It allows to limit the maximum force/torque in percent (scale = 0.1%, > value = 0 to 1000).

Parameter	Value
TelegramType	7
PrimaryOperationMode	3
ConfigurationListAT	'S-0-0051.0.0;P-0-0100.0.0;P-0-0101.0.0;S-0-0040.0.0;S-0-0084.0.0;S-0-0389.0.0'
ConfigurationListATLength	9
PositionFeedbackValueOffset	0
ConfigurationListMDT	'S-0-0047.0.0;S-0-0092.0.0'
ConfigurationListMDTLength	3
PositionCommandValueOffset	0

Echtzeitkanal			
TelegramType	UINT(0..7)	7	
PrimaryOperationMode	UINT	3	
ConfigurationListAT	STRING(254)	'S-0-0051.0.0;P-0-0100.0;P-0-0101.0.0;S-0-0040.0.0;S-0-0084.0.0;S-0-0389.0.0'	
ConfigurationListATLength	UINT(0..750)	9	
PositionFeedbackValueOffset	UINT(0..748)	0	
ConfigurationListMDT	STRING(254)	'S-0-0047.0.0;S-0-0092.0.0'	
ConfigurationListMDTLength	UINT(0..750)	3	
PositionCommandValueOffset	UINT(0..748)	0	



Attention:

Attention!
The order of the list's objects and its content must be exactly as stated in the table above to work properly.

Make sure the Bipolar torque limit value is not 0 or the motor cannot move.



Note:

Writing to the MDT from the PLC program (e.g., to write the Bipolar torque limit) could be done as follows:

13.4 Homing (Linear Motors)

There are several possible ways to home the axis. If the template(s) of Schneider is used the user may want to use the integrated FB_Home function block (see chapter 13.4.1). An alternative is using the drive-based homing as shown in chapter 13.4.2.

13.4.1 Homing using the Schneider template (FB_Home)

As homing mode *NegDirectionPosEdgeSensor* is used in this example project. As sensor the tracking deviation is evaluated. The axis moves in negative direction until it reaches the mechanical stop, and the tracking deviation increases. At a certain value this triggers *i_xSensor*.

13.4.1.1 Setup

Set the homing mode:

```
55 AXM.FC_SetHomeMode( i_etModeVirtualDrive      := PDL.ET_HomeMode.SetPosAxisAndLogEncoderPosition,
56                      i_etModeRealdrive       := PDL.ET_HomeMode.NegDirectionPosEdgeSensor,
57                      iq_stAxisModuleIf      := stAxisInterface,
58                      q_etDiag                => etDiag,
59                      q_etDiagExt              => etDiagExtAXM,
60                      q_smMsg                 => );
```

Setup the homing mode Sensor:

```
72 (* Possible modes for homing mode Sensor:
73    PDL.ET_HomeMode.PosDirectionPosEdgeSensor
74    PDL.ET_HomeMode.NegDirectionPosEdgeSensor
75    PDL.ET_HomeMode.NegDirectionNegEdgeSensor
76    PDL.ET_HomeMode.PosDirectionNegEdgeSensor
77 *)
78 stAxisInterface.stHome.stSensor.i_lrHomePosition      := 0.0;          (* Position at the end of homing in units *)
79 stAxisInterface.stHome.stSensor.i_lrVel               := 5.0;           (* Homing ceiling velocity in units/s *)
80 stAxisInterface.stHome.stSensor.i_lrAcc               := 1000.0;         (* Homing acceleration in units/s^2 *)
81 stAxisInterface.stHome.stSensor.i_lrDec               := 1000.0;         (* Homing deceleration in units/s^2 *)
82 stAxisInterface.stHome.stSensor.i_lrJerk              := 10000.0;        (* Homing jerk in units/s^3 *)
83 stAxisInterface.stHome.stSensor.i_lrOffset             := 10.0;          (* Offset from home signal in units *)
84 stAxisInterface.stHome.stSensor.i_lrMaxTravel         := 720.0;          (* Max. travel for referencing by normal input *)
85 stAxisInterface.stHome.stSensor.i_xRotativeSystem     := FALSE;         (* Rotative system true or false for referencing by norm
86 stAxisInterface.stHome.stSensor.i_xSensor              := FALSE;         (* Input for home signal. Can be a signal from a control
```

Make sure to keep the velocity *i_lrVel* low for best accuracy and set *i_lrOffset* to move away from the mechanical stop afterwards.

In a cyclic task trigger *i_xSensor*. E.g., as follows:

```
38 // XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
39 // Sensor for homing
40 //
41 // Can be used with homing modes:
42 //    PDL.ET_HomeMode.PosDirectionPosEdgeSensor
43 //    PDL.ET_HomeMode.NegDirectionPosEdgeSensor
44 //
45 // Recommended solution:
46 // - set i_xSensor if the tracking deviation reaches a certain level (2mm in this example)
47 // - keep the search velocity (stAxisInterface.stHome.stSensor.i_lrVel) low to get accurate results. Best below 5-10mm/s
48 //
49 // Alternative (probably less accurate):
50 // - If iTorque feedback (in 0.1% of the motors maximal force/torque) is 100% the sensor becomes TRUE
51 // - As limit by default 100% (1000) is used. The user is free to use other limits.
52 // XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
53 //
54 stAxisInterface.stHome.stSensor.i_xSensor := (ABS(DRV_LMAxis1.TrackingDeviation) >= 2); // Trig sensor on tracking deviation level (2mm in this example)
55 //
```

13.4.2 Drive-Based Homing (S-0-0148)

By executing IDN S-0-0148 as a procedure command, the drive-controlled homing is started.

**Attention:**

Executing this command while the drive is not in AxisState 3 (Wait for job) will result in an error.

Use the function block **FB_SercosWriteServiceData!** Using the **FC_SercosWriteServiceData** will interrupt the PLC task until the homing has been completed.

Example sequence that is used in the example project (see chapter 13.1 Overview).

```
VAR
// [Action: Homing_Active]
xHome          : BOOL;
diHomeState     : DINT := 0;
fbHoming       : FB_SercosWriteServiceData;
diBuffer        : DINT := 0; // Value not relevant
etDiag_homing  : GD.ET_Diag;
etDiagExt_homing : PDL.ET_DiagExt;

diResult        : DINT;
diBuffer2       : DINT;
END_VAR

...
100: // Disable Module if active
IF stSubModuleInterface.q_xActive THEN
    stSubModuleInterface.i_xEnable := FALSE;
END_IF
diHomeState:=110;

110: // Check Module disabled and axis ready for enable or enabled(Axis State = 1 or 3)
IF NOT stSubModuleInterface.q_xActive AND (DRV_LMAxis1.AxisState = 1 OR DRV_LMAxis1.AxisState = 3) THEN
    diHomeState:=120;
END_IF

120: // Set Controller Enable and check for Axis State = 3
DRV_LMAxis1.ControllerEnableSet := TRUE;
IF DRV_LMAxis1.AxisState = 3 THEN
    diHomeState:=130;
END_IF

130: // Start homing procedure
fbHoming(
    i_stLogicalAddress:= DRV_LMAxis1.stLogicalAddress,
    i_xPSercosParameter:= FALSE,
    i_dwIDN:= 148, // S-0-0148 drive based homing command
    i_dwIDN_SI:= 0,
    i_dwIDN_SE:= 0,
    i_wType:= 7, // Execute command
    i_pdwData:= ADR(diBuffer),
    i_wMaxDataLen:= SIZEOF(diBuffer)
);
PDL.G_ifAsyncMgr.Start(i_ifAsync:= fbHoming, q_etDiag=> etDiag_homing , q_etDiagExt=> etDiagExt_homing); // Pass job to async manager

IF etDiag_homing <> GD.ET_Diag.Ok THEN
    diHomeState:= 994; // Error Reaction see Online Help for possible diag codes
END_IF

diHomeState := 131;

131: // Check if homing function block has completed
IF fbHoming.xDone := FALSE;
    fbHoming.xDone := FALSE;
    diHomeState:=0;
    xHome := FALSE;
ELSIF fbHoming.q_diResultWrite <> 0 THEN
    diHomeState:=995;
END_IF

...

```

13.5 Parameter Access

Every parameter and variable in a LinMot system has its own UPID (Unique Parameter ID). Every UPID is mapped to its own manufacturer specific IDN to access it via the sercos service channel.

UPIDs are mapped according to the following table:

UPID	IDN (dec)	IDN (hex)
0xHBLB	P-Y-0000.HBdec.LBdec	0xHBLB0000 + (0x00008000 + 0x0000Y000)

HB: High Byte (hexadecimal), HBdec: High Byte (decimal)

LB: Low Byte (hexadecimal), LBdec: Low Byte (decimal)

Y = 0: RAM value of a UPID is accessed

Y = 1: ROM value of a UPID is accessed

Y = 2: RAM and ROM value of a UPID is accessed (only applicable when writing UPIDs)

(Note: Not every UPID has a RAM and a ROM Value)

Example:

Access RAM value (Y=0) of UPID 0x13A6 (Maximal Current of Control Parameter Set A)

UPID = 0x13A6

IDN (dec) = P-0-0000.19.166

IDN (hex) = 0x13A60000 + (0x00008000 + 0x00000000) = 0x13A68000

13.5.1 Supported UPID Functions via IDN Access over the Sercos Service Channel

Use Schneider functions *FC_SercosReadServiceData* & *FC_SercosWriteServiceData* (see Schneider help)

UPID Access	Data Service Type (i_wType)
Read UPID value (RAM or ROM value)	5 (read/write user data)
Write UPID value (RAM and/or ROM value)	5 (read/write user data)
Get minimum value of UPID	3 (read/write min. value)
Get maximum value of UPID	4 (read/write max. value)



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!

More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual

> see chapter Documentation / User Manuals



Advanced:

By writing anything to **IDN P-0-0099 (hex: 16#00008063)** a drive reboot can be performed (e.g., to load and activate written ROM parameters).

Attention: The Sercos line/ring will be interrupted until the drive has completed the reboot.

13.5.2 Read RAM Parameter Example

To read the RAM value of a LinMot parameter the function *FC_SercosReadServiceData* (see Schneider help) can be used.

```
PROGRAM SR_Main
VAR
    bStartReadIDN: BOOL := 0;
    diRetVal: DINT;
    i_stAxisId := DRV_SercDrv.stLogicalAddress;
    wIDN: DWORD := 16#1BF38000; // UPID 1BF3h (Max Read Out Motor Temp, Offset = -50, Scale =
    0.9803...°C)
    dwIDNDataIN: DWORD ; // read data value
    wNumBytetoRead: WORD:= 4; // read 4 bytes of data
    uiReadDataLen: UINT; // actual length of read data
    uiMaxReadDataLen: UINT; // actual maximum length of read data (i.e. max possible length of a string)

END_VAR

...
// ReadIDN
IF bStartReadIDN THEN

    RetVAL:=FC_SercosReadServiceData(
        i_stAxisId,
        wIDN,
        5,
        ADR(dwIDNDataIN),
        wNumBytetoRead,
        uiReadDataLen,
        uiMaxReadDataLen);

    StartReadIDN := 0;

END_IF
...
```

13.5.3 Write RAM Parameter Example

To write the RAM value of a LinMot parameter the function *FC_SercosWriteServiceData* (see Schneider help) can be used.

```
PROGRAM SR_Main
VAR
    bStartWriteIDN: BOOL := 0;
    diRetVal: DINT;
    i_stAxisId := DRV_SercDrv.stLogicalAddress;
    wIDN: DWORD := 16#13A58000; // UPID 13A5h (Integrator Limit)
    dwIDNDataOUT: DWORD := 3000; // Set Integrator Limit to 3A (Scale 0.1 mA)
    wNumBytetoWrite: WORD := 4; // Write 4 bytes of data

END_VAR
...
// WriteIDN
IF bStartWriteIDN THEN // If StartWriteIDN = TRUE parameter will be read

    RetVAL:=FC_SercosWriteServiceData(
        i_stAxisId,
        wIDN,
        5,
        ADR(dwIDNDataOUT),
        wNumBytetoWrite);

    bStartWriteIDN := 0;
END_IF
...
```

13.6 Enable/Disable Drive Warnings

By default, any SERCOS Slave C2D warning (8165) or SERCOS C2Dman specific warning (8166) will cause the PLC to stop the axes. The LinMot drive can generate several warnings *Motor Not Homed*, *Speed Lag Always* and so on.


To avoid this behaviour on the Schneider PLC, these diagnostic messages can be deactivated using `FC_DiagConfigSet2` (see Schneider help for more information).

In the example project (see 13.1 Overview) in the `Init_Action` of the program `SR_MainMaschine` the two diagnostic codes 8165 and 8166 are set to diagnostic class 1:

```
IF (SystemConfiguration.G_ifSercos.State = 4) THEN
    //Warnings, see help
    diResultDiagConfigSet8165 := FC_DiagConfigSet2(i_diDiagCode:= 8165, i_diDiagClass:= 1, i_stLogAddr:= SERCDRV_TYPE, i_diDiagSubClass:= 1);
    diResultDiagConfigSet8166 := FC_DiagConfigSet2(i_diDiagCode:= 8166, i_diDiagClass:= 1, i_stLogAddr:= SERCDRV_TYPE, i_diDiagSubClass:= 1);

    xInitDone := TRUE;
END_IF
```

Otherwise it is also possible to disable warnings on the drive side:



Attention:

Be aware that some of the warnings of a LinMot drive can indicate an upcoming error. So, make sure you have good reasons to disable warnings on the drive, e.g., *Motor Hot Sensor* or *Drive Hot*.

14 Drive Profile: CODESYS SoftMotion, CiA402

14.1 Overview

This chapter shows how a LinMot drive with *DS402 (CoE) / CiA402* interface (e.g., C1250-DS-XC-1S) can be integrated and setup in a CODESYS SoftMotion environment (on a Raspberry Pi 2).

Download:

Example projects can be downloaded from:

http://download.linmot.com/plc_lib/examples/CODESYS_DS (named *LM_DS_Demo_CODESYS_RaspPi...*)

Components used:

- LinMot C1250-DS-XC-1S-000 (article number 0150-2416) with firmware 6.6 Build 20170522
- Raspberry Pi 2, Model B, target system version 3.5.10.20
- CODESYS Control for Raspberry PI 3.5.10.20 Package
- CODESYS V3.5 SP10 Patch 3




Image Source: <http://www.raspberrypi.org/>

EtherCAT is the real-time Ethernet network originally developed by Beckhoff. The LinMot acts as Slave in this network and is implemented with the standard ASIC ET1100 from Beckhoff.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>

14.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:

<http://www.linmot.com/download/linmot-talk-drive-configuration/>

14.2.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select a homing mode in the Motor Wizard as with the DS (DS402 / CiA402) interface a drive-based homing is possible (e.g. *Mechanical Stop Negative Search*):



See Appendix I: Basic Position Control Loop Tuning

14.2.2 XML File

Install the XML file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML\
- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML\ (-MI drives)





XML file names:

NTIL_CiA402_Servos_Vx_xrx.xml	LinMot DS drives SG6-7
NTIL_CiA402_SG5_Servos_Vx_xrx.xml	LinMot DS drives SG5
NTIL_CiA402_Servos_MI_Vx_xrx.xml	LinMot MI drives SG6

14.2.3 EtherCAT Connection

The drive is connected to the EtherCAT network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-DS-UC drive. On all other LinMot drives supporting EtherCAT DS the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



14.3 PLC Setup

14.3.1 EtherCAT Device Description File XML


The EtherCAT device description file (XML) is located by default in the LinMot-Talk installation path:
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML

Install the XML in CODESYS by selecting “Tools > Device Repository”.

14.3.2 Add and setup the LinMot drive


Follow these steps to add the LinMot drive to your CODESYS project.

1. If not already existing add an *EtherCAT Master SoftMotion* by right-click on the PLC and select *Add Device...*
2. Right-Click on the *EtherCAT Master SoftMotion* and select *Scan for Devices...*




In the following window select Copy All Devices to Project

3. Right-Click on the added drive (e.g. C1250_DS_XS_1S...) and select *Add SoftMotion CiA402 Axis*



Select Ok in the following pop up.

4. Move to the tab **Scaling/Mapping** and set 10'000 increments per 1 motor turn




You are now ready to use the axis.

14.3.3 Check EoE settings

On supported drives (C1250-..., C1450-... & E1450-...) please check the EoE (Ethernet over EtherCAT) settings.

You can enable the *Virtual Ethernet Port* and assign an IP to be able to login over EtherCAT into the drive using LinMot-Talk.



Be aware that the PLC must route the requests from LinMot-Talk over Ethernet to the EtherCAT network.

**Note:**

EoE can be used to login into the drive with LinMot-Talk directly over EtherCAT. E.g., to change drive settings or for monitoring and tracing. If not required, this feature can be disabled.

LinMot drives do NOT support the DHCP mode yet. A fix IP must be assigned or the EoE feature must be completely disabled (disable Virtual Ethernet Port).


14.4 Homing

To home the axis using the drive-controlled homing procedure the function block MC_Home (library SM3_Basic) can be used.

Executing this function block will start the homing procedure defined with the Motor Wizard of LinMot-Talk (e.g., Mechanical Stop Negative Search). The Position input of the function block defines the home position of the axis, e.g., the mechanical stop.

14.5 Visualization

In the example project the VISU_NEW_SMC_StartupDrive (SM3_Basic) template is used



14.6 Parameter Access

Parameters can be modified using their UPIDs (Unique Parameter ID) via CoE.
To use a UPID command the function blocks MC_ReadParameter and MC_WriteParameter can be used.

The Sub-Index specifies the command which is performed

SDO Service	Index	SubIndex	Description
Read	2000h+UPID	0x01	Parameter UPID read RAM value
Write	2000h+UPID	0x01	Parameter UPID write RAM value
Read	2000h+UPID	0x02	Parameter UPID read ROM value
Write	2000h+UPID	0x02	Parameter UPID write ROM value
Read	2000h+UPID	0x03	Parameter UPID read minimal value
Read	2000h+UPID	0x04	Parameter UPID read maximal value
Read	2000h+UPID	0x05	Parameter UPID read default value
Write	2000h+UPID	0x06	Parameter UPID write RAM and ROM value
Write	2000h	0x07	Parameter Default OS SW instance
Write	2000h	0x08	Parameter Default MC SW instance
Write	2000h	0x09	Parameter Default Intf SW instance
Write	2000h	0x0A	Parameter Default Appl SW instance
Write	2000h	0x0B	Reset device



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual
> see chapter Documentation / User Manuals

The input *ParameterNumber* of the MC_... function blocks must be of type DINT and contains the data length the index and the subindex.

E.g., *ParameterNumber := -DWORD_TO_DINT(SHL(USINT_TO_DWORD(usiDataLength), 24) + SHL(UINT_TO_DWORD(uiIndex), 8) + usiSubIndex);*

```

1 PROGRAM PLC_PRG
2 VAR
3     _StartUp: SM3_Basic.SMC_StartupDrive;
4
5 //Parameter Access
6 MC_ReadParameter1: MC_Readparameter;
7 MC_WriteParameter1: MC_Writeparameter;
8 usiDataLength: USINT := 4; // Length 4 Bytes
9 uiIndex: UINT; //= 16#2000 + UPID number of the LinMot parameter. E.g. UPID 16#13a6 => Index := 16#2000 + 16#13a6 = 16#33a6
10 usisubIndex: USINT := 1; // 1 = RAM Value, 2 = ROM Value, further information in the drive interface manual
11 END_VAR
12
13 // SM3_Basic StartupDrive
14 _StartUp(Axis:= LinMot);
15
16 // Parameter Access
17 MC_ReadParameter1.ParameterNumber := -DWORD_TO_DINT(SHL(USINT_TO_DWORD(usiDataLength), 24) + SHL(UINT_TO_DWORD(uiIndex), 8) + usisubIndex);
18 MC_WriteParameter1.ParameterNumber := -DWORD_TO_DINT(SHL(USINT_TO_DWORD(usiDataLength), 24) + SHL(UINT_TO_DWORD(uiIndex), 8) + usisubIndex);
19
20 MC_ReadParameter1(Axis:=LinMot);
21 MC_WriteParameter1(Axis:=LinMot);

```


Example:

To write 1A to the RAM value of the parameter Maximal Current:

Name: Maximal Current	DataLength = 4
UPID: 13A6h	Index = 16#2000 + 16#13a6 = 16#33a6
Type: SInt32 = DINT	SubIndex = 1
Scale: 0.001 A	Value = 1A / 0.001A (scale) = 1'000


14.7 Add Additional Parameters or Variables to the Process Data

To be able to modify the Process Data make sure to enable the expert settings:



It is possible to add additional parameters or variables of the drive to the Process data PDO for cyclical write or read access.

Make sure to enable the user defined inputs/outputs PDO if required:



Example 1: Read the Demand Current (UPID 1B93h) of the drive cyclically by adding it to AT 1:

Name	Value	RawData	UPID	Type	Scale	Offset
Demand Current	1B93h	SInt32	0.001 A	0 A

Name: Demand Current**UPID:** 1B93h**Type:** SInt32 = DINT**Scale:** 0.001 A

1. In the Expert Process Data select *User Defined Inputs* from the PDO List.
2. Press the *Insert* button
3. In the *Select Item From Object Dictionary* window enter the name, the UPID as *Index* and set the *Datatype* to DINT (as the Demand Current is of type SINT32)
4. Click OK to finish

SM	Size	Type
0	0	Mailbox Out
1	0	Mailbox In
2	16	Outputs
3	16	Inputs


Index	Size	Name	Flags	SM
16#1602	8.0	Cyclic PositionMode	F	
16#1603	12.0	CyclicPosition VelocityMode	F	2
16#1604	14.0	Cyclic Position Velocity Mode	F	
16#1606	6.0	Cyclic Torque Mode	F	
16#1620	4.0	User Defined Outputs		2
16#1708	8.0	ConfigModule	F	
16#1710	4.0	Max Current Set A	F	
16#1A02	16.0	Cyclic Mode Inputs	F	3
16#1A20	0.0	User Defined Inputs		

Index:Subindex	Name	Flags	Type	Default
16#6040:16#00	Controlword	RW	UINT	
16#6041:16#00	Statusword	RO	UINT	
16#6060:16#00	Mode of Operation	RW	USINT	
16#6061:16#00	Mode of Operation display	RO	USINT	
16#6062:16#00	Position demand value	RW	UDINT	
16#6064:16#00	Position actual value (units)	RO	UDINT	
16#607A:16#00	Target position	RW	UDINT	
16#607C:16#00	Home offset	RW	UDINT	
16#6098:16#00	Homing method	RW	USINT	
16#609A:16#00	Homing acceleration	RW	UDINT	
16#60FC:16#00	Position demand internal value	RW	UDINT	
16#60FF:16#00	Target velocity	RW	UDINT	

Select Item from Object Directory

Name	Demand Current
Index: 16#	1B93
SubIndex: 16#	0
Datatype:	DINT

Example 2: Write the *Maximal Current (UPID 13A6h)* of the drive cyclically by adding it to the process data:




Name: Maximal Current

UPID: 13A6h

Type: SInt32 = DINT

Scale: 0.001 A

1. In the Expert Process Data select *User Defined Outputs* from the PDO List.
2. Click the *Insert* button
3. In the *Select Item From Object Dictionary* window enter the name, the UPID as *Index* and set the *Datatype* to DINT (as the Maximal Current is of type SINT32)
4. Click OK to finish



15 Drive Profile: B&R NC Motion, CiA402

15.1 Overview

This chapter shows how a LinMot drive with *Powerlink* interface (e.g., C1250-PL-XC-1S) can be integrated and setup in a B&R environment as DS402 motion axis (CiA402).

Download:

The demo project can be downloaded from:

http://download.linmot.com/plc_lib/examples/BR/DS402 (named *LM_DS402_Demo_AS4...*)

Components used:

- LinMot C1250-PL-XC-1S-000 (article number 0150-1885)
Firmware 6.10 Build 20210521
- B&R X20CP1584 (1.9.0.0)
- Automation Studio V 4.9.2.46 SP#, Automation Runtime C4.90, mapp Motion **5.12.3**



Attention:

Drive firmware **6.10 Build 20210521 or later** is required to use the DS402 / CiA402 functionality



In the *B&R Help Explorer* check chapter **McDS402Ax** for more details about the DS402 / CiA402 integration of 3rd party drives.

Press Ctrl + G to open by Guid: **5935c8d1-cc4a-43f2-aead-783ff4f9f6fc**




Image Source: <http://www.br-automation.com/>

The LinMot POWERLINK devices are Ethernet POWERLINK CNs (Controlled Nodes) with the following parameters (according to EPSG-DS-301-V1.1.0):

Device Properties	Value
Minimal POWERLINK cycle time	250 µs
Size of isochronous transmit buffer (maximal size of isochronous frames)	64 Byte
Size of isochronous receive buffer (maximal size of isochronous frames)	64 Byte
Overall buffer size available for isochronous data	128 Byte
PReq to PRes latency (CN isochronous reaction time)	~ 1 µs
SoA to ASnd latency (CN asynchronous reaction time)	~ 1 µs
Maximum asynchronous MTU	300 Byte
Ability to support multiplexed isochronous access	No
Asynchronous SDO transfer method (UDP/IP and/or POWERLINK ASnd)	POWERLINK ASnd only

For further information on Ethernet POWERLINK please visit: <http://www.ethernet-powerlink.org>

15.2 Preconditions to use DS402 / CiA402

- Only SG6 devices are supported (C1250, C1251, C1450 & E1450)
- Drive firmware must be >= 6.10 Build 20210521
- Use of "00000156_xxxxxPL_DS402.xdd" as device description file when configuring the drive in the PLC

**Attention:**

After adding the axes, it is recommended to rebuild the project and to **restart both the PLC and drives** to have a proper start-up. Ignoring this may prevent being able to power on the axis.

15.3 Supported operating modes

- | | |
|--|-------|
| • Mode 1: Profile Position Mode | (pp) |
| • Mode 3: Profile Velocity Mode | (pv) |
| • Mode 6: Homing Mode | (hm) |
| • Mode 7: Interpolated Position Mode | (ip) |
| • Mode 8: Cyclic synchronous position mode | (csp) |
| • Mode 9: Cyclic synchronous velocity mode | (csv) |

15.4 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

15.4.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select a homing mode in the Motor Wizard if you want to use the drive-based homing as described in chapter 15.7 Homing



See Appendix I: Basic Position Control Loop Tuning

15.4.2 XDD File

Install the XDD file that is part of the LinMot-Talk software/firmware you are using.
The most recent device files are always part of the newest LinMot-Talk software.


It is located by default:

- Powerlink: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Powerlink\XDD\AS4
- Powerlink: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Powerlink_Nx\XDD\AS4 (-MI drives)

e.g., 00000156_C1250PL_DS402.xdd

15.4.3 Powerlink Connection

The drive is connected to the Powerlink network using the X17 (IN) & X18 (OUT) connectors.
The below pictures show the ports of an E1250-PL-UC drive. On all other LinMot drives supporting Powerlink
the ports are named the same (X17 & X18), but they may be placed differently on the drive housing.



15.4.4 Node ID

The Node ID of the LinMot drive is set using the hardware address selectors.

S1 - S2		Address Selectors	
E1100	E1200 V2	S1 (5 .. 8)	Bus ID High (0 ... F). Bit 5 is LSB, bit 8 MSB.
E1200 V1	E1400 C1x00	S2 (1 .. 4)	Bus ID High (0 ... F). Bit 1 is LSB, bit 4 MSB.


E.g.: Node ID 18 dec = 12 hex = 0001 0010 bin

=> S1 = 1 hex = 0001 bin (Dip Switch 5 = ON), S2 = 2 hex = 0010 bin (Dip Switch 2 = ON)

15.5 Automation Studio Physical View

15.5.1 Add the LinMot drive to the Powerlink network

Install the XDD file(s) using *Tools > Import Fieldbus Device...* in Automation Studio.




The required XDD-file can be found in the following folder (default):

C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\POWERLINK\XDD\AS4
C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\Powerlink_Nx\XDD\AS4

In the Hardware Catalog search for the LinMot drive (e.g., C1250...) and drag&drop it onto the Powerlink interface (PLK).

Alternatively select the Product Group *3rd Party Devices* > all installed LinMot drives are shown.




Set the Node ID according to your requirements.


15.5.2 Configuration

In the configuration of the LinMot slave module (right-click on device > Configuration) the following setting must be done. Attention: The “Axis reference” can only be set when the axis is already defined (see 15.6.1)

15.5.2.1 Linear Axis (10'000 increments per revolution):



In case the dynamic requirements are very high the following encoder settings will help



15.5.2.2 Rotary Axis PR01 or PR02 (360'000 increments per revolution):

[-] C1250-PL_Rot	
[-] Allgemein	
[-] Modulüberwachung	Aus
[-] POWERLINK Parameter	
[-] Verwendung der DS402 Achstreiber-Bibliothek	Ein
[-] DS402 axis	
[-] Axis reference	gAxis_2
[-] Mechanical elements	
[-] Encoder settings	
[-] Increments per revolution	360000
[-] Position actual value range	Default
[-] Cyclic set value modes	
[-] Cyclic position mode	Cyclic synchronous position
[-] Cyclic velocity mode	Cyclic synchronous velocity
[-] Axis features	
[-] Feature reference 1	Feature_1_ProfGen
[-] Feature reference 2	
[-] Kanaele	
[-] Geraetespezifische Parameter	
[-] Simulation	

**Note:**

In this example the feature “*Feature_ProfGen*” is used. It is only required if CNC, CAM, or other synchronized motion is used.

15.6 Automation Studio Configuration View

15.6.1 Add axis objects

Add an axis object to MappMotion and add two axes (Linear & Rotary)

The screenshot shows the Automation Studio Configuration View interface. On the left, the 'Configuration View' pane displays a tree structure of configuration elements, with 'mappMotion' selected and highlighted by a red box. In the center, the 'Config [Active]' tab is open, showing two axis objects: 'gAxis_1' and 'gAxis_2'. 'gAxis_1' is a linear axis with a base type of 'Linear', measurement unit of 'Millimeters', and resolution of '0.0001'. 'gAxis_2' is a rotary periodic axis with a base type of 'Rotary periodic', measurement unit of 'Degrees', and resolution of '0.001'. Both axes have movement limits for velocity, acceleration, and deceleration. On the right, the 'Toolbox - Objektkatalog' pane shows the 'mapp Motion' category, with 'Axis' selected and highlighted by a red box. The 'Object Type' section shows 'Mechatronic' and 'Basic' categories.



Note:

A **LinMot linear motor** has an internal position resolution of 0.1 um. Therefore the “Measurement resolution” for the unit Millimetres is **0.0001**.

A **LinMot PR01/PR02 rotary motor** has by default 360'000 ticks/increments per motor revolution. Therefore, for the “Measurement resolution” for the unit Degrees is $360^\circ / 360'000 = 0.001$.

15.7 Homing

Within the DS402 / CiA402 profile a drive based / manufacturer specific homing is possible. To setup the homing the function block *MC_BR_InitHome_DS402Ax* is used.

Only manufacturer specific homing modes are supported.

When using the MC_BR_InitHome_DS402Ax function block, set "DriveSpecificHoming" to "mcSWITCH_ON". "DriveSpecificHomingModeMode" configures the HomingMode like the UPID 13C4h does:

Name	Value	Raw Data
<input type="radio"/> Actual Position	Off	0000h
<input checked="" type="radio"/> Mechanical Stop Negative Search	On	0001h
<input type="radio"/> Mechanical Stop Positive Search	Off	0002h
<input type="radio"/> Limit Switch Negative	Off	000Eh
<input type="radio"/> Limit Switch Positive	Off	000Fh
<input type="radio"/> Home Switch Negative	Off	0003h
<input type="radio"/> Home Switch Positive	Off	0010h
<input type="radio"/> Home Switch And Mechanical Stop Negative	Off	0004h
<input type="radio"/> Home Switch And Mechanical Stop Positive	Off	0005h
<input type="radio"/> Home Switch And Limit Switch Negative	Off	0006h
<input type="radio"/> Home Switch And Limit Switch Positive	Off	0007h
<input type="radio"/> Index On X13 And Mechanical Stop Negative	Off	0008h
<input type="radio"/> Index On X13 And Mechanical Stop Positive	Off	0009h
<input type="radio"/> Index On X13 And Limit Switch Negative	Off	000Ah
<input type="radio"/> Index On X13 And Limit Switch Positive	Off	000Bh
<input type="radio"/> Index On X13 Negative Search	Off	000Ch
<input type="radio"/> Index On X13 Positive Search	Off	000Dh
<input type="radio"/> No Drive Homing	Off	0011h

Select the homing mode you have setup with the Motor Wizard of LinMot-Talk.

Position offset, velocity and acceleration should also be configured to the users' needs.

15.7.1 Linear Motor

A possible setup for homing mode "Mechanical Stop Negative Search" when the drive-based homing should be modified could look as follows.

Just uncomment all *MC_BR_InitHome...* and the *MC_Home_0.HomingMode* lines.

The code as it is shown below is directly executing the homing sequence as it is setup within the Motor Wizard of LinMot-Talk.

```
PROGRAM _INIT

gAxis_1; // Touch PV

// MC_BR_InitHome_DS402Ax initialisations
// This is only required if one doesn't want to use Homing Mode setup in the drive
// MC_BR_InitHome_DS402Ax_0.Axis := ADR(gAxis_1);
// MC_BR_InitHome_DS402Ax_0.HomingParameters.DriveSpecificHoming := mcSWITCH_ON;
// MC_BR_InitHome_DS402Ax_0.HomingParameters.DriveSpecificHomingMode := 1; // Homing Mode "Mechanical Stop Negative Search"
// MC_BR_InitHome_DS402Ax_0.HomingParameters.Position := -10;
// MC_BR_InitHome_DS402Ax_0.HomingParameters.StartVelocity := 10; // 10 mm/s
// MC_BR_InitHome_DS402Ax_0.HomingParameters.HomingVelocity := 10; // 10 mm/s
// MC_BR_InitHome_DS402Ax_0.HomingParameters.Acceleration := 100;

// MC_Power initialisations
MC_Power_0.Axis := ADR(gAxis_1);

// MC_Home initialisations
MC_Home_0.Axis := ADR(gAxis_1);
MC_Home_0.HomingMode := mcHOMING_DEFAULT;
//MC_Home_0.HomingMode := mcHOMING_INIT; // This is only required if one doesn't want to use Homing Mode setup in the drive
```

15.7.2 Rotary Motor

LinMot rotary motors (RS01 & EC02) have a single turn absolute encoder. Therefore, as homing mode *ncHOME_OFFSET* can be used.

**Note:**

It is recommended to home axes with absolute encoders first before switching the motor on.

15.8 Parameter access

15.8.1 SDO commands

For SDO access the B&R library *AsEPL* is required.
Function blocks: *EplSDORead()* & *EplSDOWrite()*

The Index specifies the LinMot parameter (UPID) to be addressed. It is UPID + 16#2000.
The Sub-Index specifies the command which is performed

Index	Sub-Index	Description	Access Type
2000h -FFFFh		LinMot Parameter Commands	
UPID Commands			
	01h	RAM Value of UPID	Read & Write
	02h	ROM Value of UPID	Read & Write
	03h	Min Value of UPID	Read Only
	04h	Max Value of UPID	Read Only
	05h	Default Value of UPID	Read Only
	06h	RAM / ROM Write of UPID	Write Only
System Commands			
	07h	Set ROM to default (OS)	Write Only
	08h	Set ROM to default (MC)	Write Only
	09h	Set ROM to default (Interface)	Write Only
	0Ah	Set ROM to default (Application)	Write Only
	0Bh	Reset drive	Write Only
	35h	Stop MC and APPL Software	Write Only
	36h	Start MC and APPL Software	Write Only



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus* ([0185-1074](#)) user manual
> see chapter Documentation / User Manuals

Possible variable declaration:

- ❑ instLMAxis01_SdoWrite EplSDOWrite
- ❑ instLMAxis01_SdoRead EplSDORead
- ❑ udiDataWrite UDINT
- ❑ udiDataRead UDINT

Possible function block calls where IF3 is the Powerlink interface:

```
// SDO read
instLMAxis01_SdoRead(pDevice:=ADR('IF3'), pData:=ADR(udiDataRead));

// SDO write
instLMAxis01_SdoWrite(pDevice:=ADR('IF3'), pData:=ADR(udiDataWrite));
```

Example read parameter:

Read the RAM value of the parameter Maximal Current:

Name: Maximal Current
UPID: 16#13A6
Type: SInt32 = DINT = 4 Bytes
Scale: 0.001 A

pDevice := pointer to POWERLINK interface, e.g., **ADR('IF3')**
node := 1 (Node ID of the LinMot drive)
index := 13222 = 16#33a6 = 16#2000 + 16#13a6
subindex := 1 (access RAM value)
pData := pointer to data buffer, e.g., **ADR(udiDataRead)**
datalen := 4 (always 4 Bytes! Even if the parameter to read is less)

instLMAxis01_SdoRead	EplSDORRead	local	
enable	BOOL		TRUE
pDevice	UDINT		69733729
node	USINT		1
index	UINT		13222
subindex	USINT		1
pData	UDINT		69735842
datalen	UDINT		4
status	UINT		65535
errorinfo	UDINT		16#0000_0000
readlen	UDINT		4
intern	EPL_I_TYPE		
udiDataRead	UDINT	local	15000

Example write parameter:

Write 1A to the RAM value of the parameter Maximal Current:

Name: Maximal Current
UPID: 16#13A6
Type: SInt32 = DINT = 4 Bytes
Scale: 0.001 A > value to be sent = 1'000

pDevice := pointer to POWERLINK interface, e.g., **ADR('IF3')**
node := 1 (Node ID of the LinMot drive)
index := 13222 = 16#33a6 = 16#2000 + 16#13a6
subindex := 1 (access RAM value)
pData := pointer to data buffer, e.g., **ADR(udiDataWrite)**
datalen := 4 (always 4 Bytes! Even if the parameter to read is less)


instLMAxis01_SdoWrite	EplSDOWrite	local	
enable	BOOL		TRUE
pDevice	UDINT		69733783
node	USINT		1
index	UINT		13222
subindex	USINT		1
pData	UDINT		69735838
datalen	UDINT		4
status	UINT		65535
errorinfo	UDINT		0
intern	EPL_I_TYPE		
udiDataWrite	UDINT	local	1000

15.9 Add Additional Parameters or Variables to the Process Data

It is possible to add up to 4 parameters or variables to the cyclic PDO of the drive. This allows fast read/write access.

Right-click on the drive and select *Configuration*.

- Set the **Cyclic transmission** to either *Read* (for read access from the drive) or *Write* (for write access to the drive) in the “Channels”.
- As **Init value** in the “Device specific parameters” set the UPID number (e.g., Maximal Current has UPID 16#13A6 > 5030 decimal) of the parameter you want to access.



Afterwards you can assign a PV in the I/O configuration of the device.

16 Drive Profile: B&R NC Motion, SDC interface

16.1 Overview

This chapter shows how a LinMot drive with *Powerlink* interface (e.g., C1250-PL-XC-1S) can be integrated and setup in a B&R environment as motion axis (ACP10 > SDC > LinMot).

Download:

The demo project can be downloaded from:

http://download.linmot.com/plc_lib/libraries/BR/SDC/ (named *LM_SDC_Demo_...*)

The general library for LinMot drives is available from:

http://download.linmot.com/plc_lib/libraries/BR/ (v2.10.0 or later required)

Components used:

- LinMot C1250-PL-XC-1S-000 (article number 0150-1885)
Firmware 6.7 Build 20190311 & 6.8 Build 20190315
- B&R X20CP1584
- Automation Studio V 4.3.8.58 SP#, Automation Runtime G4.34, ACP10 ARNC0 **5.2.1**
- Automation Studio V 4.4.6.71 SP#, Automation Runtime C4.45, ACP10 ARNC0 **5.4.1**



In the *B&R Help Explorer* check chapter *ACP10SDC* for more details about SDC.
It contains all important information about requirements and setup of SDC NC objects.



Image Source: <http://www.br-automation.com/>

The LinMot POWERLINK devices are Ethernet POWERLINK CNs (Controlled Nodes) with the following parameters (according to EPSG-DS-301-V1.1.0):

Device Properties	Value
Minimal POWERLINK cycle time	200 µs
Size of isochronous transmit buffer (maximal size of isochronous frames)	64 Byte
Size of isochronous receive buffer (maximal size of isochronous frames)	64 Byte
Overall buffer size available for isochronous data	128 Byte
PReq to PRes latency (CN isochronous reaction time)	~ 1 µs
SoA to ASnd latency (CN asynchronous reaction time)	~ 1 µs
Maximum asynchronous MTU	300 Byte
Ability to support multiplexed isochronous access	No
Asynchronous SDO transfer method (UDP/IP and/or POWERLINK ASnd)	POWERLINK ASnd only

For further information on Ethernet POWERLINK please visit:

<http://www.ethernet-powerlink.org>

16.2 Compatibility LinMot_SDC <=> ACP10 ARNC0

The following table lists the dependencies of the LinMot_SDC library.



LinMot_SDC	< compatible with >	ACP10 ARNC0
1.00.1	<->	5.2.0 to 5.2.9
1.00.2	<->	5.4.0 to 5.4.9

16.3 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

16.3.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select "No Drive Homing" as homing mode in the Motor Wizard as with the SDC interface the motor is homed within the PLC.



See Appendix I: Basic Position Control Loop Tuning

16.3.2 XDD File

Install the XDD file that is part of the LinMot-Talk software/firmware you are using.
The most recent device files are always part of the newest LinMot-Talk software.



It is located by default:

- Powerlink: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Powerlink\XDD
- Powerlink: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\Powerlink_Nx\XDD (-MI drives)

There are separate XDD files available for either AS3 or AS4.

16.3.3 Powerlink Connection

The drive is connected to the Powerlink network using the X17 (IN) & X18 (OUT) connectors.
The below pictures show the ports of an E1250-PL-UC drive. On all other LinMot drives supporting Powerlink
the ports are named the same (X17 & X18) but they may be placed differently on the drive housing.



16.3.4 Node ID

The Node ID of the LinMot drive is set using the hardware address selectors.

S1 - S2		Address Selectors	
E1100	E1200 V2	S1 (5 .. 8)	Bus ID High (0 ... F). Bit 5 is LSB, bit 8 MSB.
E1200 V1	E1400	S2 (1 .. 4)	Bus ID High (0 ... F). Bit 1 is LSB, bit 4 MSB.


E.g.: Node ID 18 dec = 12 hex = 0001 0010 bin

=> S1 = 1 hex = 0001 bin (Dip Switch 5 = ON), S2 = 2 hex = 0010 bin (Dip Switch 2 = ON)

16.4 Short Description of the LinMot SDC interface function block

16.4.1 Principle of Operation

The *LM_SdcIf* function block acts as interface between the LinMot drive and the B&R SDC (Smart Device Controller) interface. On top of the SDC interface the ACP10 Manager is located that manages the ACP10 axes.



16.4.2 HTML Help

The library LinMot_SDC provides a basic HTML Help. Hit F1 to open.

Note:
This Library provides a function block that acts as interface between a LinMot Powerlink drive and the B&R SDC interface. This allows to use a LinMot drive as motion axis in the B&R environment. The LinMot motor is directly connected to the ACP10 axis through the SDC interface.

Important:
This Library is using the SDC functionality provided by B&R. Therefore only ACP10 axes are supported up to now.


This library provides a function block that allows to connect a LinMot Powerlink drive to a B&R ACP10 axis using the SDC interface. The function block LM_SdcIf requires the standard library from LinMot (LinMot v2.10.0).

Download LinMot library: http://download.linmot.com/plc_lib/libraries/BR/
Download Demo project: http://download.linmot.com/plc_lib/libraries/BR/SDC/

How to setup the LinMot Powerlink drive as ACP10 axis using the SDC interface is shown in detail in the application note PLC Commissioning (0185-1120-E): <http://shop.linmot.com/E/product/0185-1120-E>

16.4.3 LM_Sdclf (Interface Function Block)

This is the function block that acts as interface between SDC and LinMot drive.



16.4.4 enCallType

The function block LM_Sdclf has two call types.

- **enLM_SDCIF_CALLTYPE_INIT** (value 1):
With this type the function block LM_Sdclf is called in the Init section of the PLC program to setup all required internal variables
- **enLM_SDCIF_CALLTYPE_CYCLE** (value 2):
With this type the function block LM_Sdclf is called in the cyclic section of the PLC program. This is the normal operation mode.

16.4.5 stConfig

This structure contains the parameters required for a proper operation of the LM_Sdclf function block.

Name	Data Type	Default Value	Description
pszLogName	UDINT	0	Log name to be used / created. Set 0 if not logger should be used / created
pszAxisName	UDINT	0	ACP10 axis name.
pszSDCHWName	UDINT	0	Name of SDC HW without _HW <i>Name of SDC HW</i>
pszSDCDrvIf32Name	UDINT	0	<i>Name of SDC Drv32If (Attention: max length of string is 34 characters!)</i>
pszSDCEnclf32Name	UDINT	0	<i>Name of SDC Enc32If (Attention: max length of string is 34 characters!)</i>
pszSDCDiDolf32Name	UDINT	0	<i>Name of SDC DiDolf (Attention: max length of string is 34 characters!)</i>
pszSDCLmName	UDINT	0	<i>Name of LinMot tstLM_LinMot</i>
udiSM_SCALE_LOAD_MOTREV	UDINT	1	Same as used in the ACOPOS Parameter Table
udiSM_SCALE_LOAD_UNITS	UDINT	10000	Same as used in the ACOPOS Parameter Table
udiSM_SCALE_STEP	UDINT	10000	Same as used in the ACOPOS Parameter Table
diResReductionFactor	DINT	10	Resolution reduction (Default 10 for LinMot linear motors. Use 1 for other motors)
diEncReductionFactor	DINT	10	Encoder reduction (Default 10 for LinMot linear motors. Use 1 for other motors)
tEnableDelay	TIME	T#10ms	Delay velocity calculation during enable


Note:

The default values of the parameters in the table with blue background color are set to be used with a LinMot linear motor. These default values and the settings done in chapter 16.8 result in 1um per Unit and 10um actual position resolution.


Attention:

The orange parameters in italic font are optional. In the examples of this manual they are not used. In this manual, the names of the individual SDC components are derived from *pszSDCHWName* as shown in chapter 16.5 point 3.

Nevertheless, it is possible to set unique names for each SDC component and the LinMot axis type (*tstLM_axis*) and assign them to the parameters above (orange).

16.5 Prerequisites



Attention:

There are some prerequisites that must be fulfilled before the following chapters can be successfully completed.

1. The project you are using must already have the PLC type setup. Otherwise please follow the B&R wizard for creating a new project
2. The libraries from LinMot (*LinMot v2.10.0 or later & LinMot_SDC*) must be installed in the project. Check compatibility with ACP10 ARNC0 in **chapter 16.2 Compatibility LinMot_SDC <> ACP10 ARNC0**

You may want to create a separate package for testing (E.g., *LinMot_SDC_Demo*).

The libraries can be copied from the demo project to your project:

Object Name	Description
LM_SDC_Demo	
Global.typ	Global data types
Global.var	Global variables
Libraries	Global libraries
operator	This library contains function in
runtime	This library contains runtime fur
astime	The AsTime Library supports D
AslecCon	This library contains function in
standard	This library contains standard fu
sys.lib	The SYS_LIB library contains fi
ArEventLog	The ArEventLog library can be
LinMot_SDC_Demo	
LinMot	LinMot library
LinMot_SDC	LinMot SDC interface

3. Add the following PVs to the *Global.var* (except *gAxis01*)

Name	Type
gAxis01	ACP10AXIS_typ
gAxis01_HW	SdcHwCfg_typ
gAxis01_DrvIf	SdcDrvIf32_typ
gAxis01_EncIf1	SdcEncIf32_typ
gAxis01_DiDolf	SdcDiDolf_typ
gAxis01_LM	tstLM_Axis



Attention:

Don't add the PV *gAxis01* (ACP10AXIS_typ) yet. It will be added in chapter 16.6.5.




Attention:

The names of the PVs are very important! As shown above the PVs beside the ACP10AXIS (gAxis01) must be named *xxx_HW*, *xxx_DrvIf*, *xxx_EncIf1*, *xxx_DiDolf*, *xxx_LM* where *xxx* is always the same for the same axis (e.g., *gAxis01*).

16.6 Automation Studio Physical View

16.6.1 Add the LinMot drive to the Powerlink network

Install the XDD file(s) using *Tools > Import Fieldbus Device...* in Automation Studio.




The required XDD-file can be found in the following folder (default):

C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\POWERLINK\XDD
C:\Program Files\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\Powerlink_Nx\XDD

In the Hardware Catalog search for the LinMot drive (e.g., C1250...) and drag&drop it onto the Powerlink interface (PLK).

Alternatively select the Product Group *3rd Party Devices* > all installed LinMot drives are shown.



Set the Node ID according to your requirements.

16.6.2 Configuration

In the configuration of the LinMot slave module (right-click on device > Configuration) the following channels must be selected:

Set the **Cyclic transmission** of all channels marked with a red exclamation mark to **Read** or to **Write** respectively.

Name	Value
[-] C1250-PL_lin	
[+] General	
[+] POWERLINK parameters	
[+] Channels	
[+] MCSW_Variables_I4F00 RECORD[0x19]	
[+] MCSW_StateVar_I4F00_S01	
[!] Cyclic transmission	Read
[!] Datatype	UINT
[+] MCSW_StatusWord_I4F00_S02	
[+] MCSW_WamWord_I4F00_S03	
[+] MCSW_ActualPosition32Bit_I4F00_S04	
[+] MCSW_DemandPosition32Bit_I4F00_S05	
[+] MCSW_DemandCurrent_I4F00_S06	
[+] MCSW_ControlWord_I4F00_S07	
[+] MCSW_MotionCommandHeader_I4F00_S08	
[+] MCSW_MotionCommandByte_00_03_I4F00_S09	
[+] MCSW_MotionCommandByte_04_07_I4F00_S0A	
[+] MCSW_MotionCommandByte_08_11_I4F00_S0B	
[+] MCSW_MotionCommandByte_12_15_I4F00_S0C	
[+] MCSW_MotionCommandByte_16_19_I4F00_S0D	
[+] MCSW_MotionCommandByte_20_23_I4F00_S0E	
[+] MCSW_MotionCommandByte_24_27_I4F00_S0F	
[+] MCSW_MotionCommandByte_00_01_I4F00_S10	
[+] MCSW_MotionCommandByte_02_03_I4F00_S11	
[+] MCSW_MotionCommandByte_04_05_I4F00_S12	
[+] MCSW_MotionCommandByte_06_07_I4F00_S13	
[+] MCSW_MotionCommandByte_08_09_I4F00_S14	
[+] MCSW_MotionCommandByte_10_11_I4F00_S15	
[+] MCSW_MotionCommandByte_12_13_I4F00_S16	
[+] MCSW_MotionCommandByte_14_15_I4F00_S17	
[+] MCSW_MotionCommandByte_16_17_I4F00_S18	
[+] MCSW_MotionCommandByte_18_19_I4F00_S19	
[+] UPID_Variables_Values_I4F02 RECORD[0x04]	
[+] Configuration_Module_I4F03 RECORD[0x06]	
[+] TX_Cfg_Module_Control_I4F03_S01	
[+] TX_Cfg_Module_Index_Out_I4F03_S02	
[+] TX_Cfg_Module_Value_Out_I4F03_S03	
[+] RX_Cfg_Module_Status_I4F03_S04	
[+] RX_Cfg_Module_Index_In_I4F03_S05	
[+] RX_Cfg_Module_Value_In_I4F03_S06	
[+] Device specific parameters	

16.6.3 I/O Mapping

Right-click on the device and open *I/O mapping*. The inputs and outputs of the modules are mapped to the axis structure (datatype *tstLM_Axis*).

In the actual example the used PV *gAxis01_LM* is defined in the *Global.var* as data type *tstLM_Axis*:

Name	Type
gAxis01	ACP10AXIS_typ
gAxis01_HW	SdcHwCfg_typ
gAxis01_DrvIf	SdcDrvIf32_typ
gAxis01_Enclf1	SdcEnclf32_typ
gAxis01_DiDolf	SdcDiDolf_typ
gAxis01_LM	tstLM_Axis

Map the channels to the process variables as shown below

Channel Name	Process Variable	Data Type
+● ModuleOk	::gAxis01_LM.DrvToPlc.StateVar	BOOL
+● MCSW_StateVar_I4F00_S01	::gAxis01_LM.DrvToPlc.StatusWord	UINT
+● MCSW_StatusWord_I4F00_S02	::gAxis01_LM.DrvToPlc.WamWord	UINT
+● MCSW_WamWord_I4F00_S03	::gAxis01_LM.DrvToPlc.ComActualPosition	DINT
+● MCSW_ActualPosition32Bit_I4F00_S04	::gAxis01_LM.DrvToPlc.ComDemandPosition	DINT
+● MCSW_DemandPosition32Bit_I4F00_S05	::gAxis01_LM.DrvToPlc.ComActualCurrent32	DINT
+● MCSW_DemandCurrent_I4F00_S06	::gAxis01_LM.DrvToPlc.ControlWord	UINT
● MCSW_ControlWord_I4F00_S07	::gAxis01_LM.PlcToDrv.MCHeader	UINT
● MCSW_MotionCommandHeader_I4F00_S08	::gAxis01_LM.PlcToDrv.MCParaDWord_00_03	UDINT
● MCSW_MotionCommandByte_00_03_I4F00_S09	::gAxis01_LM.PlcToDrv.MCParaDWord_04_07	UDINT
● MCSW_MotionCommandByte_04_07_I4F00_S0A	::gAxis01_LM.PlcToDrv.MCParaDWord_08_11	UDINT
● MCSW_MotionCommandByte_08_11_I4F00_S0B	::gAxis01_LM.PlcToDrv.MCParaDWord_12_15	UDINT
● MCSW_MotionCommandByte_12_15_I4F00_S0C	::gAxis01_LM.PlcToDrv.MCParaDWord_16_19	UDINT
● MCSW_MotionCommandByte_16_19_I4F00_S0D	::gAxis01_LM.PlcToDrv.CfgControlWord	UINT
● TX_Cfg_Module_Control_I4F03_S01	::gAxis01_LM.PlcToDrv.CfgIndexOut	UINT
● TX_Cfg_Module_Index_Out_I4F03_S02	::gAxis01_LM.PlcToDrv.CfgValueOut	UDINT
● TX_Cfg_Module_Value_Out_I4F03_S03	::gAxis01_LM.DrvToPlc.CfgStatusWord	UINT
+● RX_Cfg_Module_Status_I4F03_S04	::gAxis01_LM.DrvToPlc.CfgIndexIn	UINT
+● RX_Cfg_Module_Index_In_I4F03_S05	::gAxis01_LM.DrvToPlc.CfgValueIn	UDINT
+● RX_Cfg_Module_Value_In_I4F03_S06		

16.6.4 Powerlink Interface and PLC Configuration

Set the cycle time of the Powerlink interface (right-click on PLK > Configuration). In this example 800us.

The screenshot shows the 'Physical View' and 'X20CP1584 [Configuration]' tabs. In the configuration tab, under the 'IF3' module, the 'POWERLINK parameters' section is selected. The 'Cycle time' parameter is highlighted with a red arrow and set to 800 μs.

Name	Value	Unit
Type 4	Type 4	
POWERLINK V2	POWERLINK V2	
MTU size	300	
Baud rate	100 MBit half duplex	
Activate POWERLINK communication	on	
Device name	<InterfaceAddress>	
Host names	Single CPU Project br-automation	
Redundant parameter		
Host name		
Cycle time	800	μs
Multiplexing prescale	8	
Mode	managing node	
Advanced		

In the PLC configuration (right-click on X20CP1584 > Configuration) set Cyclic #1 duration to 800us (same as Powerlink cycle time) and tolerance to 0 (Important!)

The screenshot shows the 'Physical View' and 'X20CP1584 [Configuration]' tabs. In the configuration tab, under the 'Timing' section, the 'Cyclic #1' parameters are highlighted with a red box. The 'Duration' is set to 800 μs and 'Tolerance' is set to 0 μs.

Name	Value	Unit
LM_SDC_Demo_Config1	LM_SDC_Demo_Config1	
1.0.0	1.0.0	
Number of cyclic resources	8	
Activate exception task class	off	
Cyclic task classes		
Cyclic #1		
Duration	800	μs
Tolerance	0	μs
Stack	8192	Byte
Used as output cycle trigger	off	
I/O input delay	no delay	
I/O output delay	no delay	
Cyclic #2		
Cyclic #3		



Note:

Other cycle times are possible too. Just make sure that Cyclic #1 Duration and Powerlink Cycle Time are set the same (e.g. 2000us).

16.6.5 Add a B&R drive to generate all NC object specific requirements automatically




In the *B&R Help Explorer* check chapter *ACP10SDC > Using the Drive Configuration wizard*.


It explains how to add the required components.

As alternative it is also possible to do all steps manually as described in the B&R Help Explorer.

- Search for 8V1010.001-2 in the *Hardware Catalog* and then double-click (or drag&drop on the Powerlink interface)




- Click through the Drive Configuration Wizard without changing anything until *Global Settings*. Then select the language, set a name for the axis (gAxis01 in this example) and click *Finish* at the end.



Now all required libraries for NC objects are added to the project. Also, the *NC manager configuration* and the *NC mapping* are created.


3. Delete the just created drive (right-click > Delete)




16.7 Automation Studio Configuration View

16.7.1 Setup NC Manager and NC Mapping

Delete the automatically created NC mapping (right-click > Delete)




Add a new NC mapping by drag&drop *ACP10 Mapping Table* from the Toolbox – Object Catalog




Attention:

Assign a name that is different to *Acp10map.ncm* or you will later not be able to add a new NC object.
E.g. name it *Acp10map1.ncm*

Double-click on the NC manager configuration. Then right-click on the POWERLINK interface (or anywhere else in the NC manager configuration) and select "Insert Interface"




Select Smart Device Controller (SDC) and click OK



16.7.2 Add new NC Object

Open the NC Mapping and in the editor right-click and select *Add NC Object*



In the new empty line enter the following data:

NC Object Name	PLC Address	Nc Object Type	Channel	Simulation	NC INIT Parameter	ACOPOS Parameter	Additional Data
gAxis01	SDC_IF1.ST1	ncAXIS	1	Off	gAxis01i	gAxis01a	SDC_AX_HwPv="gAxis01_HW"

NC Object Name: Name of the ACP10Axis in Global.var. In this example *gAxis01*

PLC Address: Select the SDC interface, e.g. SDC_IF1.STx (Where x is a number. Here 1)

Nc Object Type: ncAxis

Channel: 1

Simulation: Off

NC INIT Parameter: Init Parameter table for this axis. In this example *gAxis01i*

ACOPOS Parameter: ACOPOS Parameter table for this axis. In this example *gAxis01a*

Additional Data: Name of SDC HW PV. In this example *gAxis01_HW* as defined in *Global.var*


Name	Type
gAxis01	ACP10AXIS_typ
gAxis01_HW	SdcHwCfg_typ
gAxis01_DrvIf	SdcDrvIf32_typ
gAxis01_EncIf1	SdcEncIf32_typ
gAxis01_DiDof	SdcDiDof_typ
gAxis01_LM	tstLM_Axis

16.7.3 Add TextSystem



Note:

If you don't want to use the logger functionality this chapter can be skipped.


If not available first add Project Languages from the Toolbox to the project (in Logical View) and set it up:



Add a new TextSystem Configuration from the Toolbox:



Copy the *tmx* file from the demo project (see chapter 16.1) to your project:



Open the TextSystem Configuration and set it up by selecting the *.tmx file just copied.

To do so right-click on "Tmx file for target 1" and select *Add New Dynamic Node*.

Click in the empty Value field and choose *xxx.LinMot_SDC.txtLinMot_SDC.tmx*

Name	Value
Tmx file for target 1	LinMot_SDC_Demo.LinMot_SDC.txtLinMot_SDC.tmx
Tmx file for target 2	

16.8 Automation Studio Logical View: Linear Motor Example


This chapter shows the integration of a LinMot linear motor.

By default, a LinMot linear drive has a maximum resolution of 0.1um of the actual and demand positions. The SDC encoder interface has the limitation that it must be able to check two times per task/Powerlink cycle the actual encoder value of the motor. With 10'000 Units per motor revolution (=1mm) and a task/Powerlink cycle time of 800us this limits the maximum reachable velocity to around 400mm/s which is slow for a LinMot linear motor.

Therefore, the resolution is changed to 1um by setting the SCALE_ENC_INCR and the parameter *diEncReductionFactor* of the LinMot SDC interface function block accordingly. This allows maximum velocities of up to 4'000 mm/s which is enough for most applications.

16.8.1 Add the example program to the project

Copy the sample program *Sample_Linear_ST* from the demo project (see chapter 16.1) and past it to the Logical View, e.g. to the package *LinMot_SDC_Demo*:



16.8.2 ACOPos Parameter Table

For a LinMot linear motor the parameters must be set exactly as shown below. This will result in a resolution of 1um per Unit.

Name	ID	Value	Unit	Description
SCALE_ENCOD_INCR	109	1000		Encoder: Encoder scaling: increments per
SM_SCALE_STEP	64232	10000		Stepper motor: Step scaling: Steps per motc
SM_SCALE_LOAD_MOTREV	64234	1		Stepper motor: Load scaling: Motor revolutic
SM_SCALE_LOAD_UNITS	64233	10000		Stepper motor: Load scaling: Units per SM_
VCTRL_SCALE_LOAD_MOTREV	674	1		Motor encoder: Load scaling: Encoder revo
VCTRL_SCALE_LOAD_UNITS	673	10000		Motor encoder: Load scaling: Units per load

16.8.3 Init Parameter Table

Set all digital input active levels to *ncACTIV_HI*.

Set *Units* in *Encoder_if* to 10000 (> 1um per Unit with LinMot linear motor)

Set *t_predict* and *t_total* to 5 times Powerlink cycle time each > 800us * 5 = 0.004 s

Name	Value	Unit	Description
ACP10AXIS_typ			
dig_in			Digital Inputs
level			Active Input Level
reference	ncACTIV_HI		Reference switch
pos_hw_end	ncACTIV_HI		Positive HW end switch
neg_hw_end	ncACTIV_HI		Negative HW end switch
trigger1	ncACTIV_HI		Trigger1
trigger2	ncACTIV_HI		Trigger2
encoder_if			Encoder Interface
parameter			Parameters
count_dir	ncSTANDARD		Count direction
scaling			Scaling
load			Load
units	10000	Units	Units at the load
rev_motor	1		Motor revolutions
limit			Limit value
controller			Controller
mode	ncPOSITION		Mode
position			Position Controller
kv	50	1/s	Proportional amplification
tn	0	s	Integral action time
t_predict	0.004	s	Prediction time
t_total	0.004	s	Total time
p_max	1.0e30	Units/s	Maximum proportional action
i_max	0	Units/s	Maximum integral action

As the limits depend on the application and the motor type used it is recommended to start with some moderate values.

		Limit value	
limit		Parameters	
parameter			
v_pos	1000000.0	Units/s	Speed in positive direction
v_neg	1000000.0	Units/s	Speed in negative direction
a1_pos	5000000.0	Units/s ²	Acceleration in positive direction
a2_pos	5000000.0	Units/s ²	Deceleration in positive direction
a1_neg	5000000.0	Units/s ²	Acceleration in negative direction
a2_neg	5000000.0	Units/s ²	Deceleration in negative direction
t_jolt	0	s	Jolt time
t_in_pos	0	s	Settling time before message 'In Position'
pos_sw_end	2000000000	Units	Positive SW end
neg_sw_end	-2000000000	Units	Negative SW end
ds_warning	2000.0	Units	Lag error limit for display of a warning
ds_stop	5000.0	Units	Lag error limit for stop of a movement
a_stop	1.0e30	Units/s ²	Acceleration limit for stop of a movement
dv_stop	0	1/s	Speed error limit for stop of a movement
dv_stop_mode	ncOFF		Mode for speed error monitoring

16.8.4 Check Init Parameters of the SDC function block

Open Main_Linear.st and check if the axis, SDCHW and log names as well as the other parameters in stConfig are set correctly.

The screenshot shows the SIMATIC Manager interface. On the left, the Logical View pane displays the project structure under LM_SDC_Demo, including subfolders like Global.typ, Global.var, Libraries, LinMot, LinMot_SDC, and Sample_Linear_ST, along with files such as acp10texn, gAxis01obj, gAxis01a, gAxis01, and gAxis01.ax. On the right, the Structured Text editor shows the _CYCLIC program:

```

PROGRAM _INIT
    // Touch PVs so that the system can find them
    gAxis01;
    gAxis01_HW;
    gAxis01_DrvIf;
    gAxis01_EncIf1;
    gAxis01_DiDoIf;
    gAxis01_IM;


    // Init LinMot SDC interface for LinMot linear motor
    instLMAxis01_SdcIf.enCallType := enLM_SDCIF_CALLTYPE_INIT;
    instLMAxis01_SdcIf.stConfig.pszAxisName := ADR('gAxis01'); /* axis name (can also be inside an array) */
    instLMAxis01_SdcIf.stConfig.pszSDCHWName := ADR('gAxis01'); /* SDC HW name without _HW */
    instLMAxis01_SdcIf.stConfig.pszLogName := ADR('LinMotvLog'); /* log name */
    instLMAxis01_SdcIf.stConfig.udisM_SCALE_LOAD_MOTREV := 1; (* Set to the same value as in the according AO *)
    instLMAxis01_SdcIf.stConfig.udisM_SCALE_LOAD_UNITS := 10000; (* Set to the same value as in the according ACOP0 *)
    instLMAxis01_SdcIf.stConfig.udisM_SCALE_STEP := 10000; (* Set to the same value as in the according ACOP0 *)
    instLMAxis01_SdcIf.stConfig.diEncReductionFactor := 10; (* 1 = filter disabled, 10 = default for LinMot 1 *)
    instLMAxis01_SdcIf.stConfig.diResReductionFactor := 10; (* 1 = resolution reduction disabled, 10 = default for LinMot 1 *)
    instLMAxis01_SdcIf();

END_PROGRAM

```

16.8.5 Assign the example program to Cyclic #1

In the Physical View Right-click X20CP1584 > Software and assign the example program to Cyclic #1



16.9 Automation Studio Logical View: Rotary Motor Example

This chapter shows the integration of a rotary motor. In this example a RS01 (rotary part of a LinMot PR01 linear rotary motor).


To add a second axis, repeat chapter 16.6 and 16.7 and use another name, e.g. *gAxis02*.

The mapping table with more axes may look as follows:

NC Object Name	PLC Address	Nc Object Type	Channel	Simulation	NC INIT Parameter	ACOPOS Parameter	Additional Data
gAxis01	SDC_IF1.ST1	ncAXIS	1	Off	gAxis01i	gAxis01a	SDC_AX_HwPv="gAxis01_HW"
gAxis02	SDC_IF1.ST2	ncAXIS	1	Off	gAxis02i	gAxis02a	SDC_AX_HwPv="gAxis02_HW"

16.9.1 Add the example program to the project

Copy the sample program *Sample_Rotary_RS01* from the demo project (see chapter 16.1) and paste it to the Logical View, e.g. to the package *LinMot_SDC_Demo*. You may also want to copy the axes objects:



16.9.2 ACOPOS Parameter Table

For a rotary motor the parameters must be set in relation to the settings on the LinMot drive.

The following examples will result in a resolution of **0.001 degree per Unit**.

The parameters **SCALE_ENCOD_INCR** and **SM_SCALE_STEP** must be set to the number of ticks shown in the LinMot-Talk motor wizard.

Example 1: RS01 motor

The screenshot shows the Global.ty [Data Type Declaration] and Global.var [Map] tabs in a software interface. The Global.var tab displays a table of parameters. The 'Parameters' row is highlighted with a red box. The table data is as follows:

Name	ID	Value
SCALE_ENCOD_INCR	109	360000
SM_SCALE_STEP	64232	360000
SM_SCALE_LOAD_MOTREV	64234	1
SM_SCALE_LOAD_UNITS	64233	360000
VCTRL_SCALE_LOAD_MOTREV	674	1
VCTRL_SCALE_LOAD_UNITS	673	360000
SGEN_SW_END_IGNORE	128	1

A red arrow points from the 'gAxis02_RS01' node in the Logical View tree to the 'gAxis02a' node, indicating the specific axis being configured.

The screenshot shows the Motor Wizard Step 5/6: Position Feedback configuration screen. The 'Motor Angle to Position Ratio' section is highlighted with a red box. The configuration is as follows:

- Base of Angle Measuring: Sine/Cosine Sensor
- 1 Revolution = 360000 Ticks
- Positive Counting Direction: Counter-clockwise

The 'External Position Measuring System (optional)' section shows a Sensor Type of No Sensor.

Below these sections is a table of Derived Settings:



Derived Settings	Value	Comment
Commutation Period	119.999888241291 °	
BEMF Constant	8E-6 V/(°/s)	

At the bottom are buttons for Help, < Back, Next >, Finish, and Cancel.

Example 2: EC02 motor

This motor has 524288 ticks per motor revolution. For this reason, the parameters **SCALE_ENCOD_INCR** and **SM_SCALE_STEP** must be set to 524288.

The unit is the same as before: 0.001 degree



16.9.3 Init Parameter Table

Set all digital input active levels to `ncACTIV_HI`.

Set `Units` in `Encoder_if` to 360000 (> 0.001 degree per Unit)

Set `t_predict` and `t_total` to 5 times Powerlink cycle time each > 800us * 5 = 0.004 s

Name	Value	Unit	Description
ACP10AXIS_typ			
dig_in			Digital Inputs
level			Active Input Level
reference	ncACTIV_HI		Reference switch
pos_hw_end	ncACTIV_HI		Positive HW end switch
neg_hw_end	ncACTIV_HI		Negative HW end switch
trigger1	ncACTIV_HI		Trigger1
trigger2	ncACTIV_HI		Trigger2
encoder_if			Encoder Interface
parameter			Parameters
count_dir	ncSTANDARD		Count direction
scaling			Scaling
load			Load
units	360000	Units	Units at the load
rev_motor	1		Motor revolutions
limit			Limit value
controller			Controller
mode	ncPOSITION		Mode
position			Position Controller
kv	0.0	1/s	Proportional amplification
tn	0.0	s	Integral action time
t_predict	0.004	s	Prediction time
t_total	0.004	s	Total time
p_max	0.0	Units/s	Maximum proportional action
i_max	0.0	Units/s	Maximum integral action

As the limits depend on the application and the motor type used it is recommended to start with some moderate values.

Name	Value	Unit	Description
limit			Limit value
parameter			Parameters
v_pos	3600000.0	Units/s	Speed in positive direction
v_neg	3600000.0	Units/s	Speed in negative direction
a1_pos	7200000.0	Units/s ²	Acceleration in positive direction
a2_pos	7200000.0	Units/s ²	Deceleration in positive direction
a1_neg	7200000.0	Units/s ²	Acceleration in negative direction
a2_neg	7200000.0	Units/s ²	Deceleration in negative direction
t_jolt	0.0	s	Jolt time
t_in_pos	0.0	s	Settling time before message 'In Position'
pos_sw_end	2000000000	Units	Positive SW end
neg_sw_end	-2000000000	Units	Negative SW end
ds_warning	10000.0	Units	Lag error limit for display of a warning
ds_stop	20000.0	Units	Lag error limit for stop of a movement
a_stop	1.0E+09	Units/s ²	Acceleration limit for stop of a movement
dv_stop	0.0	1/s	Speed error limit for stop of a movement
dv_stop_mode	ncOFF		Mode for speed error monitoring

16.9.4 Check Init Parameters of the SDC function block

Open Main_Linear.st and check if the axis, SDCHW and log names as well as the other parameters in stConfig are set correctly.

The screenshot shows the SIMATIC Manager Logical View. On the left, the project structure is displayed under 'Object Name'. A red arrow points to the 'st Main_Rotate.st' file. The right pane shows the code for the 'st Sample_Rotary_RS01_ST::Main_Rotate.st [Structured Text]' program. A red box highlights the initialization code:

```

PROGRAM _INIT
    // Touch PVs so that the system can find them
    gAxis02;
    gAxis02_HW;
    gAxis02_DrvIf;
    gAxis02_EncIf1;
    gAxis02_DiDoIf;
    gAxis02_IM;

    // Init LinMot SDC interface for LinMot rotary motor (RS01-xx)
    instLMAxis02_SdcIf.enCallType := enLM_SDCIF_CALLTYPE_INIT;
    instLMAxis02_SdcIf.stConfig.pszAxisName := ADR('gAxis02'); (* axis name (can also be inside an a *)
    instLMAxis02_SdcIf.stConfig.pszSDCHWName := ADR('gAxis02'); (* SDC HW name without _HW *) 
    instLMAxis02_SdcIf.stConfig.pszLogName := ADR('LinMotLog'); (* log name *)
    instLMAxis02_SdcIf.stConfig.udISM_SCALE_LOAD_MOTREV := 1; (* Set to the same value as in the acc
    instLMAxis02_SdcIf.stConfig.udISM_SCALE_LOAD_UNITS := 360000; (* Set to the same value as in the accor
    instLMAxis02_SdcIf.stConfig.udISM_SCALE_STEP := 360000; (* Set to the same value as in the accor
    instLMAxis02_SdcIf.stConfig.diEncReductionFactor := 1; (* 1 = filter disabled, 10 = default for
    instLMAxis02_SdcIf.stConfig.diResReductionFactor := 1; (* 1 = resolution reduction disabled, 10
    instLMAxis02_SdcIf();
END_PROGRAM

```



Attention:

The parameter **SM_SCALE_STEP** must be set as shown in chapter 16.9.2.

For a LinMot RS01 rotary motor the parameter **SM_SCALE_STEP** is set to 360000.

For a LinMot EC02 rotary motor the parameter **SM_SCALE_STEP** is set to 524288.

For any other motor please check the Position Feedback in the LinMot-Talk Motor Wizard.

16.9.5 Assign the example program to Cyclic #1

In the Physical View Right-click X20CP1584 > Software and assign the example program to Cyclic #1

The screenshot shows the SIMATIC Manager Physical View and Structure View. In the Physical View, a red arrow points to the 'X20CP1584' node. In the Structure View, a red box highlights the 'Sample_Lin' and 'Sample_Rot' programs under 'Cyclic #1 - [0.8 ms]'. Both programs have a version of 0.00.1.

Name	Version
X20CP1584	
Serial	IF1
ETH	IF2
PLK	IF3
C1250-PL_1in	ST1
USB	IF4
USB	IF5
X2X	IF6
	SS1

Object Name	Version
<CPU>	
Cyclic #1 - [0.8 ms]	
Sample_Lin	0.00.1
Sample_Rot	0.00.1
Cyclic #2 - [20 ms]	
Cyclic #3 - [49.6 ms]	
Cyclic #4 - [100 ms]	
Cyclic #5 - [200 ms]	
Cyclic #6 - [500 ms]	

16.10 Homing

16.10.1 Linear Motor

A possible setup for homing mode ncBlock_DS:

		Movement
move		Stop Movement
stop		Homing procedure
homing		Parameters
parameter		
s	-1000	Units Reference position
v_switch	5000.0	Units/s Speed for searching the reference switch
v_trigger	5000.0	Units/s Trigger Speed
a	50000.0	Units/s ² Acceleration
mode	ncBLOCK_DS	Mode
edge_sw	ncPOSITIVE	Edge of reference switch
start_dir	ncNEGATIVE	Start direction
trigg_dir	ncPOSITIVE	Trigger direction
ref_pulse	ncOFF	Reference pulse
fix_dir	ncOFF	Fixed direction
tr_s_block	1.0	Rev. Distance for blocking the activation of triggering reference pulse'
torque_lim	0.0	Nm Torque limit for homing on block
ds_block	1000.0	Units Lag error for block detection
ds_stop	2000.0	Units Lag error for stop of a movement

16.10.2 Rotary Motor

LinMot rotary motors (RS01 & EC02) have a single turn absolute encoder.

Therefore, as homing mode *ncHOME_OFFSET* can be used.

		Movement
move		Mode
mode	ncOFF	Detail
detail	ncOFF	Stop Movement
stop		Homing procedure
homing		Parameters
init	ncTRUE	Homing procedure initialized
status		Status
parameter		
s	0	Units Reference position
v_switch	5000	Units/s Speed for searching the reference switch
v_trigger	5000	Units/s Trigger Speed
a	50000	Units/s ² Acceleration
mode	ncHOME_OFFSET	Mode
edge_sw	ncPOSITIVE	Edge of reference switch
start_dir	ncNEGATIVE	Start direction
trigg_dir	ncPOSITIVE	Trigger direction
ref_pulse	ncOFF	Reference pulse
fix_dir	ncOFF	Fixed direction
tr_s_block	0.1	Rev. Distance for blocking the activation of triggering reference pulse'
torque_lim	0	Nm Torque limit for homing on block
ds_block	1000	Units Lag error for block detection
ds_stop	2000	Units Lag error for stop of a movement



Note:

It is recommended to home axes with absolute encoders first before switching the motor on.

16.10.3 Reference Switch (mcHOME_ABS_SWITCH)


Attention:

Up to **LinMot drive firmware 6.7** this mode works only when on the drive only the digital input X4.5 is used. If any other input on X4 is set or used for other functions, then this method does not work with this firmware.



Attention:

From **LinMot drive firmware 6.8 Build 20190315** this method works too with boolean parameters.
E.g. for X4.5 set the parameter *Range Indicator 1 Minuend UPID* to **1C90h** (Inputs State Bit 0 (X4.5)) instead of **1C85h**. See screenshot below.

It is possible to connect a hardware switch to the LinMot drives X4 inputs (e.g. X4.5). The state of the digital input is then passed through to *iReference* of the SDC DI/DO Interface.

Setup the reference switch in the LinMot drive:


- For LinMot drive firmware 6.7:



- For LinMot drive firmware 6.8 Build 20190315 and newer replace the value in *Range Indicator 1 Minuend UPID* to **1C90h** (Inputs State Bit 0 (X4.5)) instead of **1C85h**

As example we want to use the following homing mode
(see B&R Automation Studio Help > search for mcHOME_ABS_SWITCH):

```
edge_sw = ncNEGATIVE
trigg_dir = ncPOSITIVE
fix_dir = ncOFF
```



Possible setup of the homing mode:

homing		Homing procedure	
init	ncTRUE	Homing procedure initialized	
status		Status	
parameter		Parameters	
s	0	Units	Reference position
v_switch	1000	Units/s	Speed for searching the reference switch
v_trigger	5000	Units/s	Trigger Speed
a	50000	Units/s ²	Acceleration
mode	ncABS_SWITCH	Mode	
edge_sw	ncNEGATIVE	Edge of reference switch	
start_dir	ncNEGATIVE	Start direction	
trigg_dir	ncPOSITIVE	Trigger direction	
ref_pulse	ncOFF	Reference pulse	
fix_dir	ncOFF	Fixed direction	
tr_s_block	1	Rev.	Distance for blocking the activation of 'triggering reference pulse'
torque_lim	0	Nm	Torque limit for homing on block
ds_block	1000	Units	Lag error for block detection
ds_stop	2000	Units	Lag error for stop of a movement

16.11 Test

After the LinMot drive is integrated as shown in the chapters before, the project can be compiled and downloaded to the PLC.


Attention:


It is recommended to rebuild the project and to **restart both the PLC and drives** to have a proper start-up. Ignoring this may prevent being able to power on the axis.

For testing purposes, the Test tool in Automation Studio can be used.

Open the Test from the NC mapping:

NC Object Name	PLC Address	Nc Obj...	Channel	Simulation	...
gAxis01	SDC_IF1.ST1	ncAXIS	1	Off	g...

For proper operation select *Parallel Mode*:



16.11.1 Switch On

To power on the motor execute the *Switch On* command:

- Use ncaction
- Trace enabled
-
-

- Command Interface
 - Preparation
 - Digital Inputs
 - Controller
 - Initialize
 - **Switch on**
 - Switch off
 - Homing
 - Basis Movement
 - Limits
 - Service Interface

Parallel mode

16.11.2 Homing

To home the axis (in this example a linear motor to hard stop) use the Homing command.

A possible homing configuration with mode ncBLOCK_DS

Name	Value	Unit	Description
homing	ncTRUE		Homing procedure
init			Homing procedure initialized
status			Status
parameter			Parameters
s	-1000	Units	Reference position
v_switch	5000	Units/s	Speed for searching the reference switch
v_trigger	5000	Units/s	Trigger Speed
a	50000	Units/s ²	Acceleration
mode	ncBLOCK_DS		Mode
edge_sw	ncPOSITIVE		Edge of reference switch
start_dir	ncNEGATIVE		Start direction
trigg_dir	ncPOSITIVE		Trigger direction
ref_pulse	ncOFF		Reference pulse
fix_dir	ncOFF		Fixed direction
tr_s_block	1	Rev.	Distance for blocking the activation of 'triggering reference pulse'
torque_lim	0	Nm	Torque limit for homing on block
ds_block	1000	Units	Lag error for block detection
ds_stop	2000	Units	Lag error for stop of a movement

16.11.3 Error Acknowledge

To acknowledge errors, press the button *Acknowledge Error* as long as an error is shown in the Watch:


PLCopen State: Errorstop

Error 31247: Drive Interface: DrvOK not set from HW Module

16.12 Parameter Access

16.12.1 Parameter access by LMcf_ParaAccess function block

Every parameter and variable in a LinMot system has its own UPID (Unique Parameter ID). Read and write access is possible using the LMcf_ParaAccess function block from the library LinMot.



Supported Modes

Value	Used Inputs	Description
0	UPIDIn	Read ROM Value of Parameter by UPID
1	UPIDIn	Read RAM Value of Parameter by UPID
2	UPIDIn, ValueIn	Write ROM Value of Parameter by UPID
3	UPIDIn, ValueIn	Write RAM Value of Parameter by UPID
4	UPIDIn, ValueIn	Write RAM and ROM Value of Parameter by UPID
5	UPIDIn	Get minimal Value of Parameter by UPID
6	UPIDIn	Get maximal Value of Parameter by UPID
7	UPIDIn	Get default Value of Parameter by UPID



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the life-time of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual
> see chapter Documentation / User Manuals



Note:

Further documentation about this function block can be found in the LinMot library manual.
See chapter 16.1.

16.12.2 Parameter access by SDO commands

Alternatively, also access by SDO is possible. For SDO access the B&R library *AsEPL* is required.
Function blocks: *EplSDORead()* & *EplSDOWrite()*

The Index specifies the LinMot parameter (UPID) to address. It is UPID + 16#2000.
The Sub-Index specifies the command which is performed

Index	Sub-Index	Description	Access Type
2000h -5FFFh		LinMot Parameter Commands	
UPID Commands			
	01h	RAM Value of UPID	Read & Write
	02h	ROM Value of UPID	Read & Write
	03h	Min Value of UPID	Read Only
	04h	Max Value of UPID	Read Only
	05h	Default Value of UPID	Read Only
	06h	RAM / ROM Write of UPID	Write Only
System Commands			
	07h	Set ROM to default (OS)	Write Only
	08h	Set ROM to default (MC)	Write Only
	09h	Set ROM to default (Interface)	Write Only
	0Ah	Set ROM to default (Application)	Write Only
	0Bh	Reset drive	Write Only
	35h	Stop MC and APPL Software	Write Only
	36h	Start MC and APPL Software	Write Only



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the life-time of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual
> see chapter Documentation / User Manuals

Possible variable declaration:

instLMAxis01_SdoWrite	EplSDOWrite
instLMAxis01_SdoRead	EplSDORead
udiDataWrite	UDINT
udiDataRead	UDINT

Possible function block calls where IF3 is the Powerlink interface:

```
// SDO read
instLMAxis01_SdoRead(pDevice:=ADR('IF3'), pData:=ADR(udiDataRead));

// SDO write
instLMAxis01_SdoWrite(pDevice:=ADR('IF3'), pData:=ADR(udiDataWrite));
```

Example read parameter:

Read the RAM value of the parameter Maximal Current:

Name: Maximal Current

UPID: 13A6h

Type: SInt32 = DINT = 4 Bytes

Scale: 0.001 A

pDevice := pointer to POWERLINK interface, e.g. **ADR('IF3')**
node := 1 (Node ID of the LinMot drive)
index := **13222 = 16#33a6** = 16#2000 + 16#13a6
subindex := 1 (access RAM value)
pData := pointer to data buffer, e.g. **ADR(udiDataRead)**
datalen := 4 (always 4 Bytes! Even if the parameter to read is less)

instLMAxis01_SdoRead	EpISDORRead	local	
enable	BOOL		TRUE
pDevice	UDINT		69733729
node	USINT		1
index	UINT		13222
subindex	USINT		1
pData	UDINT		69735842
datalen	UDINT		4
status	UINT		65535
errorinfo	UDINT		16#0000_0000
readlen	UDINT		4
intem	EPL_I_TYPE		
udiDataRead	UDINT	local	15000

Example write parameter:

Write 1A to the RAM value of the parameter Maximal Current:

Name: Maximal Current

UPID: 13A6h

Type: SInt32 = DINT = 4 Bytes

Scale: 0.001 A > value to be sent = 1'000

pDevice := pointer to POWERLINK interface, e.g. **ADR('IF3')**
node := 1 (Node ID of the LinMot drive)
index := **13222 = 16#33a6** = 16#2000 + 16#13a6
subindex := 1 (access RAM value)
pData := pointer to data buffer, e.g. **ADR(udiDataWrite)**
datalen := 4 (always 4 Bytes! Even if the parameter to read is less)


instLMAxis01_SdoWrite	EpISDOWrite	local	
enable	BOOL		TRUE
pDevice	UDINT		69733783
node	USINT		1
index	UINT		13222
subindex	USINT		1
pData	UDINT		69735838
datalen	UDINT		4
status	UINT		65535
errorinfo	UDINT		0
intem	EPL_I_TYPE		
udiDataWrite	UDINT	local	1000

16.13 Add Additional Parameters or Variables to the Process Data

It is possible to add up to 4 parameters or variables to the cyclic PDO of the drive. This allows fast read/write access.

Right-click on the drive and select *Configuration*.

- Set the **Cyclic transmission** to either *Read* (for read access from the drive) or *Write* (for write access to the drive) in the “Channels”.
- As **Init value** in the “Device specific parameters” set the UPID number (e.g. Maximal Current has UPID 16#13A6 > 5030 decimal) of the parameter you want to access.



Afterwards you can assign a PV in the I/O configuration of the device.

16.14 Errors (LM_Sdclf outputs)

16.14.1 bError

This output indicates that an error occurred either in the *LM_Sdclf* function block itself, in the used libraries (LinMot, Sys_Lib or ArEventLog) or in the LinMot drive. The source is shown by the *diStatusID* output.

16.14.2 diStatusID

diStatusID shows the actual status of the *LM_Sdclf* function block. The following values are valid.

Parameter	Value	Description
enLM_SDCIF_ERR_OK	0	No Event ID: No error
enLM_SDCIF_INF_FUB_ENABLE_FALSE	1610612736	Function block not enabled
enLM_SDCIF_WRN_LIB_LINMOT	-1610612736	Library LinMot: Warning
enLM_SDCIF_ERR_LIB_CONFIG_AXNAME	-536870912	Object at parameter "pszAxisName" or "pszSDCHWName" not found or null. Or PV names (pszSDC...) too long (>34 characters)
enLM_SDCIF_ERR_LIB_SYS_LIB	-536870911	Library Sys_Lib: Error
enLM_SDCIF_ERR_LIB_LINMOT	-536870910	Library LinMot: Error
enLM_SDCIF_ERR_LIB_AREVENTLOG	-536870909	Library ArEventLog: Error

16.14.3 uiErrorCode

If the LinMot drive has an error this is indicated by:

- *diStatusID* value of -536870910 (enLM_SDCIF_ERR_LIB_LINMOT)
- *uiErrorCode* output greater than 0 (zero)

A list of possible *uiErrorCode* values can be found in either the MS_SW manual or within LinMot-Talk (Menu > Manuals > Errors > MC Layer).

It is possible to read the error message (English only) as STRING using the function block *LMcf_GetErrorText* from the library LinMot.

inst_LMGetErrorText	LMcf_GetErrorTxt	
Execute	BOOL	TRUE
ErrorCode	UINT	11
Done	BOOL	TRUE
Busy	BOOL	FALSE
ErrorText	STRING[80]	'Err: Pos Lag Always Too Big'
Error	BOOL	FALSE
ErrorID	UINT	0
Axis	UDINT	65872452



Note:

Further documentation about this function block can be found in the LinMot library manual.
See chapter 16.1.

17 Drive Profile: OMRON Sysmac Studio, CoE DS402

17.1 Overview

This chapter shows how LinMot drives with *DS402 (CoE) / CiA402* interface (e.g., C1250-DS-XC-1S) can be integrated and setup in an OMRON N-Series (NJ, NX, NY) environment.



For this example, **Sysmac Studio V1.50** and **LinMot-Talk V6.11** were used.

Download:

Example projects can be downloaded from:

http://download.linmot.com/plc_lib/examples/Omron_DS/ (named: *prjLinMotDS402_fwV6.10_Nx1.smc2*)



Image Source: <http://www.omron.com/>

EtherCAT is the real-time Ethernet network originally developed by Beckhoff. The LinMot drives acts as slaves in this network and are implemented with either the standard ASIC ET1100 from Beckhoff or Hilscher NETX.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>



Note:

In this chapter the following Modes of Operation of the DS402 / CiA402 profile are used:

6 = homing mode

8 = cyclic synchronous position (csp)

10= cyclic synchronous torque (cst)

The modes are switched by setting object 6060h (Mode of operation) to the according value.
The drive shows the active mode in object 6061h (Mode of operation display).

17.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:
<http://www.linmot.com/download/linmot-talk-drive-configuration/>

17.2.1 Motor Configuration


It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Only select a homing mode in the Motor Wizard in case of a drive-based homing (e.g., *Mechanical Stop Negative Search*). Otherwise, *No Drive Homing* must be selected.



See Appendix I: Basic Position Control Loop Tuning



For **Drive Based Homing** please refer to chapter 17.5

17.2.2 XML File

Install the XML file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML\
- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML\ (-MI drives)





XML file names:

NTIL_CiA402_Servos_Vx_xrx.xml	LinMot DS drives SG6-7
NTIL_CiA402_SG5_Servos_Vx_xrx.xml	LinMot DS drives SG5
NTIL_CiA402_Servos_MI_Vx_xrx.xml	LinMot MI drives SG6

17.2.3 EtherCAT Connection

The drive is connected to the EtherCAT network using the X17 (IN) & X18 (OUT) connectors.

The below pictures show the ports of an E1250-DS-UC drive. On all other LinMot drives supporting EtherCAT DS402 / CiA402 the ports are named the same (X17 & X18), but they may be placed differently on the drive housing.




17.3 PLC Setup

17.3.1 Install EtherCAT Device Description File XML


Find the most recent *ESI* file as described in chapter **17.2.2 XML File**.

Install this file as follows:


- When Offline with the PLC, double-click *EtherCAT* under *Configuration and Setup* in the Multiview Explorer. The *EtherCAT Edit Tab* page is displayed.



- Scan EtherCAT network by right-click *Master* in the *Network configuration* and select *Compare and Merge with Actual Network Configuration*



3. Install XML file



17.3.2 Define EtherCAT node address on LinMot-Device

The accepted address range depends on the used PLC.

NJ, NX1: 1...192

NX7/NY: 1...512




OMRON does not support implicit addressing. But **Node address “0”** can be addressed by Sysmac Studio or with additional function blocks in the user program.


17.3.2.1 Set node address by address selector on device

This is the most popular way, because it is user-friendly to maintenance people.

1. Select ID Switches



2. Depending on the LinMot-Drive the address selector is designed as Hex- or DIP-Switch.



17.3.2.2 Set node address by parameter on device

The node address can be defined by parameter.

3. Select Parameter

Name	Value
None	Off
ID Switches	Off
ID Switches + Parameter	Off
RT MAC	Off
Parameter	On
Masked RT MAC and Parameter	Off

4. Enter desired node address within the allowed range of your Omron PLC

Name	Value	Raw Data
Alias Address Source	Parameter	0007h
Alias Address Parameter	11	000Bh
Alias Address Parameter Mask	32768	8000h


17.3.2.3 Write node address from Sysmac Studio

The node address can be written to the slave from *Sysmac Studio* (OMRON Software license required!).




This feature is currently not supported for **-MI** Drives


1. Select *None* and reboot drive




2. When *Online* with the PLC double-click *EtherCAT* under *Configuration and Setup* in the Multiview Explorer. The *EtherCAT Edit Tab* page is displayed.



3. Open the writing-tool by right-click *Master* in the *Network configuration* and select *Write Slave Node Address*



4. Enter the desired node address within the allowed range of your Omron PLC and reboot drive.



17.3.2.4 Set node address by function block




This feature is currently not supported for -MI Drives

Omron supports a library with extended functions for EtherCAT:


EthercatExtendedFunctions.slr

1. Select None and reboot drive



2. Use function block **EEF_SlaveAddress** to set a node address to the desired drive and reboot the drive.

You may use function block **EEE_EtherCAT_Scan** to check the EtherCAT network before and after writing a slave address.




The OMRON library *EthercatExtendedFunctions.slr* can be requested by your local Omron support. It is an additional Library made by Omron ATC in Barcelona.


17.3.3 Scanning the EtherCAT network for devices

Follow these steps to add LinMot drives to your OMRON PLC.


- When *Online* with the PLC double-click *EtherCAT* under *Configuration and Setup* in the Multiview Explorer. The *EtherCAT Edit Tab* page is displayed.



- Scan the EtherCAT network by right-click on the *Master* in the *Network configuration* and select *Compare and Merge with Actual Network Configuration*



- Apply the actual network found by the EtherCAT Master.



17.3.4 Edit PDO mapping

The following steps show how to setup the PDO mapping.




For standard (minimal) functionality, no change of the PDO mapping is required.


The less PDO's are mapped the less bandwidth is required - and therefore the performance of EtherCAT fieldbus will be higher.

1. Open PDO Map Dialog:

When Offline with the PLC first choose the desired drive then select *Edit PDO Map Settings*.




2. For full functionality (Position- AND Force/Torque-Control) choose *Cyclic Position Velocity Torque Mode* for Output. For Input choose *Cyclic Mode Input 2*.



3. For cyclic PDO transmission of any drive value/parameter choose **Par Channel X** for Output and **Mon Channel X** for Input.
Please refer to chapter 17.8.1 for more information.

4. When Force/Torque must be limited on Position-Control-Mode, choose in addition **Torque/Force limits**.




17.3.5 Create a motion axis and link it to your physical LinMot axis

Follow these steps to use the LinMot axis as a motion axis on your OMRON PLC.


5. Create a motion axis:

When *Offline* with the PLC right-click *Axis Setting* → *Add* → *Axis Setting* under *Configuration and Setup* → *Motion Control Setup* in the Multiview Explorer.




6. First assign a meaningful name to the axis.

Right-click on your motion axis and select *Rename*.




7. Set axis type.

Open edit-window of motion axis and set *Axis type* to *Servo axis*.



8. Link physical axis to the motion axis:


Select desired EtherCAT-Node on *Output device 1*.



9. Assign PDO's of the axis

Select *Detailed Settings* and assign Out- and Inputs as shown below.

(Entries marked with a star are the minimal entries required from Sysmac. In addition, *Target velocity* should be assigned to achieve better/smooth performance of the LinMot).



10. OPTIONAL: When using drive-based-homing, assign the Actual-Position of Drive in the PDO mapping to synchronise it with the position value of the Motion-Axis on PLC.

Open *Configuration and Setup* → *I/O MAP* in the Multiview Explorer. Select desired node and assign PDO 6064h as shown below.

For detail description refer to chapter 17.5 (drive-based-homing).

Multiview Explorer	EtherCAT	MC_PR_Lin (0,MC1)	I/O Map	subDriveBasedHome_Ho.....			
		Port	Des R/W	Data Type	Variable	Variable Comm	Variable Type
		EtherCAT Network Configuration					
Node11	C1150-DS-XC-05						
	Cyclic Position Velocity Tor_Controlword_6040_00		W	UINT			
	Cyclic Position Velocity Tor_Target position_607A_00		W	DINT			
	Cyclic Position Velocity Tor_Target velocity_60F_F_00		Cc W	DINT			
	Cyclic Position Velocity Tor_Target torque_6071_00		W	INT			
	Cyclic Position Velocity Tor_Mode of Operation_6060_00		W	SINT			
	Torque/force limits_TorqueLimitPositiv_60E0_00		W	UINT			
	Torque/force limits_TorqueLimitNegativ_60E1_00		W	UINT			
	Par Channel 1_Par Channel 1_20B0_00		W	DINT	diSpeedLimit	UPID 1511h	prgPR_Lin Internal
	Cyclic Mode Inputs 2_Statusword_6041_00		R	UINT			
	Cyclic Mode Inputs 2_Position actual value (uni_6064_00)		R	DINT	diActPos		prgPR_Lin Internal
	Cyclic Mode Inputs 2_Position demand value_6062_00		R	DINT			
	Cyclic Mode Inputs 2_Torque actual value_6077_00		R	INT			
	Cyclic Mode Inputs 2_Mode of Operation display_6061_00		R	SINT			
	Input ActVel_ActualVelocity_1B8E_00		R	DINT			
	Mon Channel 1_Mon Channel 1_20A8_00		R	DINT	diActualForce	UPID 1BFFh	prgPR_Lin Internal
	Mon Channel 2_Mon Channel 2_20A9_00		R	DINT	dwExtStatusWord	UPID 1DD0h	prgPR_Lin Internal
Node12	C1250-DS-XC-05						

17.3.6 Setting up the motion axis

The following steps show how to basically setup the motion axis.

1. Set axis unit:

Choose *Unit Conversion Settings* in the Edit-Window of your axis and set *Unit* to “mm”.

Linear	Rotative (e.g., RS01 w/o gearbox)
Unit mm	Unit degree
Travel Distance Work travel distance per motor rotation 10000 pulse/rev (1)	Travel Distance Command pulse count per motor rotation 360000 pulse/rev (1)
Do not use gearbox Work travel distance per motor rotation 10000 mm/rev (2)	Do not use gearbox Work travel distance per motor rotation 360 degree/rev (2)
Use gearbox Work travel distance per work rotation 10000 mm/rev (3)	Use gearbox Work travel distance per work rotation 10000 degree/rev (3)

2. Set axis scaling:

Set *Travel Distance* to standard value 10'000:1 [Ticks/mm] on linear axis or 360'000:360 [Ticks/rotation] on rotary axis.



For rotary motors, choose your desired work travel distance according to your mechanical system (gearbox, belt transmission, pinion etc.)

Linear	Rotative (e.g., RS01 w/o gearbox)
Unit mm	Unit degree
Travel Distance Work travel distance per motor rotation 10000 pulse/rev (1)	Travel Distance Command pulse count per motor rotation 360000 pulse/rev (1)
Do not use gearbox Work travel distance per motor rotation 10000 mm/rev (2)	Do not use gearbox Work travel distance per motor rotation 360 degree/rev (2)
Use gearbox Work travel distance per work rotation 10000 mm/rev (3)	Use gearbox Work travel distance per work rotation 10000 degree/rev (3)

3. Set axis velocity limits:


Choose *Operation Settings* and set your desired values at least into *Velocity* fields.

The screenshot shows two side-by-side configuration windows for 'MC_DS (0)' and 'MC_C100_PR_Lin (0,MCI)'. Both windows have tabs for 'Linear' and 'Rotative (e.g., RS01 w/o gearbox)'. Under the 'Operation Settings' tab, there are sections for 'Velocity/Acceleration/Deceleration' and 'Torque'. In the 'Velocity/Acceleration/Deceleration' section, the 'Maximum velocity' field is set to 5000 mm/s for the linear axis and 9000 degree/s for the rotative axis. The 'Maximum jog velocity' field is set to 10 mm/s for the linear axis and 360 degree/s for the rotative axis. Red arrows point to these fields in both windows.

4. Set axis torque limits:

In case force/torque must be limited in Position-Control-Mode, set torque limit to **500.0%**.

Use motion instruction **MC_SetTorqueLimit** to limit force/torque of your motor.



Linear and/or Rotative (e.g., RS01 w/o gear)


The screenshot shows the 'Other Operation Settings' window for both 'MC_DS (0)' and 'MC_C100_PR_Lin (0,MCI)'. It includes sections for 'Immediate stop input stop method', 'Drive error reset monitoring time', 'Maximum positive torque limit' (set to 500.0%), and 'Maximum negative torque limit' (set to 500.0%). Red arrows point to the 'Maximum positive torque limit' and 'Maximum negative torque limit' fields.

5. Configure ABS encoder and Modulo:

In case of using a LinMot rotary motor (with single turn ABS encoder) or an external ABS encoder for linear motors, *Absolute encoder* must be selected. To use modulo functionality, select *Rotary mode*.

The screenshot shows two 'Position Count Settings' windows. The left one is for 'MC_PR_Lin (0,MCI)' and the right one is for 'MC_C100_PR_Rot (1,MCI)'. Both show 'Count mode' as 'Linear mode'. The 'Modulo maximum position setting value' is set to 360 degree for the rotative axis. The 'Encoder type' dropdown is set to 'Absolute encoder' for both. Red arrows point to the 'Encoder type' dropdown in both windows.

- Transfer program to your PLC:
Go Online and *Transfer*



17.4 Homing procedure on Sysmac with ABS Encoder

When using ABS encoder, there is no need for any homing procedure.

Device name	Name	Online value	Modify
new_Controller_0	MC_C1200_PR_Rot.Act.Pos	29.04	TRUE FALSE
new_Controller_0	MC_C1200_PR_Rot.Details.Homed	True	

Monitoring

Connection Status: Online
Firmware Status: Running
Motor Status: Switched On

Op. State: Ready to Operate

Actual Position: 29.04 °
Demand Position: 29.04 °
Force Factor: 100.00 %
Motor Current: 0.00 A
Logic Supply Volt.: 23.96 V
Motor Supply Volt.: 72.48 V


17.5 Drive Based Homing (INC Encoder)

In general, the easiest way to home a linear motor is to use homing routines predefined in the servo drive.

17.5.1 Settings on LinMot drive

The following setting are required on the drive.

- Use *Motor Wizard* to define a homing routine.



17.5.2 Function blocks required on Sysmac

To operate a drive-based homing the following function blocks are used.

17.5.2.1 EC_CoESDORead

With this function block, the status word of the physical LinMot axis will be read.

Variables to declare:

	Data type	Value
Function block	EC_CoESDORead	
SDO Parameter	_sSDO_ACCESS	Index := 16#3D51, Subindex := 1
Read Data	ARRAY[0..3] OF WORD	Located in [0]

17.5.2.2 EC_CoESDOWrite

With this function block, the homing procedure will be executed and stopped.

Variables to declare:

	Data type	Value
Function block	EC_CoESDOWrite	
SDO Parameter	_sSDO_ACCESS	Index := 16#33F7, Subindex := 1 Index := 16#341F, Subindex := 1
Write Data	WORD	16#0 (FALSE) or 16#1 (TRUE)
Write Data Size	UINT	2 (Bytes to write)

17.5.2.3 MC_ResetFollowingError

With this function block, the position lag on the motion axis will be reset.

Variables to declare:

	Data type	Initial Value
Function block	MC_ResetFollowingError	

17.5.2.4 MC_HomeWithParameter

With this function block, the PLC motion axis will be homed.


Variables to declare:

	Data type	Initial Value
Function block	MC_HomeWithParameter	
Homing Parameter	_sHOMING_REF	(HomingMode := _mcHomePreset) others irrelevant


17.5.3 Homing procedure on Sysmac (motors with INC Encoder)

This section describes the *Drive Based Homing* sequence.


1. Use MC_Power instruction to make axis ready to operate.



2. Read Status-Word of LinMot drive while homing to check Homed Bit.




3. Execute homing by setting the *Home* within the *Control Word* to TRUE.




4. Clear the following-error of motion axis during *Drive Based Homing* otherwise malfunction can occur (e.g., when homing long stroke).

It must be cleared, because Sysmac does not update the axis position during Drive Based Homing.




PLC Commissioning


5. a) Observe Homed Bit in Status-Word of LinMot drive.
- b) When axis is homed, may wait a short time, until the axis does not oscillate due mechanical construction.
- c) Use Actual-Positionⁱ⁾ of LinMot drive as offset for MC_Homing on PLC.



i) Map a variable in I/O Map to have Actual-Position available. Also refer to chapter 17.3.5 10)




6. Reset homing by setting the *Home* within the *Control Word* to FALSE.



17.6 Drive reset to clear axis error

To acknowledge an error of a DS402 / CiA402 drive, use the standard motion instruction ***MC_Reset***.




17.7 Control of force / torque

17.7.1 Limiting force or torque output in Position-Control-Mode

To limit output torque/force of a DS402 / CiA402 servo drive, use standard motion instruction ***MC_SetTorqueLimit***. Please make sure, the necessary PDOs are mapped.

Detailed Settings		
	Function Name	Device
-	Output (Controller to Device)	
★ 1. Controlword	Node : 11 C1150-DS-XC-0S(E002)	6040h-00.0(Cyclic Position Velocity Tor_Controlword_6040_00)
★ 3. Target position	Node : 11 C1150-DS-XC-0S(E002)	607Ah-00.0(Cyclic Position Velocity Tor_Target position_607A_00)
5. Target velocity	Node : 11 C1150-DS-XC-0S(E002)	60FFh-00.0(Cyclic Position Velocity Tor_Target velocity_60FF_00)
7. Target torque	Node : 11 C1150-DS-XC-0S(E002)	6071h-00.0(Cyclic Position Velocity Tor_Target torque_6071_00)
9. Max profile Velocity	<Not assigned>	<Not assigned>
11. Modes of operation	Node : 11 C1150-DS-XC-0S(E002)	6060h-00.0(Cyclic Position Velocity Tor_Mode of Operation_6060_00)
15. Positive torque limit value	Node : 11 C1150-DS-XC-0S(E002)	60E0h-00.0(Torque/force limits_TorqueLimitPositiv_60E0_00)
16. Negative torque limit value	Node : 11 C1150-DS-XC-0S(E002)	60E1h-00.0(Torque/force limits_TorqueLimitNegativ_60E1_00)
21. Touch probe function	<Not assigned>	<Not assigned>
44. Software Switch of Encoder's Input Slave	<Not assigned>	<Not assigned>
Input (Device to Controller)		
★ 22. Statusword	Node : 11 C1150-DS-XC-0S(E002)	6041h-00.0(Cyclic Mode Inputs 2_Statusword_6041_00)
★ 23. Position actual value	Node : 11 C1150-DS-XC-0S(E002)	6064h-00.0(Cyclic Mode Inputs 2_Position actual value (uni_6064_00))
24. Velocity actual value	<Not assigned>	<Not assigned>
25. Torque actual value	Node : 11 C1150-DS-XC-0S(E002)	6077h-00.0(Cyclic Mode Inputs 2_Torque actual value_6077_00)
27. Modes of operation display	Node : 11 C1150-DS-XC-0S(E002)	6061h-00.0(Cyclic Mode Inputs 2_Mode of Operation display_6061_00)
40. Touch probe status	<Not assigned>	<Not assigned>
41. Touch probe pos1 pos value	<Not assigned>	<Not assigned>
42. Touch probe pos2 pos value	<Not assigned>	<Not assigned>




Value 500.0% equals to max. force or torque.

17.7.2 Control force or torque output in Torque-Control-Mode (CST Mode 10)

To control output torque/force of a DS402 servo drive, use standard motion instruction **MC_TorqueControl**. Please make sure, necessary PDOs are mapped, and parameter settings on drive are done correctly.

Detailed Settings			
Function Name		Device	Process Data
- Output (Controller to Device)			
★ 1. Controlword	[Node : 11 C1150-DS-XC-0S(E002)]	6040h-00.0(Cyclic Position Velocity Tor_Controlword_6040_00)	
★ 3. Target position	[Node : 11 C1150-DS-XC-0S(E002)]	607Ah-00.0(Cyclic Position Velocity Tor_Target position_607A_00)	
5. Target velocity	[Node : 11 C1150-DS-XC-0S(E002)]	60FFh-00.0(Cyclic Position Velocity Tor_Target velocity_60FF_00)	
7. Target torque	[Node : 11 C1150-DS-XC-0S(E002)]	6071h-00.0(Cyclic Position Velocity Tor_Target torque_6071_00)	
9. Max profile Velocity	<Not assigned>	<Not assigned>	
11. Modes of operation	[Node : 11 C1150-DS-XC-0S(E002)]	6060h-00.0(Cyclic Position Velocity Tor_Mode of Operation_6060_00)	
15. Positive torque limit value	[Node : 11 C1150-DS-XC-0S(E002)]	60E0h-00.0(Torque/force limits_TorqueLimitPositiv_60E0_00)	
16. Negative torque limit value	[Node : 11 C1150-DS-XC-0S(E002)]	60E1h-00.0(Torque/force limits_TorqueLimitNegativ_60E1_00)	
21. Touch probe function	<Not assigned>	<Not assigned>	
44. Software Switch of Encoder's Input Slave	<Not assigned>	<Not assigned>	
- Input (Device to Controller)			
★ 2. Statusword	[Node : 11 C1150-DS-XC-0S(E002)]	6041h-00.0(Cyclic Mode Inputs 2_Statusword_6041_00)	
★ 23. Position actual value	[Node : 11 C1150-DS-XC-0S(E002)]	6064h-00.0(Cyclic Mode Inputs 2_Position actual value (uni_6064_00)	
24. Velocity actual value	<Not assigned>	<Not assigned>	
25. Torque actual value	[Node : 11 C1150-DS-XC-0S(E002)]	6077h-00.0(Cyclic Mode Inputs 2_Torque actual value_6077_00)	
27. Modes of operation display	[Node : 11 C1150-DS-XC-0S(E002)]	6061h-00.0(Cyclic Mode Inputs 2_Mode of Operation display_6061_00)	
40. Touch probe status	<Not assigned>	<Not assigned>	
41. Touch probe pos1 pos value	<Not assigned>	<Not assigned>	
42. Touch probe pos2 pos value	<Not assigned>	<Not assigned>	



Torque 500.0% equals to max. force or torque.



The **Velocity** input of MC_TorqueControl is currently not supported for LinMot drives.
Use the Speed Limiter instead

17.7.2.1 Speed Limiter for Torque/Force-Control-Mode

To prevent overspeed while controlling force or torque, use the Speed Limiter.

Name	Value	Raw Data	Value...	UPID
Speed Limit	0 %/s	0000000h	*** %/s	1511h
Speed Limiter Abort Force	0 Nm	0000h	*** Nm	1513h


When the motor speed reaches *Speed Limit*, the drive switches to Position-Controlled-Mode.
The selected Control parameter Set (A or B) will become active!



Switching from Force/Torque- to Position-Mode and vice versa while the motor is moving, will always cause a bumpy behaviour.
Smoother reaction can be achieved by adjusting PID values of the corresponding control loops.

17.7.2.2 Torque/Force-Control-Mode in CST Mode 10


If using an additional force or torque sensor, Closed-Loop Control Mode must be selected on drive.



0000h: Current Command Mode

This mode is only for reverse compatibility with FW older than V6.10!


Use Cyclic Mode Inputs at PDO Map



0001h: Force/Torque Control Mode

This mode corresponds to DS402.


Use Cyclic Mode Inputs 2 at PDO Map



0002h: Closed-Loop Force/Torque Control Mode


In addition to 0001h: Force/Torque Control Mode, this mode requires TF-Force Control (Technology Function).
LinMot-Article: [0150-2503](#)

It is used in combination with an external torque or force sensor such as TS01 or TS02 on a PR-module.
These sensors must be wired directly to the drive.



Make sure all parameters in Analog Force Feedback Control are set correctly.

If using this closed-loop mode, use [Cyclic Mode Inputs 2](#) at PDO Map.



17.8 Parameter Access

17.8.1 PDO Access


For cyclical write or read access of any parameter or variables, up to 4 channels each can be used.



OMRON does not support *User Defined In- or Outputs* for PDO. Please use up to 4 Parameter and Monitoring Channel each instead.

If no real-time access is required, use SDO for reading or writing values/parameters.

- Use parameter channels for cyclical write access.
- Use monitoring channels for cyclical read access.





17.8.2 Example for user defined PDO access

In this example two channels each are used for a PR02-module (rotary motor for torque control).

17.8.2.1 PDO Map

Use *Edit PDO Map Settings* at desired EtherCAT node.



17.8.2.2 I/O Map

On the drive assign UPID *Actual Torque* to and *Extended Status Word* to the **Monitoring** Channels

The screenshot shows the SIMATIC Manager interface with the following details:

- Project:** Lin offline (User) LinRot88_DS402.lmc
- Control Panel Parameters:**
 - EtherCAT CiA402
 - Monitoring Channels
- I/O Map:**

Name	Value
Channel 1 UPID	1BBFh (Actual Torque)
Channel 2 UPID	1DD0h (Extended Status Word)
Channel 3 UPID	0000h
Channel 4 UPID	0000h

And to the **Parameter** Channels assign UPID of *Speed Limit* and *Speed Limiter Abort Force*.

The screenshot shows the SIMATIC Manager interface with the following details:

- Project:** Lin offline (User) LinRot88_DS402.lmc
- Control Panel Parameters:**
 - EtherCAT CiA402
 - Parameter Channels
- I/O Map:**

Name	Value
Channel 1 UPID	1511h (Speed Limit)
Channel 2 UPID	1513h (Speed Limiter Abort Force)
Channel 3 UPID	0000h
Channel 4 UPID	0000h

On Sysmac assign a DINT or a DWORD to the selected PDO channels.

The screenshot shows the Multiview Explorer and I/O Map interface with the following details:


- Multiview Explorer:**
 - new_Controller_0
 - Configurations and Setup
 - EtherCAT
 - CPU/Expansion Racks
 - I/O Map (selected)
 - Controller Setup
 - Motion Control Setup
 - Cam Data Settings
 - Event Settings
 - Task Settings
 - Data Trace Settings
 - Speed Limiter
 - OPC UA Settings
 - Programming
- I/O Map:**

Position	Port	Descr	R/W	Data Type	Variable	Variable Comm	Variable Type
Node11	C1150-DS-XC-05						
Node12	C1250-DS-XC-05						
	Cyclic Position Velocity Tor_Controlword_6040_00		W	UINT			
	Cyclic Position Velocity Tor_Target position_607A_00		W	DINT			
	Cyclic Position Velocity Tor_Target velocity_60FF_00		W	DINT			
	Cyclic Position Velocity Tor_Target torque_6071_00		W	INT			
	Cyclic Position Velocity Tor_Mode of Operation_6060_00		W	SINT			
	Torque/force limits.TorqueLimitPositiv_60E0_00		W	UINT			
	Torque/force limits.TorqueLimitNegativ_60E1_00		W	UINT			
	Par Channel 1_Par Channel 1_20B0_00		W	DINT	diSpeedLimit	UPID 1511h	prgPR_Rot Internals
	Par Channel 2_Par Channel 2_20B1_00		W	DINT	diSpeedLimitAbort	UPID 1513h	prgPR_Rot Internals
	Cyclic Mode Inputs 2_Statusword_6041_00		R	UINT			
	Cyclic Mode Inputs 2_Position actual value_6064_00		R	DINT			
	Cyclic Mode Inputs 2_Position demand value_6062_00		R	DINT			
	Cyclic Mode Inputs 2_Torque actual value_6077_00		R	INT			
	Cyclic Mode Inputs 2_Mode of Operation display_6061_00		R	SINT			
	Input ActVel_ActualVelocity_188E_00		R	DINT			
	Mon Channel 1_Mon Channel 1_20A8_00		R	DINT	diActualTorque	UPID 1BBFh	prgPR_Rot Internals
	Mon Channel 2_Mon Channel 2_20A9_00		R	DINT	dwExtStatusWord	UPID 1DD0h	prgPR_Rot Internals

17.8.2.3 Scaling of mapped PDO

Check scale and offset of all used UPIDs and recalculate them on Sysmac

Example Actual Torque:




The screenshot shows the OMRON Sysmac Studio interface. On the left, a tree view of variables is shown, with 'MC SW Motor' selected. On the right, a table displays various motor parameters with their UPID, type, scale, offset, and current values. Below the table, there are 'Scale' and 'Offset' buttons. At the bottom, a code editor window shows the following ladder logic and comments:

```


1 //Rotary motor; Actual Torque 1BFFh
2 IrActualTorque_Nm ▶ -0.108456 := DINT_TO_LREAL(diActualTorque ▶ -108456) / 1000000; // Newtonmeter
3 IrActualTorque_inchlbs ▶ -0.9599164 := IrActualTorque_Nm ▶ -0.108456 / 0.112984829; // Inch-pounds
4

```

Example Speed Limit and Speed Limit Abort Force:




→ Check the value of the parameter always in RAM




The screenshot shows the parameter configuration table for module 3805.752.001: Rot. The table lists parameters such as 'Speed Limit' and 'Speed Limiter Abort Force' with their current values, raw data, UPID, type, scale, offset, and limits.

Name	Value	Raw Data	Value (RAM)	UPID	Type	Scale	Offset	Min	Max	Dt
Speed Limit	0 */s	0000000h	359.99964723873 */s	1511h	SInt32	0.0099999068677425 */s	0 */s	0 */s	21474816.47 */s	0
Speed Limiter Abort Force	0 Nm	0000h	2.00019566280169 Nm	1513h	UInt16	0.00057295779513082 Nm	0 Nm	0 Nm	18.7741080730516 Nm	01

Example Speed Limiter Active:

→ For Bit variables DWORD instead of DINT can be used to make masking easier.




17.8.3 SDO Access

Parameters of the LinMot drive can be accessed using the Omron function block *EC_CoESDORead* and *EC_CoESDOWrite* which are part of Sysmac library.

More information about this function blocks can be found in the *Instructions Reference Manual (W502)* from Omron:

<https://industrial.omron.eu/en/home> (search for W502)

Example calls of this function blocks can be found in the example project (see chapter 17.1).



NodeAddr: EtherCAT-Slave node address

SdoObj.Index: Parameter address to be accessed = **16#2000** + UPID

SdoObj.Subindex: Parameter memory area to be accessed.
01: Read and write the **RAM** value of the UPID.
02: Read and write the **ROM** value of the UPID.



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual
> see chapter Documentation / User Manuals



Note:

Use *EC_CoESDORead* and *EC_CoESDOWrite* from Omron to access drive parameters.



Advanced: Stop / Start MC and Application SW and reboot drive

The SDO-index 16#2000 allows

1. Stopping the MC and Appl SW for flash access or to setup the drive from the PLC
2. Starting the MC and Appl SW after flash access and to load changed ROM values to RAM,
3. Rebooting the drive (warm start).

Subindex 16#35 ► Stop MC and Application SW

Subindex 16#36 ► Start MC and Application SW

Subindex 16#0B ► Reboot drive

18 Drive Profile: TRIO, CiA402

18.1 Overview

This chapter shows how a LinMot drive with *DS402 (CoE) / CiA402* interface (e.g., C1250-DS-XC-1S) can be integrated and setup as axis in a TRIO motion controller.

Download:

An example project can be downloaded from:

http://download.linmot.com/plc_lib/examples/TRIO (named *LM_TRIO_DS_Demo...*)



Attention:

Drive firmware **6.10 Build 20210521 or later** is required to use all the functionality shown in this chapter.

Components used:

- LinMot C1250-DS-XC-1S-000 (article number 0150-2416) with firmware 6.10 Build 20210521
- TRIO MC4N ECAT (P904) v2.0309
- Motion Perfect v5.1.1




Image Source: <http://www.triomotion.uk/>

EtherCAT is the real-time Ethernet network originally developed by Beckhoff. The LinMot acts as Slave in this network and is implemented with the standard ASIC ET1100 from Beckhoff.

For further information on the EtherCAT fieldbus please visit:

<http://www.ethercat.org/>

18.2 Configuration and Connection of the LinMot Drive

The LinMot drive is configured using the LinMot-Talk software:

<http://www.linmot.com/download/linmot-talk-drive-configuration/>

18.2.1 Motor Configuration

It is assumed that the motor connected to the drive is already configured.



Use the *Motor Wizard* inside LinMot-Talk to setup the motor (Menu -> Drive -> Motor Wizard):



Make sure that you select "No Drive Homing" in the Motor Wizard as with TRIO the homing of the axis is done in the PLC (DS402 mode of operation 6 is not yet supported).

Step 7/10: Homing I

Home Position Search Move

Speed: 0.01 m/s

Mode: No Drive Homing

The drive executes no homing, at power up the homed bit in the Status Word is already set. Mainly used in drive profile applications, where the homing is made in the superior system.

Derived Settings	Value	Comment

Help < Back Next > Finish Cancel Create MDF



See Appendix I: Basic Position Control Loop Tuning

18.2.2 XML File

Install the XML file that is part of the LinMot-Talk software/firmware you are using.

The most recent device files are always part of the newest LinMot-Talk software. They are located by default:

- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCAT\XML\
- EtherCAT CoE: \\LinMot-Talk X.X Build XXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML\ (-MI drives)




XML file names:

NTIL_CiA402_Servos_Vx_xrx.xml	LinMot DS drives SG6-7
NTIL_CiA402_SG5_Servos_Vx_xrx.xml	LinMot DS drives SG5
NTIL_CiA402_Servos_MI_Vx_xrx.xml	LinMot MI drives SG6

18.2.3 EtherCAT Connection

The drive is connected to the EtherCAT network using the X17 (IN) & X18 (OUT) connectors.


The below pictures show the ports of an E1250-DS-UC drive. On all other LinMot drives supporting EtherCAT DS the ports are named the same (X17 & X18), but they may be placed differently on the drive housing.




18.2.4 Set the node address / station alias by address selectors on the drive

This is the most popular way, because it is user-friendly to maintenance people.

Depending on the LinMot-Drive the address selectors are designed as Hex- or DIP-Switches.



Hex-Switches



DIP-Switches

18.3 Controller Setup

18.3.1 EtherCAT Device Description File (XML)


The EtherCAT device description file (XML) is located by default in the LinMot-Talk installation path:
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\EtherCAT\XML
C:\Program Files (x86)\LinMot\LinMot-Talk X.X Build XXXXXXXXX\Firmware\Interfaces\EtherCat_Nx\XML

18.3.2 Add and setup the LinMot drive


Follow these steps to add the LinMot drive to your Motion Perfect project.

1. Set the node address / station alias address of the LinMot drive to 1 for this example using the S1&S2 address selectors on the drive (if available > check chapter 18.2.4)

Or alternatively in LinMot-Talk set the Alias Address Source of the drive to "Parameter":




And the "Alias Address Parameter" to your desired value (1 in this example):




Attention: A drive reboot is required to activate the address after a change!


2. Set the “Velocity Scale Denominator” to 1:




3. Open the “Intelligent drives” window:




4. Right-Click on the found LinMot device (Address 1 in this case) and select “Import ESI file...”:



5. Select “Import from File...” and select the XML file “NTIL_CiA402_Servos_...”:




6. Choose the following **RxPDO** and **TxDPO** mappings, activate “Generate BOOT configuration” and click “Save”:




Close the window after successfully creating the EC_EXTEND file.


7. Right click on the LinMot device and select "Configure":




8. Set the Axis Address (1 in this case), "Apply" and "Apply & Save To MC_CONFIG":




9. Open the EC_EXTEND file, click to enable editing, and assign the **TARGET_PROFILE_SPEED** instead of **TARGET_SPEED** in the RxPDO to have a smoother motion behaviour of the axis:



10. Reset the controller:



The Master state should now become "Operational":



18.3.3 UNITS for Linear and Rotary Motors

To define the application units (mm, degrees, ...) the drive parameters UNITS and ENCODER_RATIO can be used.

Motor Type	Type	Application units	Counts per Rev	UNITS	ENCODER_RATIO
LinMot PS01 / PS02	Linear	Millimetres [mm]	10'000	10000	-
LinMot RS01 (PR01 & PR02)	Rotary	Degrees [°]	360'000	1000	-
LinMot EC02	Rotary	Degrees [°]	524'288	1456*	(524160,524288)*



***ENCODER_RATIO example for a EC02 motor (From the TrioBASIC help):**

Counts per rev: 524'288

Units per rev: 360 [°]

The highest value that is less than **524288** yet divides into **360** should be chosen. This is **524160** ($524160 / 1456 = 360$). This reduces the resolution from 0.00068664... to 0.00068681... degrees but enables you to program easily in degrees.

Therefor set the drive parameters as follows:

'LinMot EC02 with 524288 counts per motor rev.

ENCODER_RATIO(524160,524288)

UNITS = 1456 'AXIS calibrated IN degrees

18.4 Homing

There are several ways to home an axis.

The example project from chapter **18.1 Overview** contains a program called “AX1_Homing” that uses the DATUM and DEFPOS functions to implement a homing sequence to detect a hard stop.

```
0      '=====
1      'Application based homing procedure (detect hard stop in negative direction)
2      '
3      '=====
4
5      'Variables / Parameters
6      torque_limit = 2500 '=250.0% > Force/Torque Limit in 0.1% for hard stop detection,
7      '5000 = 500% = maximal force/torque of connected motor
8
9      home_position = 0.0 'Position that is set at hard stop
10     init_position = 10.0 'Position the axis moves to after detection
11
12    fe_limit_backup = 0.0 'Backup variable for FE_LIMIT
13
14
15    'Base: Axis 1
16    '=====
17    BASE(1)
18
19    UNITS = 10000 'Set motor units. 10000inc = 1mm
20    'REP_DIST AXIS(axisx) = 360 ' make position modulo 0..360° for rotary axis
21
22
```

**Note:**

This is an application side homing sequence as TRIO does not support the DS402 drive-controlled homing mode (Mode of Operation 6) yet.

18.5 Parameter Access

Parameters can be modified using their UPIDs (Unique Parameter ID) via CoE.

To use a SDO service the **CO_READ_AXIS** and **CO_WRITE_AXIS** functions can be used (See TRIO Basic Help).

Syntax:

- **CO_READ_AXIS**(axis_number, index, subindex ,type [,vr_number])
- **CO_WRITE_AXIS**(axis_number, index, subindex, type, vr_number [,value])

The sub-index specifies the command which is performed

SDO Service	CANopen Object index	CANopen Object sub-index	Description
Read	2000h+UPID	0x01	Parameter UPID read RAM value
Write	2000h+UPID	0x01	Parameter UPID write RAM value
Read	2000h+UPID	0x02	Parameter UPID read ROM value
Write	2000h+UPID	0x02	Parameter UPID write ROM value
Read	2000h+UPID	0x03	Parameter UPID read minimal value
Read	2000h+UPID	0x04	Parameter UPID read maximal value
Read	2000h+UPID	0x05	Parameter UPID read default value
Write	2000h+UPID	0x06	Parameter UPID write RAM and ROM value
Write	2000h	0x07	Parameter Default OS SW instance
Write	2000h	0x08	Parameter Default MC SW instance
Write	2000h	0x09	Parameter Default Intf SW instance
Write	2000h	0x0A	Parameter Default Appl SW instance
Write	2000h	0x0B	Reset device



Attention ROM Access:

Intense use of writing into the ROM memory can reduce the lifetime of the drive memory!
More details can be found in the *Drive Configuration Over Fieldbus (0185-1074)* user manual
> see chapter Documentation / User Manuals

Example Write:

To write 1A to the RAM value of the parameter Maximal Current:

Name: Maximal Current	Index = 16#2000 + 16#13a6 = 16#33a6
UPID: 13A6h	Sub-index = 1
Type: SInt32 = DINT = 4	Value = 1A / 0.001A (scale) = 1'000
Scale: 0.001 A	


VR(200) = 1000 'Set Maximal Current UPID 13A6h to 1A = 1'000
CO_WRITE_AXIS(BASE, \$33a6, 1, 4, 200)

Example Read:

'Read UPID 13A6 Maximal Current in Control Parameter Set A of the drive
CO_READ_AXIS(BASE, \$33a6, 1, 4, 200)
motor_max_current_set_a = **VR(200)**

18.6 Examples

The example project from chapter **18.1 Overview** also contains programs to show a simple positioning cycle and a torque mode sequence.



Just set the correct BASE for the axis you want to use the program with:

```
'Base: Axis 1
',
-----
BASE (1)
```


19 Troubleshooting

The following points should be checked if there are any troubles getting the LinMot drive to connect to the fieldbus or using the LinMot PLC libraries.


- Is the fieldbus connected to the correct connector of the LinMot drive?
E.g., for EtherCAT or PROFINET X17 must be used as input (PLC → X17, X18 → next device)
- Is the address of the LinMot drive set correct? (Node address, MAC ID, IP)
→ Check the fieldbus variables inside LinMot-Talk
- Are all interface parameters on the drive set to the specified values of the library documentation?
→ Check with LinMot-Talk → Parameters → Interface

By default, the LinMot libraries use factory default interface parameters on the LinMot drive.
Except CANopen and LinRS.


- Is the run mode of the drive set to "Motion Command Interface"?



- Is the interface enabled?



On E1100 series drives check if the interface dip switch is set to ON:



- Are there any digital inputs on X4 configured that are controlled by the PLC?
Check if the I/O's are set correctly by the PLC or try to use the default settings and check if it works:

The screenshot shows two tables of parameters in the LinMot configuration software:

Name	Value
IO X4.3 Function	None
IO X4.4 Function	None
IO X4.5 Function	None
IO X4.6 Function	None
IO X4.7 Function	None
IO X4.8 Function	None
IO X4.9 Function	None
IO X4.10 Function	None
IO X4.11 Function	None
IO X4.12 Function	Ctrl Word: Safety Voltage Enable (Input)
X4 I/O Logic Definitions	

Name	Value
Switch On	False
/Quick Stop	True
Enable Operation	True
/Abort Motion Command	True
/Freeze Motion Command	True
Go To Position	False
Error Acknowledge	False
Jog Move +	False
Jog Move -	False
Special Mode	False
Home	False
Clearance Check	False
Go To Initial Position	False
Linearizing	False
Phase Search	False

- If possible, use a clean configuration of the LinMot drive.
 - Install / reinstall the firmware or set the drive to factory settings using LinMot-Talk
 - Set up the motor using the motor wizard
 - Set the fieldbus specific parameters (e.g., node address, IP, ...)

Now check again if the problem still exists

- Are the safety inputs powered before trying to switch on the motor?
 - Is the X4.12 input powered with 24V DC (SVE input on series E1100 and E1200 drives)?
 - Are the safety relays X33 powered (drives with -1S option)?

The screenshot shows a list of control inputs in the LinMot configuration software:

- 0: Switch On.....1Interface
- 1: Safety Volt. Enable...1IO X4.12 Function
- 2: /Quick Stop.....1Forced by Parameter
- 3: Enable Operation....1Forced by Parameter

The entry for "Safety Volt. Enable" is highlighted with a red box.

Appendix I: Basic Position Control Loop Tuning

Tuning the position loop of a LinMot drive depends a lot on the application the motor is used for.




Hint: Further documentation

See application note about **position loop tuning**: 0185-1156 ([EN](#) / [DE](#)).

See application note about using the **LinMot oscilloscope**: 0185-0132 ([EN](#) / [DE](#)).

A basic setup of the position loop parameters could look as follows.

1. Start with the default soft settings suggested in the LinMot-Talk Motor Wizard:




If the motor is mounted vertically or if a high accuracy at the target position is required set the *I Gain* of the position controller to a value between 20 to 50 A/(mm*s).

To reduce noise of the motor it is recommended to set the *D Filter Time* to 500us (C1200, C1100) or 800us (E1100, E1200)

It is highly recommended to disable the *Dead Band*, especially if a Drive Profile is used or in vertical applications. Uncheck *Enable Noise Filter*.


2. After finishing the Motor Wizard, rebooting the drive firmware, enabling, and homing the motor you can start moving the motor. With the built-in oscilloscope in LinMot-Talk you can trace the movement of the motor.

Select the Default oscilloscope and start it by pressing the green arrow .



The green channel shows the *Difference Position* (Position Error) you may want to minimize.

3. Slowly increase the P, D and I Gains in the Control Parameter Set A until the accuracy fits your application, and you have a stable position control loop:



Attention:

When controlling the LinMot drive using a drive profile (e.g., SoE, CiA402, FSP_Drive, ...) and velocity or acceleration jumps occur then try to set **all** FF ... parameters (except *FF Constant Force*) in *Control Parameter Set A* to 0 (zero).

Appendix II: Basic Closed Loop Torque/Force Control Loop Tuning

Tuning the closed loop torque/force control loop of a LinMot drive depends a lot on the application the motor is used for.


Attention:

To use closed loop force/torque control the technology function **TF-Force Control** (0150-2503) is required. Check the manual for more information: [0150-2503](#)


Attention:

An application note about how to setup, tune and use closed loop torque/force control is available with document reference 0185-0144 ([EN](#) / [DE](#)).

Please follow that document to properly setup your system. This chapter here is thought to give a rough overview of where the parameters and variables related to closed loop torque/force control can be found.

Not following the above-mentioned document may lead to sever damage of your system.


Attention:

Before starting any tests with closed loop torque/force control enable the speed limiter!

LinMot-Talk 6.10

File Search Drive Services Options Window Tools Manuals Help

Name	Value	Raw Data	Value...	UPID
Speed Limit	0.2 m/s	00030D40h	*** m/s	1511h
Speed Limiter Abort Force	0 N	0000h	*** N	1513h

This will help to protect you mechanics and sensors.

A basic setup of the torque/force control loop could look as follows:

1. Enable and set the Speed Limiter as shown above
2. Make sure the *TF Force Control* license is activated (Drive > Set Access Code):

Set Access Code

Active Keys:		
Name	Value	Access Code
Key1	5A93h - TF Force Control	2BFD82D9h
Key2	0000h - No Key	

If it is not activated please check the manual [0150-2503](#)


3. Make sure the torque or force sensor is correctly wired to the drive and is setup accordingly:

Name	Value
None	Off
Analog Input On X4.9	Off
Diff Analog Input On X4.10/X4.11	On


Name	Value
0V/-10V Force	0 N
10V Force	100 N
Speed Filter Time	1000 us
Acceleration Filter Time	1000 us

4. Start tuning the control loop. In most application it is enough to increase only slowly the I Gain.

For linear motors (linear system of units) you can use 0.5 A/(N*s) as the step size for the I Gain, for rotary motors (rotary system of units) you can use 50 to 100 A/(Nm*s) as the step size.



5. Setup and start an oscilloscope (see manual 0185-0132 ([EN](#) / [DE](#))) that contains the target and measured torque/force and start your process.



6. Check the result and repeat steps 4 and 5 until you reach the required control quality.

Notes

Contact & Support**Europe / Asia Headquarters****NTI AG - LinMot & MagSpring**

Bodenaeckerstrasse 2
CH-8957 Spreitenbach
Switzerland

Sales / Administration:

+41 56 419 91 91
office@linmot.com

Tech. Support:

+41 56 544 71 00
support@linmot.com

+49 201 858940 10
support@linmot.de

Web:

<https://www.linmot.com>

North / South America Headquarters**LinMot USA Inc.**

N1922 State Road 120, Unit 1
Lake Geneva, WI 53147
USA

Sales / Administration:

262.743.2555
usasales@linmot.com

Tech. Support:

262.743.2555
usasupport@linmot.com

Web:

<https://www.linmot-usa.com>

Visit <https://www.linmot.com/contact> to find a distributor next to you.

Smart solutions are...

