

**LinMot®**

# CC-Link IE Field Basic Interface

---

Manual

**CC-Link *IE* *Field*  
*Basic***

**CSP+**

**This document applies to the following devices:**

- **C1250-CC-xx-xx-xxx (SG6)**
- **C1250-MI-xx-xx-xxx (SG6)**

© 2022 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

#### Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

NTI AG  
LinMot  
Bodenaeckerstrasse 2  
CH-8957 Spreitenbach

Tel.: +41 56 419 91 91  
Fax.: +41 56 419 91 92  
Email: [office@LinMot.com](mailto:office@LinMot.com)  
Homepage: [www.LinMot.com](http://www.LinMot.com)

## Table of Contents

<b>1 SYSTEM OVERVIEW .....</b>	<b>4</b>
<b>2 CONNECTING TO THE CC_LINK IE FIELD BASIC NETWORK .....</b>	<b>5</b>
2.1 PIN ASSIGNMENT OF THE CONNECTORS X17-X18 .....	5
2.2 SETTING THE STATION-ID / IP-ADDRESS .....	5
<b>3 CC-LINK IE FIELD BASIC PARAMETERS AND VARIABLES .....</b>	<b>5</b>
3.1 PARAMETERS .....	5
3.1.1 Dis-/Enable .....	6
3.1.2 IP Configuration / StationID .....	6
3.1.3 IP Configuration / StationID\ IP Configuration Mode .....	6
3.1.4 Monitoring Channels .....	7
3.1.5 Parameter Channels .....	7
3.2 VARIABLES .....	8
<b>4 MAPPING OF PROCESS DATA .....</b>	<b>8</b>
4.1 Data transmitted to PLC .....	8
4.2 Data received from PLC .....	9
<b>5 RT LEDS .....</b>	<b>10</b>
<b>6 INTERFACE ERROR CODES .....</b>	<b>12</b>
<b>7 TROUBLESHOOTING .....</b>	<b>12</b>
7.1 ANALYZING TRAFFIC IN CC-LINK IE FIELD BASIC NETWORKS .....	12
7.2 FREQUENT PROBLEMS AND SOLUTIONS .....	12

## 1 SYSTEM OVERVIEW

The LinMot C1250-CC-xx-xx and C1250-MI-xx-xx devices are CC-Link IE Field Basic slaves with the following parameters:

Device Property	Value
Number of occupied stations	1
Standard response time	1ms or less


For further information on CC-Link IE Field Basic please visit:

<https://www.cc-link.org/en/index.html>

## 2 CONNECTING TO THE CC\_LINK IE FIELD BASIC NETWORK


### 2.1 PIN ASSIGNMENT OF THE CONNECTORS X17-X18

The CC-Link IE Field Basic connector is a standard RJ45 female connector with a pin assignment as defined by EIA/TIA T568B:

X17 – X18	ETHERCAT Connector		
	Pin	Wire color code	Assignment 100BASE-TX
	1	WHT/ORG	Rx+
	2	ORG	Rx-
	3	WHT/GRN	Tx+
	4	BLU	-
	5	WHT/BLU	-
	6	GRN	Tx-
	7	WHT/BRN	-
	8	BRN	-
	case	-	-
RJ-45	Use standard patch cables (twisted pair, S/UTP, AWG26) for wiring. This type of cable is usually referred to as a "Cat5e-Cable".		

### 2.2 SETTING THE STATION-ID / IP-ADDRESS

The lowest byte of the Station ID (192.168.3.x) can be set via the two Hex-Switches S1 and S2. This byte can have a value between 1 (01h) and 254 (FEh). After changing the ID the new value gets active after a reset of the device.

NodeID Selectors		
C12x0		
	S1 (5..8)	Station-ID High Nibble (0 ... F). Bit 5 is the LSB, bit 8 the MSB.
	S2 (1..4)	Station-ID Low Nibble (0 ... F). Bit 1 is the LSB, bit 4 the MSB.  <b>Setting the Station-ID high &amp; low to 0xFF initiates resetting the drive to manufacturer settings!</b>

## 3 CC-LINK IE FIELD BASIC PARAMETERS AND VARIABLES

### 3.1 PARAMETERS

The CC-Link IE Field Basic Interface has an additional parameter tree branch (Parameters → CC-Link IE Field Basic), which can be configured with the distributed LinMot-Talk software.

With these parameters, the CC-Link IE Field Basic behaviour can be configured.  
The LinMot-Talk software can be downloaded from <http://www.linmot.com>.

### 3.1.1 Dis/Enable

With the Dis-/Enable parameter the LinMot device can be run without the CC-Link IE Field Basic Interface going online. So in a first step the system can be configured and run without any bus connection.

<b>CC-Link IE Field Basic Dis/Enable</b>	
Disable	Device runs without CC-Link IE Field Basic.
Enable	Device runs with CC-Link IE Field Basic.



**Important:** If the CC-Link IE Field Basic Interface is disabled, the integrated CC-Link IE Field Basic switch is not powered! No messages will be sent to other devices connected to the network via the LinMot device.

### 3.1.2 IP Configuration / StationID

In this section the IP-Address / StationID can be configured.

<b>CC-Link IE Field Basic IP Configuration / StationID</b>	<b>Default value</b>
IP Configuration Mode	Selects how the IP-Address / StationID is obtained.
	Use configured IP with Hex Switches S1 and S2 as lowest byte
IP address / StationID 1st Byte	1st byte of device IP address.
IP address / StationID 2nd Byte	192
IP address / StationID 3rd Byte	2nd byte of device IP address.
IP address / StationID 4th Byte	3
Netmask 1st Byte	3rd byte of device IP address.
Netmask 2nd Byte	1
Netmask 3rd Byte	Netmask 1st Byte
Netmask 4th Byte	255
Netmask 2nd Byte	2nd byte of device Netmask.
Netmask 3rd Byte	255
Netmask 4th Byte	0
Default Gateway IP 1st Byte	4th byte of device Netmask.
Default Gateway IP 2nd Byte	0
Default Gateway IP 3rd Byte	1st byte of the default gateway IP address.
Default Gateway IP 4th Byte	0
	2nd byte of the default gateway IP address.
	3rd byte of the default gateway IP address.
	4th byte of the default gateway IP address.

### 3.1.3 IP Configuration / StationID\ IP Configuration Mode

In this section the method how to obtain the IP-Address / StationID is configured.

<b>CC-Link IE Field Basic IP Configuration / StationID\ IP Configuration Mode</b>	
Use configured IP with Hex Switches S1 and S2 as lowest Byte	IP Address is configured manually via 'IP Configuration'. The lowest Byte of the IP Address is configured via the Hex Switches S1 and S2.

**CC-Link IE Field Basic IP Configuration / StationID\ IP Configuration Mode**

Use configured IP Address	IP Address is configured manually via 'IP Configuration' .
---------------------------	--

**3.1.4 Monitoring Channels**

In this section the Monitoring Channels can be configured. The monitoring channels are used to map arbitrary parameters in the real-time data transmitted to the PLC via their UPID.

<b>CC-Link IE Field Basic\ Monitoring Channels</b>	<b>Default value</b>
Channel 1 UPID	Defines the source variable by UPID of the monitoring channel 1.
Channel 2 UPID	Defines the source variable by UPID of the monitoring channel 2.
Channel 3 UPID	Defines the source variable by UPID of the monitoring channel 3.
Channel 4 UPID	Defines the source variable by UPID of the monitoring channel 4.
Channel 5 UPID	Defines the source variable by UPID of the monitoring channel 5.
Channel 6 UPID	Defines the source variable by UPID of the monitoring channel 6.
Channel 7 UPID	Defines the source variable by UPID of the monitoring channel 7.
Channel 8 UPID	Defines the source variable by UPID of the monitoring channel 8.

**3.1.5 Parameter Channels**

In this section the Parameter Channels can be configured. The Parameter channels are used to map arbitrary parameters in the real-time data received from the PLC via their UPID.

<b>CC-Link IE Field Basic\ Parameter Channels</b>	<b>Default value</b>
Channel 1 UPID	Defines the source variable by UPID of the parameter channel 1.
Channel 2 UPID	Defines the source variable by UPID of the parameter channel 2.
Channel 3 UPID	Defines the source variable by UPID of the parameter channel 3.
Channel 4 UPID	Defines the source variable by UPID of the parameter channel 4.
Channel 5 UPID	Defines the source variable by UPID of the parameter channel 5.
Channel 6 UPID	Defines the source variable by UPID of the parameter channel 6.
Channel 7 UPID	Defines the source variable by UPID of the parameter channel 7.
Channel 8 UPID	Defines the source variable by UPID of the parameter channel 8.

### 3.2 VARIABLES

Name	Type	Definition
Main State	UInt16 Enumerator	Main State of CC-Link IE FB Interface SW
Error State	UInt16 Enumerator	Error State of CC-Link IE FB Interface SW
Error Code	UInt32	Error Code of CC-Link IE FB Interface SW
Error Location	UInt32	Error Location of CC-Link IE FB Interface SW
IP Address / StationID	String	Active IP address for CC-Link IE FB.
NetMask	String	Active NetMask for CC-Link IE FB.
Default Gateway	String	Active Default Gateway for CC-Link IE FB.
Config Module Control	UInt16	Current Value of Config Module Control
Config Module Index In	UInt16	Current Value of Config Module Index In
Config Module Value In	UInt32	Current Value of Config Module Value In
Config Module Status	UInt16	Current Value of Config Module Status
Config Module Index Out	UInt16	Current Value of Config Module Index Out
Config Module Value Out	UInt32	Current Value of Config Module Value Out

## 4 MAPPING OF PROCESS DATA

The LinMot drive is a CC-Link IE Field Basic slave. To configure it with a CC-Link master, the corresponding CSP+ file is used. The CSP+ File can be found in the installation directory.  
 (typically C:\Program Files\LinMot\LinTalk x.x\Firmware\Interfaces\CCLinkIEFB\CSPP)

### 4.1 Data transmitted to PLC

Data Type	Index	Name	Data Type
RX	-	-	
	-	<b>MCSW_Variables</b>	
RWr	00h	MCSW_StateVar	UInt16
	01h	MCSW_StatusWord	UInt16
	02h	MCSW_WarnWord	UInt16
	03h	MCSW_ActualPosition 32Bit	Int32
	05h	MCSW_DemandPosition 32Bit	Int32

Data Type	Index	Name	Data Type	
	07h	MCSW_DemandCurrent 32Bit	Int32	
	-	<b>UPID_Variables</b>		
	09h	Parameter_by_UPID_01	UInt32	
	0Bh	Parameter_by_UPID_02	UInt32	
	0Dh	Parameter_by_UPID_03	UInt32	
	0Fh	Parameter_by_UPID_04	UInt32	
	11h	Parameter_by_UPID_05	UInt32	
	13h	Parameter_by_UPID_06	UInt32	
	15h	Parameter_by_UPID_07	UInt32	
	17h	Parameter_by_UPID_08	UInt32	
	-	<b>Configuration_Module<sup>1</sup></b>		
	19h	TX_Cfg_Module_Control	UInt16	
	1Ah	TX_Cfg_Module_Index_Out	UInt16	
	1Bh	TX_Cfg_Module_Value_Out	UInt32	

**1** For a detailed description on how to use this module please consult the manual “LinMot drive Configuration over Fieldbus Interfaces SG5”.

#### 4.2 Data received from PLC

Data Type	Index	Name	Data Type	
RY	-	-		
		<b>MCSW_Variables</b>		
RWw	00h	MCSW_ControlWord	UInt16	
	01h	MCSW_MotionCommandHeader	UInt16	
	02h	MCSW_MotionCommandByte_00_01	UInt16	
	03h	MCSW_MotionCommandByte_02_03	UInt16	
	04h	MCSW_MotionCommandByte_04_05	UInt16	
	05h	MCSW_MotionCommandByte_06_07	UInt16	
	06h	MCSW_MotionCommandByte_08_09	UInt16	
	07h	MCSW_MotionCommandByte_10_11	UInt16	
	08h	MCSW_MotionCommandByte_12_13	UInt32	
	09h	MCSW_MotionCommandByte_14_15	UInt16	
	0Ah	MCSW_MotionCommandByte_16_17	UInt16	
	0Bh	MCSW_MotionCommandByte_18_19	UInt16	
	-	<b>UPID_Variables</b>		
	0Ch	Parameter_by_UPID_01	UInt32	
	0Eh	Parameter_by_UPID_02	UInt32	
	10h	Parameter_by_UPID_03	UInt32	
	12h	Parameter_by_UPID_04	UInt32	

Data Type	Index	Name	Data Type
	14h	Parameter_by_UPID_05	UInt32
	16h	Parameter_by_UPID_06	UInt32
	18h	Parameter_by_UPID_07	UInt32
	1Ah	Parameter_by_UPID_08	UInt32
	-	<b>Configuration_Module<sup>1</sup></b>	
	1Ch	RX_Cfg_Module_Status	UInt16
	1Dh	RX_Cfg_Module_Index_In	UInt16
	1Eh	RX_Cfg_Module_Value_In	UInt32

**1** For a detailed description on how to use this module please consult the manual “LinMot drive Configuration over Fieldbus Interfaces SG5”.

## 5 RT LEDS

Error Codes		
 C1250-CC: ERROR		
OK	RT Bus	Description
L3	(RU	Bus
N)	Erro	
	r	
	L4	
	(ER	
	R)	
Off	-	Station is disconnected.
On	-	Station in operation and cyclic transmission in progress.
Flickering	-	Station not configured.
Blinking	-	Station in operation and cyclic transmission stopped.
-	Off	Station in normal operation.
-	On	Communication error (e.g. no PLC connected).
-	Triple Flash	DPM watchdog has expired.

- Off: constantly off.  
 On: constantly on.  
 Flickering: equal on and off times with a frequency of approximately 10 Hz.  
 Blinking: equal on and off times with a frequency of approximately 2,5 Hz.  
 Single Flash: one short flash followed by a long off phase.

Double Flash: a sequence of two short flashes, separated by an off phase . The sequence is finished by a long off phase.

Triple Flash: a sequence of three short flashes, separated by an off phase . The sequence is finished by a long off phase.

## 6 INTERFACE ERROR CODES

Please refer to “Usermanual Motion Control Software” for the error codes of the MC software. The CC-Link IE FB interface has the following additional error codes:

Error Code	Error Description	Recommended Actions
C0h	Cfg Err: Invalid StationID	The defined StationID is not in the valid range.

## 7 TROUBLESHOOTING

### 7.1 ANALYZING TRAFFIC IN CC-LINK IE FIELD BASIC NETWORKS

To analyze the data traffic in a CC-Link IE Field Basic network the use of a network protocol analyzer is strongly recommended.

Wireshark is one of the most used analyzers and can be downloaded free of charge from  
<http://www.wireshark.org>.

### 7.2 FREQUENT PROBLEMS AND SOLUTIONS

Problem:	The drive cannot connect to the PLC
Possible Solution:	Check if the Station-ID / IP-Address of the drive matches with the one configured in the PLC.
Possible Solution:	Check if the Station-ID / IP-Address of the drive is unique, and no other device in the network has the same ID.

## Contact & Support

### SWITZERLAND

#### NTI AG

Bodenaeckerstrasse 2  
CH-8957 Spreitenbach

Sales and Administration:

+41 56 419 91 91

[office@linmot.com](mailto:office@linmot.com)

Tech. Support:

+41 56 544 71 00

[support@linmot.com](mailto:support@linmot.com)

<http://www.linmot.com/support>

Tech. Support (Skype):

support.linmot

Fax:

+41 56 419 91 92

Web:

<http://www.linmot.com>

---

### USA

#### LinMot USA Inc.

N1922 State Road 120, Unit 1  
Lake Geneva, WI 53147  
USA

Phone:

262-743-2555

E-Mail:

[usasales@linmot.com](mailto:usasales@linmot.com)

Web:

<http://www.linmot-usa.com/>

---

Please visit <http://www.linmot.com/contact> to find the distribution close to you.

Smart solutions are...

